

---

**User's  
Manual**

ADMAG **AXF**<sup>™</sup>

**AXF  
PROFIBUS PA Communication Type  
Magnetic Flowmeter**

IM 01E20F12-01E

---

**vigilantplant**<sup>®</sup>



# CONTENTS

---

|  |            |
|--|------------|
| <b>1. INTRODUCTION .....</b>                   | <b>1-1</b> |
| 1.1 Using the Magnetic Flowmeter Safely .....  | 1-2        |
| 1.2 Warranty .....                             | 1-4        |
| 1.3 Combination Remote Flowtubes .....         | 1-4        |
| <b>2. ABOUT PROFIBUS PA .....</b>              | <b>2-1</b> |
| 2.1 Outline .....                              | 2-1        |
| 2.2 Internal Structure of AXF .....            | 2-1        |
| 2.3 Logical Structure of Each Block .....      | 2-1        |
| 2.4 Wiring System Configuration .....          | 2-1        |
| <b>3. GETTING STARTED .....</b>                | <b>3-1</b> |
| 3.1 Connection of Devices .....                | 3-1        |
| 3.2 Master Settings .....                      | 3-2        |
| 3.3 Integration of GSD .....                   | 3-2        |
| 3.4 Bus and AXF Power ON .....                 | 3-3        |
| 3.5 Setting of Write Protect Switch .....      | 3-4        |
| 3.6 Engineering Tools .....                    | 3-5        |
| 3.6.1 FieldMate for DTM .....                  | 3-5        |
| 3.6.2 SIMATIC PDM for EDDL .....               | 3-5        |
| 3.7 Starting FieldMate .....                   | 3-6        |
| <b>4. CONFIGURATION .....</b>                  | <b>4-1</b> |
| 4.1 Description of Basic Parameters .....      | 4-1        |
| 4.1.1 Physical Block Parameters .....          | 4-1        |
| 4.1.2 AI Block Parameters .....                | 4-1        |
| 4.1.3 Transducer Block Parameters .....        | 4-2        |
| 4.1.4 Totalizer Block Parameters .....         | 4-5        |
| 4.1.5 DI Block Parameters .....                | 4-8        |
| <b>5. EXPLANATION OF BASIC ITEMS .....</b>     | <b>5-1</b> |
| 5.1 Outline .....                              | 5-1        |
| 5.2 Basic Parameter Setting and Changing ..... | 5-1        |
| 5.2.1 Explanation of Menu .....                | 5-1        |
| 5.3 Bus Address Setup .....                    | 5-4        |
| 5.4 Easy Setup .....                           | 5-6        |
| 5.5 Function Blocks Setting .....              | 5-7        |
| 5.5.1 Physical Block Parameters Setup .....    | 5-7        |
| 5.5.2 AI Block Parameters Setup .....          | 5-8        |
| 5.5.3 Transducer Block Parameters Setup .....  | 5-9        |
| 5.5.4 Totalizer Block Parameters Setup .....   | 5-10       |
| 5.5.5 DI Block Parameters Setup .....          | 5-11       |
| 5.6 Integral LCD Indicator .....               | 5-12       |
| 5.6.1 Flow Data Display .....                  | 5-12       |
| 5.6.2 Display Modes .....                      | 5-17       |

|   |             |
|---|-------------|
| <b>6. IN-PROCESS OPERATION .....</b>  | <b>6-1</b>  |
| 6.1 Mode Transition .....   | 6-1         |
| 6.2 Generation of Alarm .....   | 6-1         |
| 6.2.1 Indication of Alarm .....   | 6-1         |
| 6.2.2 Alarms and Warnings .....   | 6-1         |
| 6.3 Simulation Function .....   | 6-5         |
| 6.3.1 Transducer Block .....  | 6-6         |
| 6.3.2 AI / TOT / DI Blocks .....  | 6-7         |
| 6.3.3 Physical Block .....  | 6-7         |
| 6.3.4 Simulation Parameter Setup by FieldMate R1.03 .....                           | 6-9         |
| <b>7. DIAGNOSTIC INFORMATION .....</b>  | <b>7-1</b>  |
| 7.1 DEVICE STATUS .....   | 7-1         |
| <b>8. GENERAL SPECIFICATIONS .....</b>  | <b>8-1</b>  |
| 8.1 STANDARD SPECIFICATIONS .....   | 8-1         |
| 8.2 OPTIONAL SPECIFICATIONS .....   | 8-2         |
| 8.3 TERMINAL CONNECTION .....   | 8-3         |
| <b>9. PARAMETER LISTS .....</b>   | <b>9-1</b>  |
| 9.1 Physical Block Parameter List (Slot 0) .....                                    | 9-1         |
| 9.2 AI Block Parameter List (Slot 1) .....  | 9-3         |
| 9.3 Transducer Block Parameter List (Slot 7) .....                                  | 9-5         |
| 9.4 Totalizer Block Parameter List (TOT1: Slot2, TOT2: Slot3,<br>TOT3: Slot4) ..... | 9-10        |
| 9.5 DI Block Parameter List (DI1: Slot5, DI2: Slot6) .....                          | 9-12        |
| <b>10. MAINTENANCE .....</b>  | <b>10-1</b> |
| <b>APPENDIX 1. LIST OF DTM MENU .....</b>   | <b>A-1</b>  |
| <b>APPENDIX 2. LIST OF PDM (EDDL) MENU .....</b>                                    | <b>A-3</b>  |
| <b>REVISION RECORD</b>  |             |

# 1. INTRODUCTION

---

This manual contains a description of the ADMAG AXF Series Magnetic Flowmeter Converter PROFIBUS PA Communication Type. The PROFIBUS PA communication type is based on the same ADMAG AXF technology used in the BRAIN/HART communication type, and is similar to the communication types in terms of basic performance and operation. This manual describes only those topics that are required for operation of the PROFIBUS PA communication type. For information on the installation, wiring, and maintenance of AXF series magnetic flowmeter, refer to the user's manual for each model (IM 01E20D01-01E or IM 01E20C02-01E).

As far terminal connection, refer to section 8.3 of this manual.



## NOTE

When describing the model name like AXF□□□C in this manual, "□□□" means any of the following.

002, 005, 010, 015, 025, 032, 040, 050, 065, 080, 100, 125, 150, 200, 250, 300, 350, 400

## ■ Regarding This Manual

- This manual should be provided to the end user.
- Before use, read this manual thoroughly to comprehend its contents.
- The contents of this manual may be changed without prior notice.
- All rights are reserved. No part of this manual may be reproduced in any form without Yokogawa's written permission.
- Yokogawa makes no warranty of any kind with regard to this material, including, but not limited to, implied warranties of merchantability and suitability for a particular purpose.
- All reasonable effort has been made to ensure the accuracy of the contents of this manual. However, if any errors or omissions are found, please inform Yokogawa.
- Yokogawa assumes no responsibilities for this product except as stated in the warranty.
- The specifications covered by this manual are limited to those for the standard type under the specified model number break-down and do not cover custom-made instruments.

- Please note that this user's manual may not be revised for any specification changes, construction changes or operating part changes that are not considered to affect function or performance.
- If the customer or any third party is harmed by the use of this product, Yokogawa assumes no responsibility for any such harm owing to any defects in the product which were not predictable, or for any indirect damages.

## ■ Safety and Modification Precautions

- The following general safety precautions must be observed during all phases of operation, service, and repair of this instrument. Failure to comply with these precautions or with specific WARNINGS given elsewhere in this manual violates safety standards of design, manufacture, and intended use of the instrument. Yokogawa assumes no liability for the customer's failure to comply with these requirements. If this instrument is used in a manner not specified in this manual, the protection provided by this instrument may be impaired.
- Yokogawa will not be liable for malfunctions or damage resulting from any modification made to this instrument by the customer.
- The following safety symbol marks are used in this user's manual and instrument.



## WARNING

A WARNING sign denotes a hazard. It calls attention to procedure, practice, condition or the like, which, if not correctly performed or adhered to, could result in injury or death of personnel.



## CAUTION

A CAUTION sign denotes a hazard. It calls attention to procedure, practice, condition or the like, which, if not correctly performed or adhered to, could result in damage to or destruction of part or all of the product.

**IMPORTANT**

An **IMPORTANT** sign denotes that attention is required to avoid damage to the instrument or system failure.

**NOTE**

A **NOTE** sign denotes information necessary for essential understanding of operation and features.

- ⊕ Protective grounding terminal
- ⊖ Functional grounding terminal  
(This terminal should not be used as a protective grounding terminal.)

PROFIBUS is a registered trademark of PROFIBUS Nutzerorganisation e.V., Karlsruhe, Germany.



## 1.1 Using the Magnetic Flowmeter Safely

### (1) Installation

**WARNING**

- Installation of the magnetic flowmeter must be performed by expert engineer or skilled personnel. No operator shall be permitted to perform procedures relating to installation.
- The magnetic flowmeter must be installed within the specification conditions.
- The magnetic flowmeter is a heavy instrument. Be careful that no damage is caused to personnel through accidentally dropping it, or by exerting excessive force on the magnetic flowmeter. When moving the magnetic flowmeter, always use a trolley and have at least two people carry it.
- When the magnetic flowmeter is processing hot fluids, the instrument itself may become extremely hot. Take sufficient care not to get burnt.

- Where the fluid being processed is a toxic substance, avoid contact with the fluid and avoid inhaling any residual gas, even after the instrument has been taken off the piping line for maintenance and so forth.
- Do not apply excessive weight, for example, a person stepping on the magnetic flowmeter.
- All procedures relating to installation must comply with the electrical code of the country where it is used.

### (2) Wiring

**WARNING**

- The wiring of the magnetic flowmeter must be performed by expert engineer or skilled personnel. No operator shall be permitted to perform procedures relating to wiring.
- When connecting the wiring, check that the supply voltage is within the range of the voltage specified for this instrument before connecting the power cable. In addition, check that no voltage is applied to the power cable before connecting the wiring.
- The protective grounding must be connected securely at the terminal with the ⊕ mark to avoid danger to personnel.

### (3) Operation

**WARNING**

- When opening the cover, wait for more than 10 minutes after turning off the power. Only expert engineer or skilled personnel are permitted to open the cover.
- Do not open the cover in wet weather or humid environment. When the cover is open, stated enclosure protection is not applicable.

### (4) Maintenance

**WARNING**

- Maintenance of the magnetic flowmeter should be performed by the trained personnel having knowledge of safety standard. No operator shall be permitted to perform any operations relating to maintenance.
- When opening the cover, wait for more than 10 minutes after turning off the power.

- Do not open the cover in wet weather or humid environment. When the cover is open, stated enclosure protection is not applicable.
- Always conform to maintenance procedures outlined in this manual. If necessary, contact Yokogawa.
- Care should be taken to prevent the build up of dirt, dust or other substances on the display panel glass or data plate. If these surfaces do get dirty, wipe them clean with a soft dry cloth.

#### (5) Explosion Protected Type Instrument



#### WARNING

- Magnetic flowmeters with the model name AXF□□□C are products which have been certified as explosion proof type instruments. Strict limitations are applied to the structures, installation locations, external wiring work, maintenance and repairs, etc. of these instruments. Sufficient care must be taken, as any violation of the limitations may cause dangerous situations.  
Be sure to read “EXPLOSION PROTECTED TYPE INSTRUMENT” at the user’s manual for each model (IM 01E20D01-01E or IM 01E20C02-01E), before handling the instruments. The description is prior to the other description in this user’s manual.  
For TIIS flameproof type instruments, be sure to read “INSTALLATION AND OPERATING PRECAUTIONS FOR TIIS FLAMEPROOF EQUIPMENT” at the end of the user’s manual for each model (IM 01E20D01-01E or IM 01E20C02-01E).
- Only trained persons use this instrument in the industrial location.
- The protective grounding (⊕) must be connected to a suitable IS grounding system.
- Take care not to generate mechanical spark when access to the instrument and peripheral devices in hazardous locations.

#### (6) European Pressure Equipment Directive (PED)



#### WARNING

- When using the instrument in compliance with PED, be sure to read IM 01E20D01-01E before use.

#### (7) Modification



#### WARNING

- Yokogawa will not be liable for malfunctions or damage resulting from any modification made to this instrument by the customer.

#### (8) Product Disposal

The instrument should be disposed of in accordance with local and national legislation/regulations.

#### (9) Authorized Representative in EEA

In relation to the CE Marking, The authorized representative for this product in the EEA (European Economic Area) is:

Yokogawa Europe B.V.

Euroweg 2, 3825 HD Amersfoort, The Netherlands

## 1.2 Warranty

- The terms of this instrument that are guaranteed are described in the quotation. We will make any repairs that may become necessary during the guaranteed term free of charge.
- Please contact our sales office if this instrument requires repair.
- If the instrument is faulty, contact us with concrete details about the problem and the length of time it has been faulty, and state the model and serial number. We would appreciate the inclusion of drawings or additional information.
- The results of our examination will determine whether the meter will be repaired free of charge or on an at-cost basis.

### ■ The guarantee will not apply in the following cases:

- Damage due to negligence or insufficient maintenance on the part of the customer.
- Problems or damage resulting from handling, operation or storage that violates the intended use and specifications.
- Problems that result from using or performing maintenance on the instrument in a location that does not comply with the installation location specified by Yokogawa.
- Problems or damage resulting from repairs or modifications not performed by Yokogawa or someone authorized by Yokogawa.
- Problems or damage resulting from inappropriate reinstallation after delivery.
- Problems or damage resulting from disasters such as fires, earthquakes, storms, floods, or lightning strikes and external causes.

### ■ Trademarks:

- All the brands or names of Yokogawa Electric's products used in this manual are either trademarks or registered trademarks of Yokogawa Electric Corporation.
- All other company and product names mentioned in this manual are trade names, trademarks or registered trademarks of their respective companies.
- In this manual, trademarks or registered trademarks are not marked with <sup>TM</sup> or ®.

## 1.3 Combination Remote Flowtubes



### IMPORTANT

The AXF remote flowtube (sizes 2.5 to 400 mm (0.1 to 16 in.)) should be combined with one of the following converters:

| Remote Flowtube |                    | Combined with the Remote Converter |
|-----------------|--------------------|------------------------------------|
| Model           | Communication Code | Model                              |
| AXF□□□G         | -P                 | AXFA14C<br>AXFA14G                 |
| AXF□□□C         |                    |                                    |
| AXF□□□H         |                    |                                    |
| AXF□□□W         |                    |                                    |

T0101.EPS

Note: "□□□" means any of the following.

002, 005, 010, 015, 025, 032, 040, 050,  
065, 080, 100, 125, 150, 200, 250, 300,  
350, 400



### CAUTION

In case of the explosion proof type, please see the manual IM 01E20D01-01E or IM 01E20C02-01E. The construction of the instrument, installation, external wiring, maintenance, and repair are strictly restricted, and non-observance or negligence of these restriction would result dangerous condition.



## 2. ABOUT PROFIBUS PA

### 2.1 Outline

PROFIBUS PA is a widely used bi-directional digital communication protocol that enables the implementation of technologically advanced process control systems. The AXF Series PROFIBUS PA communication type meets the specifications of PROFIBUS Nutzerorganisation e.V. and is interoperable with devices from Yokogawa and other manufacturers.

For information on other features, engineering, design, construction work, startup and maintenance of PROFIBUS PA, please download the adequate documents and read them by visiting the following web-site of PROFIBUS Nutzerorganisation e.V..

<http://www.profibus.com/>

### 2.2 Internal Structure of AXF

The AXF contains four blocks that share the following functions:

#### (1) Physical block

- Manages the status of AXF hardware.
- Automatically informs the host of any detected faults or other problems.

#### (2) Transducer block

- Converts sensor output to flow rate signal and transfers to AI function block.

#### (3) AI function block

- Conditions raw data from the transducer block.
- Outputs flow rate signal.
- Carries out scaling and damping extraction.

#### (4) Totalizer function block

- Totalization of raw data from the Transducer block.

#### (5) DI function block

- Conditions discrete data from the Transducer block.

### 2.3 Logical Structure of Each Block




Figure 2.1 Logical Structure of Each Block

The parameters shown in Figure 2.1 must be set before starting operation.

### 2.4 Wiring System Configuration

The number of devices that can be connected to a single bus and the cable length vary depending on system design. When constructing systems, both the basic and overall design must be carefully considered to allow device performance to be fully exhibited.

# 3. GETTING STARTED

PROFIBUS PA is fully dependent upon digital communication protocol and differs in operation from conventional 4 to 20 mA transmission and the BRAIN communication protocol.




Figure 3.1 PROFIBUS System Construction

## 3.1 Connection of Devices

The following are required for use with PROFIBUS PA devices:

- Power supply:**  
 PROFIBUS PA requires a dedicated power supply. It is recommended that current capacity be well over the total value of the maximum current consumed by all devices. Power is supplied by a DP/PA coupler.
- Terminators:**  
 PROFIBUS PA requires two terminators. A terminator shall be located at each end of the trunk cable.
- Field devices:**  
 Connect PROFIBUS PA communication type AXF (Refer to section 8.3 terminal connection). Two or more AXF devices or other devices can be connected.

- DP/PA Couplers:**

PROFIBUS PA requires DP/PA couplers which convert the RS-485 signals to the IEC 61158-2 signal level and power the field devices via the PROFIBUS PA.

- Cable:**

Refer to Figure 3.1.

Table 3.1 PROFIBUS PA Cables and Transmissible Length

| Type of cable                                    | Cable specifications           | Max. length of cable (reference value) |
|--|--------------------------------|--|
| Type A: Individually-shielded twisted pair cable | #18AWG (0.82 mm <sup>2</sup> ) | 1,900 m                                |
| Type B: Overall-shielded twisted pair cable      | #22AWG (0.32 mm <sup>2</sup> ) | 1,200 m                                |
| Type C: Unshielded twisted pair cable            | #26AWG (0.13 mm <sup>2</sup> ) | 400 m                                  |
| Type D: Overall-shielded non-twisted cable       | #16AWG (1.25 mm <sup>2</sup> ) | 200 m                                  |

T0401.EPS

Note: Yokogawa recommends the use of Type A. Usage of Type B and D is restricted.

Yokogawa does not recommend the use of Type C.

Before using a PROFIBUS PA configuration tool other than the existing class 1 and class 2 Masters, confirm it does not affect the loop functionality in which all devices are already installed in operation. Disconnect the relevant control loop from the bus if necessary.



### IMPORTANT

- It is mandatory to turn on the power supply of the AXF before turning on the power supply for the PROFIBUS line.
- Connecting a PROFIBUS PA configuration tool to a loop with its existing class 1 and class 2 Masters may cause communication data scrambling resulting in a functional disorder or a system failure.

## 3.2 Master Settings

To activate PROFIBUS PA, the following bus parameters must be set for the master.



### IMPORTANT

Do not turn off the power immediately after setting. When the parameters are saved to the EEPROM, the redundant processing is executed for an improvement of reliability. If the power is turned off within 60 seconds after setting is made, the modified parameters are not saved and the settings may return to the original values.

Table 3.2 Bus Parameters

| Symbol            | Parameter                | Description and Settings  |
|-------------------|--------------------------|---|
| Transmission rate | Transmission Rate        | The transmission rate of PROFIBUS PA matches that of the segment coupler.<br>e.g P+F: 93.75 kbps,<br>Siemens: 45.45 kbps        |
| TSL               | Slot Time                | The maximum time a master station must wait for the complete reception of the first octet of a response (11 bits).<br>e.g: 4095 |
| min TSDR          | Min. Station Delay Timer | Sets the minimum time at which a slave can send the first bit of a response back.   |
| max TSDR          | Max. Station Delay Time  | Sets the maximum time at which a slave can send the first bit of a response back.   |
| TQUI              | Quiet Time               | Controls the time at which the bus electronics or software of the sender is set to receive mode after a message is sent.        |
| TSET              | Setup Time               | Sets the maximum allowable time for parameter setting and response by the slave.  |
| HSA               | Highest Station Address  | Sets the highest station address in the network.  |
| G                 | Gap update factor        | Sets the number of token cycles after which the master will search for a new master.  |
| max. retry limit  | Max Retry Limit          | Sets the number of retries that are performed after a receiver does not respond to a message.                                   |

T0302.EPS

## 3.3 Integration of GSD

A PROFIBUS PA system requires a GSD file containing device parameters such as the supported transmission rate, input data, output data, data format and data length.

The following GSD files are available for the AXF.

Table 3.3 GSD files

|                              |                            |
|------------------------------|----------------------------|
| Profile Ident-Number         | 0x9740                     |
| Profile GSD file             | PA139740.GSD (Alx1, TOTx1) |
| Device Specific Ident-Number | 0x4590                     |
| Device Specific GSD file     | YEC_4590.GSD               |

T0303.EPS

Download GSD for AXF from the following website.  
<http://www.yokogawa.com/fld/doc/profibus/>



### IMPORTANT

Do not change contents in the GSD file from the factory default. The AXF may be given a serious problem in its operation if do so.

### 3.4 Bus and AXF Power ON

#### Address setting Switch

A setup of bus address is possible by the change with a parameter, or the hardware slide switch.

The set address which is done by hardware is higher priority than by software.

Following description is how to set the bus address using by hardware slide switch.


Refer to section 5.3 when the bus address is set by software.

The AXF must turn off the power supply when the bus address is changed by hardware slide switch.

The device information, including Tag Desc., Bus address, and Ident Number, is described on the sheet attached to the AXF. The device information is given in duplicate on this sheet.

Confirm the bus address written in the device information.

The default bus address is set as 126 (hexadecimal 7E) at the factory unless otherwise specified when ordered.





F0302.EPS

Figure 3.2 Device Information Sheet Attached to AXF

Confirm that the AXF is turned off before opening the front cover. The bus address switch is located as shown in figure 3.3. The No. 8 switch of SW102 is turned ON first. Other seven switches of No. 1 to No. 7 on the SW102 are for setting address. No. 1 switch of SW102 is allocated for bit0 of address, and No. 7 switch of SW102 is allocated for bit6 of address. The setting condition of the SW102 as shown in figure 3.3 is 3 as the set bus address number as an example. If two or more AXFs are connected on the same bus, each AXF must be set as different bus address.

The front cover must be closed after finish the work of the bus address setting.



| MSB |     |     |     | LSB |     |    |    |
|-----|-----|-----|-----|-----|-----|----|----|
| 8   | 7   | 6   | 5   | 4   | 3   | 2  | 1  |
| ON  | OFF | OFF | OFF | OFF | OFF | ON | ON |

F0303E.EPS

Figure 3.3 Address Switch



#### WARNING

When opening the cover, wait for more than 10 minutes after turning off the power. Furthermore, opening of the cover must also be carried out by the trained personnel having knowledge of safety standard.



#### IMPORTANT

To preserve the safety, do not touch the electrical circuit and the cables except the Bus address switch.

#### Bus and AXF Power ON

Firstly, turn on the power of the host, and then, the bus and also the power for the AXF. Where the AXF is equipped with the LCD indicator, first all segments are lit, then the display begins to operate.

Using the host device display function, check that the AXF is in operation on the bus.

If no AXF is detected, check the available address range. If the Bus address and Tag Desc. are not specified when ordering, default value is factory set. If two or more AXFs are connected at the same time with default value, only one AXF will be detected from the host as AXFs have the same initial address. Separately connect each AXF and set a different address for each.


### 3.5 Setting of Write Protect Switch

A write protection is a function to forbid changing of parameters. It is possible to set the software write protection by parameter setup or the hardware write protection by the hardware slide switch. In case of the setting up by parameters, it can set up in WRITE\_LOCKING. When WRITE\_LOCKING is “0: Lock”, the status of write protect becomes protected mode. And when WRITE\_LOCKING is “2457: Disabled”, the status becomes disable mode. In case of the setting up by hardware switch, it can set up on the No.1 switch of SW101. When the switch is turned on, the status becomes protected mode, and when the switch is turned off, the status becomes disable mode. The state of the hardware write-protection switch can be checked with the parameter “HW\_WRITE\_PROTECTION.” As the mentioned above, write protection is available by the setting either of software protection or hardware protection, one of them is set to protect mode, the status becomes protected mode.

Table 3.4 Write Protect

| Setting of Hardware Write Protect SW | Displaying of HW_WRITE_PROTECTION | Setting of WRITE_LOCKING | State of Protect Protect State |
|--------------------------------------|-----------------------------------|--------------------------|--------------------------------|
| Enable                               | 0:Unprotected                     | 0: Lock                  | Protect                        |
| Enable                               | 0:Unprotected                     | 2457: Disabled           | Enable                         |
| Protect                              | 1:Protected                       | 0: Lock                  | Protect                        |
| Protect                              | 1:Protected                       | 2457: Disabled           | Protect                        |

T0304E.EPS



F0304.eps

Figure 3.4 Write Protection Switch

**! WARNING**

When opening the cover, wait for more than 10 minutes after turning off the power. Furthermore, opening of the cover must also be carried out by the trained personnel having knowledge of safety standard.

**⚡ IMPORTANT**

To preserve the safety, do not touch the electrical circuit and the cables except the setting switches.

## 3.6 Engineering Tools

Engineering of the AXF PROFIBUS PA can be performed with the following two tools.

### 3.6.1 FieldMate for DTM

Yokogawa's FieldMate is a configuration/management tool for devices based on FDT/DTM technology. DTM is software for the adjustment, configuration, calibration and testing of devices.

For AXF configuration, the following devices and software are required.

- FieldMate R1.03 (FSA110 or FSA111)
- PROFIBUS card2 and COMM DTM Ver. 2.04 or later (supplied by Softing)
- PC
- DP/PA coupler (supplied by SIEMENS or P+F)
- Terminators
- Power supply
- PROFIBUS cable
- AXF DTM

Download DTM for AXF from the following website.

<http://downloads.yokogawa-europe.com/>

For each device, software and PC operating environment, refer to the corresponding user's manual.

For further information on AXF configuration using FieldMate, see chapter 5. A list on menus is shown in APPENDIX 1.

### 3.6.2 SIMATIC PDM for EDDL

Electronic Device Description Language (EDDL) defines field device information, and can be used independently of vendors. EDDL files can be read by engineering tools, and the software is used to conduct adjustment, configuration, calibration and tests of devices.

Necessary devices and software

- SIMATIC PDM (supplied by SIEMENS)
- PROFIBUS communication card (supplied by SIEMENS)
- PC
- DP/PA coupler (supplied by SIEMENS or P+F)
- Terminators
- Power supply
- PROFIBUS cable
- AXF EDDL

Download EDDL for AXF from the following website.

<http://www.yokogawa.com/fld/doc/profibus/>

For further information on the operating environment, refer to the software/device user's manual.

For information on AXF configuration using SIMATIC PDM, refer to the SIMATIC PDM user's manual.

For a list on menus, see APPENDIX 2.

#### Sample Hardware Setup




Figure 3.5 Sample Hardware Setup

## 3.7 Starting FieldMate

The following section describes how to run DTM with FieldMate R1.03.

For the detailed information on FieldMate, see its User's manual.



### IMPORTANT

- Before running the program, log-in to Windows as an Administrator or as a user with administrative authority.
- When comm. DTM is connected to the PROFIBUS network with class 1 master running, set the same busparameters of class 1 master.
- The FieldMate R1.03 has the DTM for AXF PROFIBUS PA as its standard package. Hence, it is recommended to use the R1.03 with AXF.

If the AXF connects to the FieldMate R1.02, the DTM for AXF is necessary to download from the following web-site and combine to the FieldMate R1.02 by DTM Setup tool at first.  
<http://downloads.yokogawa-europe.com/>

### Start FieldMate

Start FieldMate as followings:

Click [Start] → [All Programs] → [YOKOGAWA FieldMate] → [FieldMate]

Select [PROFIBUS] and then click [OK] in the Login Window.

The FieldMate starts to communicate, and the following window is appeared when this action was finished.




Figure 3.7.1 FieldMate R1.03

### New Device Maintenance Info

Click [Action] → [Register Device Maintenance Info].

The new device maintenance information is registered when this work was finished.




Figure 3.7.2 Register Device Maintenance Info

Next, click [Action] → [Open Device Maintenance Info]. The FieldMate confirms the device to open, then, select the adequate AXF on this menu, and click [OK].

The FieldMate shows the [Device Maintenance Info window] for AXF as shown in Figure 3.7.3 next. Set the adequate parameters if necessary depending on changing parameters against factory default values.

Close the window after saving if parameters on this menu were changed ([File] → [Save]).




Figure 3.7.3 Device Maintenance Info

## Starting DTM Works

In the FieldMate window (as shown in the Figure 3.7.1), click the icon of the device at its Main Window. Next, select [AXF PA V1.1] and click [OK] when the following small window was appeared.




Figure 3.7.4 Select Device DTM

The DTM Works starts to open, and the following new window is appeared. It is able to set parameters of the AXF in detail.




Figure 3.7.5 DTM Works

Refer to Chapter 5 how to operate the AXF in the FieldMate R1.03 for detail.




# 4. CONFIGURATION

This chapter describes the basic parameters for the three block types and explains how to set and change these parameters.

## 4.1 Description of Basic Parameters

### 4.1.1 Physical Block Parameters




F0401.EPS

Figure 4.1 Overview of Physical Block

Physical block parameters contain the characteristic data of a device such as the tag number, device name,

### 4.1.2 AI Block Parameters



F0402.EPS

Figure 4.2 Overview of AI Block

The AI block contains all the data for final processing of measured values prior to transmission to the master system. For a list of the parameters in the AXF blocks, see “Chapter 9”. The following describes the basic parameters of the AI block.

version, and serial number, etc. For a list of the parameters in the AXF blocks, see “Chapter 9”. The following is a list of basic parameters of the physical block.

#### TARGET\_MODE:

Indicates the physical block mode: Out of Service (O/S) or AUTO. In Out of Service mode, the block does not operate. Under normal circumstances, this is set to AUTO mode.

#### TAG\_DESC:

Tag description parameter (32chars.)

#### DESCRIPTOR:

User-definable text (a string) to describe the device application (32chars.)

#### WRITE\_LOCKING:

Locks the software in read-only mode.

**TARGET\_MODE:**

Indicates the AI block mode: Out of Service (O/S), MAN, or AUTO. Target Mode indicates what mode of operation is desired for the AI block. In Out of Service mode, the AI block does not operate. Manual mode does not allow values to be updated. AUTO mode causes the measured values to be updated. Under normal circumstance, set this to AUTO mode. AUTO mode is the factory default.

**SIMULATE:**

For commissioning and test purposes the input value from the Transducer Block in the Analog Input Function Block AI-FB can be modified. That means that the Transducer and AI-FB will be disconnected.

**OUT\_SCALE:**

Set the range of output (from 0% to 100%). The unit can also be set.

**PV\_FTIME:**

Sets the damping time constant of a single exponential filter for the PV, in seconds.

**FSAFE\_TYPE:**


This defines how the function block will operate if a fault is detected.

**FSAFE\_VALUE:**

This sets the default value for the OUT parameter, if a sensor or a sensor electric fault is detected.

**HI\_HI\_ALM, HI\_ALM, LO\_ALM, LO\_LO\_ALM:**

Specifies the level setting value for each alarm of flow rate limit depending on the necessity.

**4.1.3 Transducer Block Parameters**

F0403.EPS

**Figure 4.3 Overview of Transducer Block**

The transducer block sets functions specific to the measurements AXF. For a list of the AXF block parameters, see “Chapter 9”. The following describes the basic parameters of the transducer block.

**TARGET\_MODE:**

Indicates the physical block mode: Out of Service(O/S) or AUTO. In Out of Service mode, the block does not operate. Under normal circumstances, set this to AUTO mode.

**NOMINAL\_SIZE:**

Specifies the size of the flow tube.

**NOMINAL\_SIZE\_UNITS:**

Specifies the unit of the flow tube size.

**LOW\_MF:**

Specifies the meter factor of low frequency side.

**HIGH\_MF:**

Specifies the meter factor of high frequency side.

**LOW\_MF\_EDF:**

Specifies the meter factor of low frequency side under enhanced dual frequency mode.

**HIGH\_MF\_EDF:**

Specifies the meter factor of high frequency side under enhanced dual frequency mode.

**VOLUME\_FLOW\_UNITS:**

Units of VOLUME\_FLOW are shown in Table 4.1

**Table 4.1 VOLUME\_FLOW\_UNIT**

| <b>d</b>      | <b>h</b>      | <b>min</b>      | <b>s</b>      |
|---------------|---------------|-----------------|---------------|
| l/d(1355)     | l/h(1522)     | l/min(1521)     |               |
| m3/d(1350)    | m3/h(1349)    | m3/min(1348)    | m3/s(1347)    |
| kL/d(1520)    | kL/h(1519)    | kL/min(1518)    | kL/s(1523)    |
| L/d(1354)     | L/h(1353)     | L/min(1352)     | L/s(1351)     |
| cm3/d(1514)   | cm3/h(1513)   | cm3/min(1512)   | cm3/s(1511)   |
|               |               |                 | m/s(1061)     |
| t/d(1329)     | t/h(1328)     | t/min(1327)     | t/s(1326)     |
| kg/d(1325)    | kg/h(1324)    | kg/min(1323)    | kg/s(1322)    |
| g/d(1321)     | g/h(1320)     | g/min(1319)     | g/s(1318)     |
| kft3/d(1527)  | kCFH(1526)    | kCFM(1525)      | kCFS(1524)    |
| ft3/d(1359)   | CFH(1358)     | CFM(1357)       | CFS(1356)     |
| mft3/d(1531)  | mCFH(1530)    | mCFM(1529)      | mCFS(1528)    |
| Mgal/d(1366)  | Mgal/h(1459)  | Mgal/min(1455)  | Mgal/s(1451)  |
| kgal/d(1462)  | kgal/h(1458)  | kgal/min(1454)  | kgal/s(1450)  |
| gal/d(1365)   | gal/h(1364)   | GPM(1363)       | gal/s(1362)   |
| mgal/d(1461)  | mgal/h(1457)  | mgal/min(1453)  | mgal/s(1449)  |
| kbbbl/d(1493) | kbbbl/h(1489) | kbbbl/min(1485) | kbbbl/s(1481) |
| bbl/d(1374)   | bbl/h(1373)   | bbl/min(1372)   | bbl/s(1371)   |
| mbbl/d(1492)  | mbbl/h(1488)  | mbbl/min(1484)  | mbbl/s(1480)  |
| ubbl/d(1491)  | ubbl/h(1487)  | ubbl/min(1483)  | ubbl/s(1479)  |
| kbbbl/d(1534) | kbbbl/h(1533) | kbbbl/min(1532) |               |
| bbl/d(1538)   | bbl/h(1537)   | bbl/min(1536)   | bbl/s(1535)   |
| mbbl/d(1542)  | mbbl/h(1541)  | mbbl/min(1540)  | mbbl/s(1539)  |
|               |               | ubbl/min(1544)  | ubbl/s(1543)  |
|               |               |                 | ft/s(1067)    |
| klb/d(1548)   | klb/h(1547)   | klb/min(1546)   | klb/s(1545)   |
| lb/d(1333)    | lb/h(1332)    | lb/min(1331)    | lb/s(1330)    |

**VOLUME\_FLOW\_FTIME:**

Specifies output time constants. Setting range is 0.1 to 200sec. "3sec." is factory set.

**LOW\_FLOW\_CUTOFF:**

Specifies low cut range for output. Setting range is 0 to 10%. "0%" is factory set. The larger absolute value between Array1 and Array2 is used for the scale.

**DISPLAY\_SELECT1,2,3:**

**Table 4.2 DISPLAY\_SELECT1, 2, 3**

| DISPLAY_SELECT 1   | DISPLAY_SELECT 2   | DISPLAY_SELECT 3   |
|--|--|--|
| The display content for the display unit's first line.   | The display content for the display unit's second line.  | The display content for the display unit's third line.   |
| 0:Flow Rate(%)<br>1:Out Value<br>2:Totalized Flow Rate1<br>3:Totalized Flow Rate2<br>4:Totalized Flow Rate3<br><br>The factory default setting is 1. | 0:Off<br>1:Flow Rate(%)<br>2:Out Value<br>3:Flow Rate(Bar)<br>4:Totalized Flow Rate1<br>5:Totalized Flow Rate2<br>6:Totalized Flow Rate3<br>7:Tag No<br>8:Adhesion Check<br>9:Communication<br><br>The factory default setting is 0. | 0:Off<br>1:Flow Rate(%)<br>2:Out Value<br>3:Flow Rate(Bar)<br>4:Totalized Flow Rate1<br>5:Totalized Flow Rate2<br>6:Totalized Flow Rate3<br>7:Tag No<br>8:Adhesion Check<br>9:Communication<br><br>The factory default setting is 0. |

T0402.EPS

**DISPLAY\_CYCLE:**

Specifies the cycle of LCD display. The factory default setting is 400ms, but if a low temperature environment makes it difficult to view the display, it is recommended that you set a longer display cycle.

**VOLUME\_FLOW:**


Indicates the current measured value and status as the primary value (volumetric flow) This parameter is input to the AI Function Block and the Totalizer Function Block.

**Table 4.3 VOLUME\_FLOW**

| Quality (bit 6-7) | Sub-status (bit 2-5)             | Limit (bit 0-1)                         | Alarm            | Value          |
|-------------------|----------------------------------|---|------------------|----------------|
| 2:Good (NC)       | 0:Ok                             | 0:ok                                    | Normal condition | 0xA4           |
|                   | 1:Update Event                   | 0:ok                                    | 80:Adhesion Wng  |                |
|                   | 9:Maintenance required           |   | 81:(Reserved)    |                |
| 1:Uncertain       | 4:Sensor Conversion Not Accurate | 1:low limited or<br>2:high limited      | 85:Flow Vel Over | 0x49<br>0x4A   |
|                   | 7:Configuration Error            | 0:ok                                    | 82:Auto Zero Wng | 0x5C           |
|                   | 0:Bad                            | 0:Non specific<br>1:Configuration Error | 3:constant       | 40:PB O/S Mode |
| 50:Span > 10m/s   |                                  |   |                  |                |
| 51:Span < 0.1m/s  |                                  |   |                  |                |
| 57:Dens Set Err   |                                  |   |                  |                |
| 71:Meas Mod Set   |                                  |   |                  |                |
| 72:Size Set Err   |                                  |   |                  |                |
| 3:Device Failure  |                                  | 3:constant                              | 73:Adh Set Err   | 0x0F           |
|                   |                                  |   | 10:uP Fault      |                |
|                   |                                  |   | 11:EEPROM Fault  |                |
|                   |                                  |   | 12:A/D(H) Fault  |                |
| 4:Sensor Failure  | 3:constant                       | 13:A/D(L) Fault                         | 0x13             |                |
|                   |                                  | 14:A/D(Z) Fault                         |                  |                |
|                   |                                  | 16:EEPROM Dflt                          |                  |                |
|                   |                                  | 100:Comm uP Fault                       |                  |                |
| 7:Out of Service  | 0:ok                             | 101:Comm EEPROM Fault                   | 0x1C             |                |
|                   |                                  | 105:Comm Error1                         |                  |                |
|                   |                                  | 106:Comm Error2                         |                  |                |
|                   |                                  |   | 15:Coil Open     |                |
|                   |                                  |   | 30:Sig Overflow  |                |
|                   |                                  |   | 31:Empty Pipe    |                |
|                   |                                  |   | 33:Adhesion Alm  |                |
|                   |                                  |   | 34:(Reserved)    |                |
|                   |                                  |   | 41:TB O/S Mode   |                |

T0403.EPS

### 4.1.4 Totalizer Block Parameters



F0404.EPS

**Figure 4.4 Overview of Totalizer Block**

Totalizer block parameters can be read or set from the host. The AXF contains three Totalizer blocks. For a list of the parameters of blocks held by the AXF, see Chapter 9.

#### **TARGET\_MODE, MODE\_BLK:**

Indicates the three types of function block modes; Out Of Service (O/S), Manual, and Auto. TARGET\_MODE indicates what mode of operation is desired for Totalizer block. In Out Of Service mode (O/S), the TOT block does not operate. The Manual mode does not allow values to be updated. The Auto mode causes the measured value to be updated. Under normal circumstances, set the Auto mode to take effect. The Auto mode is the factory default.

#### **CHANNEL:**

This is the parameter of the transducer block to be input to the Totalizer block. Totalizer block is assigned to flow rate.

#### **UNIT\_TOT:**

This is the parameter of the unit of the totalized value coming from the transducer block. Totalizer block doesn't have the scaling which is similar to AI Block.

Available units for UNIT\_TOT are the units shown below.

1549:MI, 1034:m3 , 1035:dm3, 1517:kL, 1041:hL,  
1038:L, 1040:mL, 1036:cm3, 1092:t, 1091:Mg,  
1088:kg, 1089:g, 1090:mg, 1043:CF, 1048:gallon,  
1051:bbl, 1094:lb, 1641:bbl (US federal)

**FAIL\_TOT:**

This is the parameter which defines the fail safe mode of the Totalizer block. This parameter determines the operation of the Totalizer block during the occurrence of input values with bas status.

|   | FAIL_TOT value | TOTAL Status                         |
|---|----------------|--------------------------------------|
| 1 | 0: RUN         | UNCERTAIN: Non Specific, ok          |
| 2 | 1: HOLD        | UNCERTAIN: Last Usable Value, const. |
| 3 | 2: MEMORY      | UNCERTAIN: Non Specific, ok          |

Note: Suppose that SET\_TOT = TOTALIZE, MODE\_TOT ≠ HOLD.

T0410.EPS

**MODE\_TOT:**

This is the parameter which defines the direction of the totalization.

- 0: BALANCED; True arithmetic integration of the incoming rate values.
- 1: POS\_ONLY; Totalization of positive incoming rate values only.
- 2: NEG\_ONLY; Totalization of negative incoming rate values only.
- 3: HOLD; Totalization stopped.

**SET\_TOT:**

SET\_TOT is the parameter in order to assign the condition to the Totalizer.

- 0: TOTALIZE; “Normal” operation of the Totalizer.
- 1: RESET; Assign value “0” to Totalizer.
- 2: PRESET; Assign value of PRESET\_TOT to Totalizer.

**PRESET\_TOT:**

This is the parameters in order to define the starting value to the Totalizer.

**TOTAL:**

This parameter contains the integrated quantity of the rate parameter provided by CHANNEL and the associated status.

The alarm information that a priority is the highest is set as status.


In case of two or more alarms belonging to the same sub status are generated, the priority of alarm is so high that the number of an alarm message is small. However, as for O/S Mode alarm of Totalizer block and Physical Block, a priority becomes high most.

Table 4.4 TOTAL

| Quality (bit 6-7)       | Sub-status (bit 2-5)     | Limit (bit 0-1)         | Alarm                              | Value                 |                       |                  |                         |      |
|-------------------------|--------------------------|-------------------------|------------------------------------|-----------------------|-----------------------|------------------|-------------------------|------|
| 2:Good (NC)             | 0:Ok                     | 0:ok                    |                                    |                       |                       |                  |                         |      |
|                         | 1:Update Event           |                         |                                    |                       |                       |                  |                         |      |
|                         | 2:Active Advisory Alarm  | 1:low limited           |                                    | --:Total1 Lo Alm      | 0x89                  |                  |                         |      |
|                         |                          |                         |                                    | --:Total2 Lo Alm      |                       |                  |                         |      |
|                         |                          |                         |                                    | --:Total3 Lo Alm      |                       |                  |                         |      |
|                         |                          | 2:high limited          |                                    | --:Total1 Hi Alm      | 0x8A                  |                  |                         |      |
|                         |                          |                         |                                    | --:Total2 Hi Alm      |                       |                  |                         |      |
|                         |                          |                         |                                    | --:Total3 Hi Alm      |                       |                  |                         |      |
|                         | 3:Active Critical Alarm: | 1:low limited           |                                    | --:Total1 Lo Lo Alm   | 0x8D                  |                  |                         |      |
|                         |                          |                         |                                    | --:Total2 Lo Lo Alm   |                       |                  |                         |      |
|                         |                          |                         |                                    | --:Total3 Lo Lo Alm   |                       |                  |                         |      |
|                         |                          | 2:high limited          |                                    | --:Total1 Hi Hi Alm   | 0x8E                  |                  |                         |      |
|                         |                          |                         |                                    | --:Total2 Hi Hi Alm   |                       |                  |                         |      |
| --:Total3 Hi Hi Alm     |                          |                         |                                    |                       |                       |                  |                         |      |
| 4:Unack. Update Event   |                          |                         |                                    |                       |                       |                  |                         |      |
| 5:Unack. Advisory Alarm |                          |                         |                                    |                       |                       |                  |                         |      |
| 6:Unack. Critical Alarm |                          |                         |                                    |                       |                       |                  |                         |      |
| 9:Maintenance required  |                          | 0:ok                    | 80:Adhesion Wng<br>81:(Reserved)   | 0xA4                  |                       |                  |                         |      |
| 1:Uncertain             | 0:Non specific           | 0:ok                    | 10:uP Fault                        | 0x40                  |                       |                  |                         |      |
|                         |                          |                         | 11:EEPROM Fault                    |                       |                       |                  |                         |      |
|                         |                          |                         | 12:A/D(H) Fault                    |                       |                       |                  |                         |      |
|                         |                          |                         | 13:A/D(L) Fault                    |                       |                       |                  |                         |      |
|                         |                          |                         | 14:A/D(Z) Fault                    |                       |                       |                  |                         |      |
|                         |                          |                         | 16:EEPROM Dflt                     |                       |                       |                  |                         |      |
|                         |                          |                         | 100:Comm uP Fault                  |                       |                       |                  |                         |      |
|                         |                          |                         | 101:Comm EEPROM Fault              |                       |                       |                  |                         |      |
|                         |                          |                         | 105:Comm Error1                    |                       |                       |                  |                         |      |
|                         |                          |                         | 106:Comm Error2                    |                       |                       |                  |                         |      |
|                         |                          |                         | 15:Coil Open                       |                       |                       |                  |                         |      |
|                         |                          |                         | 30:Sig Overflow                    |                       |                       |                  |                         |      |
|                         |                          |                         | 31:Empty Pipe                      |                       |                       |                  |                         |      |
|                         |                          |                         | 33:Adhesion Alm                    |                       |                       |                  |                         |      |
|                         |                          |                         | 34:(Reserved)                      |                       |                       |                  |                         |      |
|                         |                          |                         | 41:TB O/S Mode                     |                       |                       |                  |                         |      |
|                         |                          |                         | 50:Span > 10m/s                    |                       |                       |                  |                         |      |
|                         |                          |                         | 51:Span < 0.1m/s                   |                       |                       |                  |                         |      |
|                         |                          |                         | 57:Dens Set Err                    |                       |                       |                  |                         |      |
|                         |                          |                         | 71:Meas Mod Set                    |                       |                       |                  |                         |      |
|                         |                          |                         | 72:Size Set Err                    |                       |                       |                  |                         |      |
|                         |                          |                         | 73:Adh Set Err                     |                       |                       |                  |                         |      |
|                         |                          |                         | 82:Auto Zero Wng                   |                       |                       |                  |                         |      |
|                         |                          |                         | 1:low limited or<br>2:high limited |                       |                       | 85:Flow Vel Over | 0x41<br>0x42            |      |
|                         |                          |                         | 0:Bad                              |                       | 1:Configuration Error | 0:ok             | 120:Total1 Unit Set Err | 0x04 |
|                         |                          |                         |                                    |                       |                       |                  | 121:Total2 Unit Set Err |      |
|                         |                          | 122:Total3 Unit Set Err |                                    |                       |                       |                  |                         |      |
| 7:Out of Service        | 3:constant               |                         |                                    | 40:PB O/S Mode        | 0x1F                  |                  |                         |      |
|                         |                          |                         |                                    | 43:Total1 FB O/S Mode |                       |                  |                         |      |
|                         |                          |                         |                                    | 44:Total2 FB O/S Mode |                       |                  |                         |      |
|                         |                          |                         | 45:Total3 FB O/S Mode              |                       |                       |                  |                         |      |

T0404.EPS

### 4.1.5 DI Block Parameters



F0405.EPS

**Figure 4.5 Overview of DI Block**

DI block parameters can be read or set from the host. The AXF contains two DI blocks, which individually transfer the “High Limit”, “Low Limit”, “Adhesion Alarm” and “Adhesion warning” generated by the transducer block. For a list of the parameters of blocks held by the AXF, refer to Chapter 9.

**TARGET\_MODE:**

Indicates the three types of function block modes; Out\_Of\_Service (O/S), Manual, and Auto.

TARGET\_MODE indicates what mode of operation is desired for the block. In Out\_Of\_Service mode (O/S),

the DI block does not operate. The Manual mode does not allow values to be updated. The Auto mode causes the measured value to be updated. Under normal circumstances, set the Auto mode to take effect. The Auto mode is the factory default.

**MODE\_BLK:**

The mode parameter is a structured parameter composed of the actual mode, the normal mode and the permitted mode.

**Table 4.5 Data structure of MODE\_BLK**

|   | Member    | Description   |
|---|-----------|---|
| 1 | Actual    | The actual mode is set (calculated) by the block during its execution to reflect the mode used during execution.                        |
| 2 | Permitted | The permitted mode shows which changes of the target mode is valid for the specific block to the remote user of the MODE_BLK parameter. |
| 3 | Normal    | The normal mode is the desired operating mode of the block.   |

T0406.EPS

**Table 4.6 Initial value of MODE\_BLK**

|   | Member    | Initial value  | Remark  |
|---|-----------|----------------|---|
| 1 | Actual    | Auto           | When the Actual of Physical Block is O/S, the Actual of DI changes in O/S mode. |
| 2 | Permitted | O/S, Man, Auto |   |
| 3 | Normal    | Auto           |   |

T0407.EPS



**CHANNEL:**

This is the parameter to specify the value of the transducer block to be input to the DI block. Each DI block is assigned to either “High Limit”, “Low Limit”, “Adhesion Alarm” or “Adhesion Warning”.

This parameter enables to select among “LIMSW\_1\_VALUE\_D”, “LIMSW\_2\_VALUE\_D”, “SWITCH\_1\_VALUE\_D” and “SWITCH\_2\_VALUE\_D”.

Also it enables to set “High/Low Limit” or “Adhesion Alarm/Warning” in each DI block.

**FSAFE\_TYPE:**

This is the parameter which defines the operation of the function block if a fault is detected.

**Table 4.7 FSAFE\_TYPE**

|   | <b>Value</b>            | <b>Status</b>              | <b>Remark</b>   |
|---|-------------------------|----------------------------|---|
| 1 | 0: FSAFE_VAL            | UNCERTAIN_Substitute Value | FSAFE_VAL is used as OUT_D.   |
| 2 | 1: last valid OUT Value | UNCERTAIN_LastUsable Value | If there is no valid value available, then UNCERTAIN- Inital_Value. |
| 3 | 2: wrong calculated Val | Bad:* (* as calculated)    | The status is shown in Table 4.8                                    |

T0408.EPS

**FSAFE\_VAL\_D:**

This is the parameter which sets the default value for the OUT\_D parameter, if sensor or sensor electric fault is detected.

**INVERT:**

This is the parameter which indicates whether the input value from the transducer block should be logically inverted before it is stored in the OUT\_D.

0: Not inverted

1:invert

**OUT\_D:**

OUT\_D is the output of the function block. The value is specified by the operator in MODE MAN.

The relationship between OUT\_D.Status and the result of the DIAGNOSIS are described as below.

The alarm information that a priority is the highest is set as status.

In case of two or more alarms belonging to the same sub status are generated, the priority of alarm is so high that the number of an alarm message is small. However, as for O/S Mode alarm of DI function block and Physical Block, a priority becomes high most.

**Table 4.8 OUT\_D**

| Quality (bit 6-7) | Sub-status (bit 2-5)     | Limit (bit 0-1)                    | Alarm   | Value                |
|-------------------|--------------------------|------------------------------------|---|----------------------|
| 2:Good (NC)       | 0:Ok                     | 0:ok                               |   |                      |
|                   | 1:Update Event           | 1:low limited                      |   |                      |
|                   | 2:Active Advisory Alarm  | 2:high limited                     |   |                      |
|                   | 3:Active Critical Alarm: | 3:constant                         |   |                      |
|                   | 4:Unack. Update Event    |                                    |   |                      |
|                   | 5:Unack. Advisory Alarm  |                                    |   |                      |
|                   | 6:Unack. Critical Alarm  |                                    |   |                      |
| 1:Uncertain       | 0:Non specific           | 0:ok                               | 80:Adhesion Wng                                       | 0xA4                 |
|                   |                          | 1:low limited or<br>2:high limited | 81:(Reserved)<br>82:Auto Zero Wng<br>85:Flow Vel Over | 0x40<br>0x41<br>0x42 |
| 0:Bad             | 0:Non specific           | 3:constant                         | 50:Span > 10m/s                                       | 0x03                 |
|                   |                          |                                    | 51:Span < 0.1m/s                                      |                      |
|                   |                          |                                    | 57:Dens Set Err                                       |                      |
|                   |                          |                                    | 71:Meas Mod Set                                       |                      |
|                   |                          |                                    | 72:Size Set Err                                       |                      |
|                   |                          |                                    | 73:Adh Set Err  |                      |
|                   | 3:Device Failure         | 3:constant                         | 10:uP Fault   | 0x0F                 |
|                   |                          |                                    | 11:EEPROM Fault                                       |                      |
|                   |                          |                                    | 12:A/D(H) Fault                                       |                      |
|                   |                          |                                    | 13:A/D(L) Fault                                       |                      |
|                   |                          |                                    | 14:A/D(Z) Fault                                       |                      |
|                   | 0:ok                     | 0:ok                               | 16:EEPROM Dflt  | 0x0C                 |
|                   |                          |                                    | 100:Comm uP Fault                                     |                      |
|                   |                          |                                    | 101:Comm EEPROM Fault                                 |                      |
|                   |                          |                                    | 105:Comm Error1<br>106:Comm Error2                    |                      |
| 4:Sensor Failure  | 3:constant               | 15:Coil Open                       | 0x13  |                      |
|                   |                          | 30:Sig Overflow                    |   |                      |
|                   |                          | 31:Empty Pipe                      |   |                      |
|                   |                          | 33:Adhesion Alm<br>34:(Reserved)   |   |                      |
| 7:Out of Service  | 0:ok                     | 41:TB O/S Mode                     | 0x1C  |                      |
|                   |                          | 3:constant                         | 40:PB O/S Mode  | 0x1F                 |
|                   |                          |                                    | 46:DI1FB O/S Mode<br>47:DI2FB O/S Mode                |                      |

T0409.EPS

# 5. EXPLANATION OF BASIC ITEMS

## 5.1 Outline

This section describes basic parameter setting by use of FieldMate R1.03 including easy setup and AXF display of integral indicator.

The following sections describe how to adapt the function and performance of the AXF to suit specific applications because two or more devices are connected to PROFIBUS PA, setting including the requirements of all devices need to be determined. Practically, the following steps must be taken.

Refer to Chapter 4 when the AXF is set parameters by use of other engineering tools in each function block.

## 5.2 Basic Parameter Setting and Changing

This section describes basic parameter setting and changing with FieldMate R1.03. For detailed information on FieldMate, refer to its User's manual.

### 5.2.1 Explanation of Menu.

The DTM Works window is shown below.




Figure 5.2.1 DTM Works

### Identification area

This area contains information about the device that is handled by the DTM. At online parameter, all parameters in this area must be handled as dynamic variables.

### Parameter set application

This area displays the device parameters. Parameter setting and changing are performed in this area.

If the mouse of PC moves to each parameter name, its explanation is appeared.

### Navigation tree

The navigation tree provides an overview of the parameter settings. User can easily navigate the folders and submenus using the tree view. The tree view is similar to that of windows explorer. A submenu is viewed by clicking a folder with the plus sign [+].

Clicking the minus sign [-] will close the submenu.

User can select an element by pushing the up or down arrow key. The navigation tree for online parameters is described in the following table.



### IMPORTANT

- Before running the program, log-in to Windows as an Administrator or as a user with administrative authority.
- When comm. DTM is connected to the PROFIBUS network with class 1 master running, set the same busparameters of class 1 master.

Table 5.2.1 Navigation tree structure of online parameters

| Level of node     |                       |                         |
|-------------------|-----------------------|-------------------------|
| 1st level         | 2nd level             | 3rd level               |
| Process Variable  |                       |                         |
| Device Status     |                       |                         |
| Diag and Service  |                       |                         |
| Easy Setup        |                       |                         |
| Calibration       |                       |                         |
| Physical Block    | Identification        |                         |
|                   | Diagnosis             |                         |
|                   | Simulate Diagnosis    |                         |
|                   | Function Block Status |                         |
|                   | Configuration         |                         |
| Input             | Transducer Block      | Flow Tube               |
|                   |                       | DI Set                  |
|                   |                       | AUX                     |
|                   |                       | Mask Alarm              |
|                   |                       | Simulate Measured Value |
|                   |                       | Adhesion                |
|                   |                       | Alarm Record            |
|                   |                       | Local Display           |
|                   |                       | Output                  |
| PV Scale          |                       |                         |
| Output scale      |                       |                         |
| Warning and Alarm |                       |                         |
| Totalizer 1       | Batch Information     |                         |
|                   | Totalizer Reset       |                         |
|                   | Warning and Alarm     |                         |
| Totalizer 2       | Batch Information     |                         |
|                   | Totalizer Reset       |                         |
|                   | Warning and Alarm     |                         |
| Totalizer 3       | Batch Information     |                         |
|                   | Totalizer Reset       |                         |
|                   | Warning and Alarm     |                         |
| Discrete Input 1  | Batch Information     |                         |
| Discrete Input 2  | Batch Information     |                         |

T0501.eps

**Device**

This menu shows the current accessible functions of the DTM for AXF ([Device] menu).

Table 5.2.2 DTM context menu for AXF

| DTM Function                       |                                  |  |
|------------------------------------|----------------------------------|--|
| 1st level                          | 2nd level                        | Description  |
| Connect/Disconnect                 |                                  | Connect/Disconnect   |
| Parameter                          | Online Parameter                 | Online Parameterization  |
|                                    | Offline Parameter                | Offline Parameterization   |
|                                    | Configuration                    | The Query Device is located under Configuration. The Query Device provides a list of all parameters in a designated block. |
| Additional Functions               | Observe                          | Indicates actual process conditions. All parameters must be handled as dynamic variables and updated periodically.         |
|                                    | Diagnosis                        | Provides device diagnosis information.   |
|                                    | Process Trend                    | Trend display of process value   |
|                                    | About                            | Displays DTM version of the device   |
|                                    | Refresh Online Data              | Refresh (reload) the online data   |
|                                    | Register Device Maintenance Info |  |
| Unregister Device Maintenance Info |                                  | Unregisters the device maintenance information   |
| Upload from Device                 |                                  | All parameters are uploaded from device to DTM.  |
| Download to Device                 |                                  | All parameters are downloaded from DTM to device.  |
| Print                              |                                  | Print specified parameter sets.  |
| Document                           |                                  | Displays the related document for DTM (*1)   |
| Property                           |                                  | Displays DTM version of the device   |

T0502.eps

\*1: The AXF does not have this function.

**Example of DTM context screen**

There are 8 kinds of menus as [Process Variable], [Device Status], [Diag and Service], [Easy Setup], [Calibration], [Physical Block], [Input] and [Output].

Their examples are shown in Figure 5.2.2 to 5.2.6.

(a) Process Variables




Figure 5.2.2 Process Variables

(d) Easy Setup




Figure 5.2.5 Easy Setup

(b) Device Status




Figure 5.2.3 Device Status

(e) Calibration




Figure 5.2.6 Calibration

Note: This function is only available if an online connection to the device is established.

(c) Diag and Service




Figure 5.2.4 Diag and Service

### 5.3 Bus Address Setup

This section describes how to set the bus address by FieldMate R1.03. The AXF also has a hardware slide switch. If the bus address is set by FieldMate R1.03, the No. 8 switch of the hardware slide switch must be set OFF beforehand. Refer to section 3.4 for its detail.

#### (1) Bus Address change for AXF

In the DTM Works window, click [Device] → [Parameter] → [Configuration].




Figure 5.3.1 DTM Works window

The DTM Works shows the following window.




Figure 5.3.2 Query Device window

Click [Query Device PB] at the Navigator tree.

The DTM Works shows parameters for [Query Device PB] in the Parameter set application.

Firstly, the [Target Mode] on this application must be changed from [AUTO] to [Out of Service (O/S)], and press the [Enter] key after this change. The DTM

Works starts to communicate with the AXF, and [Mode Block: Actual] parameter is changed to [Out of Service] after finish this communication.

In the meantime, the AXF starts to generate its alarm message and is displayed to its LCD at the same time.




Figure 5.3.3 Target Mode change

The bus address setting function is located down below in the [Query Device PB] menu.

Entry the adequate bus address at [Set Address] and press [Enter] key. The following figure is a case of changing from 7 to 10.






Figure 5.3.4 Bus Address change for AXF

**(2) Bus Address change for DTM**

A message as “The communication DTM sent abort” in the DTM Works is appeared as shown in figure 5.3.5. Click [OK] for this message window. A new DTM Works window is established as shown in figure 5.3.6, however, close this DTM Works window.




**Figure 5.3.5 Message from DTM Works**




**Figure 5.3.6 New DTM Works window**

Go back to the FieldMate window as shown in Figure 5.3.7 and confirm that the address is still no change. Next, click the icon for “Update”. The FieldMate starts to communicate with the AXF and the new address is set after several seconds (Figure 5.3.8).

Click this icon as “Update”.




**Figure 5.3.7 FieldMate window**



**Figure 5.3.8 New Bus Address was set**

Change the parameter from [Out of Service (O/S)] to [AUTO] again at [Target Mode] in the [Query Device PB] menu and confirm that the parameter is changed to [AUTO] at [Mode Block: Actual] at the same time by referring to the Figure 5.3.1 to 5.3.3 when the bus address change work was finished.



**Figure 5.3.9 Mode Block: Actual confirmation**

The procedure of the Bus Address setup was finished.

## 5.4 Easy Setup

Easy Setup tracks parameters that often need to be configured or changed.

Click [Easy Setup] at the Navigation tree. It shows the Easy setup window at the Parameter Set Application as shown in Figure 5.2.5. The following figure is [Easy Setup] window in the toggle the tree window mode, and its contents is described Table 5.4.1.



Figure 5.4.1 Easy Setup

Table 5.4.1 Easy Setup Items

| Block name       | Item                     | Type of Entry |
|------------------|--------------------------|---------------|
|                  | TAG                      | ASCII code    |
|                  | Descriptor               | ASCII code    |
|                  | Message                  | ASCII code    |
| Transducer Block | Target Mode              | Alternative   |
|                  | Actual Mode              | Monitor only  |
|                  | Measured Value Unit      | Alternative   |
|                  | Filter Time              | Numeric       |
| Analog Input     | Target Mode              | Alternative   |
|                  | Actual Mode              | Monitor only  |
|                  | Filter Time Const        | Numeric       |
|                  | PV Scale: Lower Value    | Numeric       |
|                  | PV Scale: Upper Value    | Numeric       |
|                  | Out Scale: Upper Value   | Numeric       |
|                  | Out Scale: Lower Value   | Numeric       |
|                  | Out Scale: Unit          | Alternative   |
|                  | Out Scale: Decimal Point | Numeric       |
| Velocity Check   | Monitor only             |               |
| Local Display    | Select 1                 | Alternative   |
|                  | Select 2                 | Alternative   |
|                  | Select 3                 | Alternative   |

T0503.eps

The [Target Mode] in each function block must be set from [AUTO] to [O/S] before changing parameters.

When the parameter in each item has been changed, the DTM Works confirms its update, hence, press the [Enter] key to fix. If the [ESC] key is pressed before fixing, the data comes back to the set data without changing.




Figure 5.4.2 Parameter change

The [Target Mode] must be returned [AUTO] when the parameter setting work was finished.



### IMPORTANT

Do not turn power OFF immediately after parameter setting. When parameters are saved to the EEPROM, the redundant processing is executed for an improvement of reliability. Should the power be turned OFF within 60 seconds after setting of parameters, changed parameters are not saved and may return to their original values.



## 5.5 Function Blocks Setting

This section describes the procedure taken to set and change the parameters for each block. Obtaining access to each parameter differs depending on the configuration system used. For detail, refer to Chapter 4 for each configuration system.

Block mode consists of the following four modes that are controlled by the universal parameter that displays the running condition of each block.

- TARGET\_MODE: Sets the operating condition of the block.
- Actual: Indicates the current operating condition.
- Permit: Indicates the operating condition that the block is allowed to take.
- Normal: Indicates the operating condition that the block will usually take.

Table 5.5.1 shows the operating conditions which the individual blocks will take.

Table 5.5.1 Operating condition in each function block

|                      | AI block | TOT block | DI block | Transducer block | Physical block |
|----------------------|----------|-----------|----------|------------------|----------------|
| Automatic (Auto)     | Yes      | Yes       | Yes      | Yes              | Yes            |
| Manual (Man)         | Yes      | Yes       | Yes      |                  |                |
| Out of Service (O/S) | Yes      | Yes       | Yes      | Yes              | Yes            |

T0504.eps

The [Target Mode] in each function block must be set from [AUTO] to [O/S] before changing parameters, and then, return [AUTO] this mode after finish the parameter setting work.

### 5.5.1 Physical Block Parameters Setup

There are 5 kinds of submenus as [Identification], [Diagnosis], [Simulate Diagnosis], [Function Block Status] and [Configuration].

Refer to section 6.3.4 for [Simulate Diagnosis] function.




Figure 5.5.1 Physical Block menu

#### (1) Configuration setting

There are 2 items to set parameters as [Write Locking] and [Factory Reset] at [Configuration] in the [Physical Block] menu. The write locking function enables to use not only parameter setting but also setting by hardware switch at the same time. Refer to section 3.5 detail.




Figure 5.5.2 Configuration Setup

### 5.5.2 AI Block Parameters Setup

The AI block outputs the flow rate signals.

There are 4 kinds of submenus as [Batch Information], [PV Scale], [Output Scale] and [Warning and Alarm] in the [Analog Input] menu.

Click [Output] → [Analog Input] at the Navigation Tree.

Refer to section 6.3.4 for [Simulation] function.




Figure 5.5.3 Analog Input menu

#### (1) Calibration range setting

Entry the upper and lower values in the [PV Scale] submenu.




Figure 5.5.4 PV Scale Setup

#### (2) Output Scale setting

Entry the flow unit, upper and lower values with their decimal points in the [Output scale] submenu.




Figure 5.5.5 Output Scale Setup

#### (3) Fail Safe Mode setting

Entry the fail safe mode, fail scale default value and output value in the [Analog Input] menu.




Figure 5.5.6 Fail Safe Mode Setup

### 5.5.3 Transducer Block Parameters Setup

There are 8 kinds of submenus as [Flow Tube], [DI Set], [AUX], [Mask Alarm], [Simulate Measured Value], [Adhesion], [Alarm Record] and [Local Display] in the [Transducer Block] menu.

Click [Input] → [Transducer Block] at the Navigation tree.

Refer to section 6.3.4 for [Simulate Measured Value] function.




Figure 5.5.7 Transducer Block menu

#### (1) Damping time constant setting

Enter the adequate numeric at [Filter Time] in the [Transducer Block] menu.

This data is also available to set at [Filter Time] in the [Easy Setup] menu.




Figure 5.5.8 Damping time constant Setup

#### (2) Output Signal Low Cut setting

Entry the adequate numeric at [Low Flow Cut Off] in the [Transducer Block] menu.




Figure 5.5.9 Output Signal Low Cut Setup

#### (3) LCD Display setting

Select the adequate type of indication for the LCD Display with its Display Cycle.

This data is also available to set at [Local Display] in the [Easy Setup] menu.

Please note the AXF PROFIBUS PA type is only available to indicate English.




Figure 5.5.10 Local Display Setup

### 5.5.4 Totalizer Block Parameters Setup

There are 3 kinds of submenus as [Batch Information], [Totalizer Reset] and [Warning and Alarm]. The AXF has 3 totalizers and their setting contents are same. The following figure is the [Totalizer 1] menu.

Click [Output] → [Totalizer 1], [Totalizer 2] or [Totalizer 3] at the Navigation tree.

Refer to section 6.3.4 for [Simulation] function.




Figure 5.5.11 Totalizer 1 Parameter menu

#### (1) Unit of Totalization setting

Select the adequate unit at [Totalizer unit] in each [Totalizer] menu.




Figure 5.5.12 Totalizer Unit Setup

#### (2) Direction of Totalization setting

Select the adequate direction at [Totalizer Mode] in each [Totalizer] menu.




Figure 5.5.13 Totalizer Mode Setup

#### (3) Fail Sale Mode setting

Select the adequate mode at [Fail Safe Mode] in each [Totalizer] menu.




Figure 5.5.14 Fail Safe Mode Setup

#### (4) Resetting or Presetting Total Value

Select type and enter the adequate numeric in each [Totalizer Reset] submenu.




Figure 5.5.15 Totalizer Reset Setup

#### (1) Limit Switch setting

Select type and entry data for Limit Switch 1 and 2 adequately at [DI Set] in the [Transducer Block] menu.




Figure 5.5.17 Limit Switch Setup

### 5.5.5 DI Block Parameters Setup

There is one submenu as [Batch Information]. The AXF has 2 Discrete Inputs and their setting contents are same. The following figure is the [Discrete Input 1] menu.

Click [Output] → [Discrete Input 1] or [Discrete Input 2] at the Navigation tree.

Refer to section 6.3.4 for [Simulation] function.




Figure 5.5.16 Discrete Input 1 menu

#### (2) Channel setting

Select the adequate type at [Channel] in each [Discrete Input] menu.




Figure 5.5.18 Selection of Channel Setup

**(3) Invert setting**

Select a use of invert at [Invert Input Value] in each [Discrete Input] menu.




Figure 5.5.19 Invert Input Value Setup

**(4) Fail Safe Mode setting**

Select the adequate mode and enter the value at [Fail Safe Mode] along with [Fail Safe Default Value] in each [Discrete Input] menu.




Figure 5.5.20 Fail Safe Mode Setup

**5.6 Integral LCD Indicator**

Employing 32\*132 full dot matrix backlit LCD, various display can be obtained.

**5.6.1 Flow Data Display**

By the transducer block parameters setting in DISPLAY\_SELECT1, 2, 3 as described in section 4.1.3, up to three lines display can be made among the following data.

- Flow Rate(%)
- Out Value
- Flow Rate(Bar)
- Totalized Flow Rate1
- Totalized Flow Rate2
- Totalized Flow Rate3
- Tag No.
- Adhesion Check
- Communication


The number of the data can be configured by setting DISPLAY\_SELECT1, 2, 3 as follows;

|                 | 1 line display | 2 line display   | 3 line display   |
|-----------------|----------------|------------------|------------------|
| Display Select1 | -              | -                | -                |
| Display Select2 | Off            | Other than "Off" | Other than "Off" |
| Display Select3 | -              | Off              | Other than "Off" |


T0506.eps

Followings are the display examples depending on choosing 1 to 3 value modes.


**1 value mode**



**2 value mode**



**3 value mode**




F0523.eps

The data titles are displayed together with the flow data and units.

- FR** : Out Value Flow Rate
- FTL** : Positive Total ( Forward Total )
- RTL** : Negative Total ( Reverse Total )
- DTL** : Balanced Total ( Differential Total )
- HTL** : Hold Total
- TAG** : Tag Number
- ADH** : Adhesion Check
- COM** : Communication

F0504.eps

**Flow Rate (%)**




F0505.eps

Decimal point is always to the first place.

**Out Value**

Flow rate is displayed together with the units set in OUT\_SCALE, the maximum number of figures is six.



F0506.eps

In the case of Characterization Type is "Direct " decimal point location of the data becomes as follows.

| OUT_SCALE. Decimal Point | Place of decimal | Example        |
|--------------------------|------------------|----------------|
| 0                        | 0                | 123            |
| 1                        | 1                | 123.4          |
| 2                        | 2                | 123.45         |
| 3                        | 3                | 123.456        |
| Other                    | Auto             | Refer to below |


T0507.eps

When OUT\_SCALE. Decimal Point is set as Other, decimal point location of the data becomes as follows.

| OUT.Value                | Place of decimal | Example |
|--------------------------|------------------|---------|
| -999999<OUT.Value≤-10000 | 0                | -222222 |
| -10000<OUT.Value≤-1000   | 1                | -4444.1 |
| -1000<OUT.Value≤-100     | 2                | -555.12 |
| -100<OUT.Value<100       | 3                | -66.123 |
| 100≤OUT.Value<1000       | 2                | 555.12  |
| 1000≤OUT.Value<10000     | 1                | 4444.1  |
| 10000≤OUT.Value≤999999   | 0                | 222222  |

T0508.eps

When the flow data exceeds the maximum number of figures six, then "84:Disp Over Wng" message is displayed.



F0507.eps

**Unit of Out Value on LCD**

Applicable Unit of Out Value is shown by the following tables corresponding to the OUT\_SCLAE Unit Codes.

**Table 5.6.1 Display Unit Codes 1**

| Units Codes | Unit on Display |
|-------------|-----------------|
| 1342:%      | %               |

**Table 5.6.2 Display Unit Codes 2**

| Units Codes             | Unit on Display [/d] | Units Codes             | Unit on Display [/h] |
|-------------------------|----------------------|-------------------------|----------------------|
| 1355:MI/d               | MI/d                 | 1522:MI/h               | MI/h                 |
| 1350:m3/d               | m <sup>3</sup> /d    | 1349:m3/h               | m <sup>3</sup> /h    |
| 1520:kL/d               | kl/d                 | 1519:kL/h               | kl/h                 |
| 1354:L/d                | l/d                  | 1353:L/h                | l/h                  |
| 1514:cm3/d              | cm <sup>3</sup> /d   | 1513:cm3/h              | cm <sup>3</sup> /h   |
| 1329:t/d                | t/d                  | 1328:t/h                | t/h                  |
| 1325:kg/d               | kg/d                 | 1324:kg/h               | kg/h                 |
| 1321:g/d                | g/d                  | 1320:g/h                | g/h                  |
| 1527:kft3/d             | kcf/d                | 1526:kCFH               | kcf/h                |
| 1359:ft3/d              | cf/d                 | 1358:CFH                | cf/h                 |
| 1531:mft3/d             | mcf/d                | 1530:mCFH               | mcf/h                |
| 1366:Mgal(US)/d         | Mgal/d               | 1459:Mgal(US)/h         | Mgal/h               |
| 1462:kgal(US)/d         | kgal/d               | 1458:kgal(US)/h         | kgal/h               |
| 1365:gal(US)/d          | gal/d                | 1364:gal(US)/h          | gal/h                |
| 1461:mgal(US)/d         | mgal/d               | 1457:mgal(US)/h         | mgal/h               |
| 1493:kbbI(US Oil)/d     | kbbI/d               | 1489:kbbI(US Oil)/h     | kbbI/h               |
| 1374:bbI(US Oil)/d      | bbI/d                | 1373:bbI(US Oil)/h      | bbI/h                |
| 1492:mbbI(US Oil)/d     | mbbI/d               | 1488:mbbI(US Oil)/h     | mbbI/h               |
| 1491:ubbbI(US Oil)/d    | μbbI/d               | 1487:ubbbI(US Oil)/h    | μbbI/h               |
| 1534:kbbI(US Federal)/d | kbbI/d               | 1533:kbbI(US Federal)/h | kbbI/h               |
| 1645:bbI(US Federal)/d  | bbI/d                | 1644:bbI(US Federal)/h  | bbI/h                |
| 1542:mbbI(US Federal)/d | mbbI/d               | 1541:mbbI(US Federal)/h | mbbI/h               |
| 1548:klb(US)/d          | klb/d                | 1547:klb(US)/h          | klb/h                |
| 1333:lb(US)/d           | lb/d                 | 1332:lb(US)/h           | lb/h                 |
| 1337:STON/d             | STon/d               | 1336:STON/h             | STon/h               |
| 1341:LTON/d             | LTon/d               | 1340:LTON/h             | LTon/h               |
| 1478:MImpGal/d          | Mgal/d               | 1474:MImpGal/h          | Mgal/h               |
| 1477:klmpGal/d          | kgal/d               | 1473:klmpGal/h          | kgal/h               |
| 1370:ImpGal/d           | gal/d                | 1369:ImpGal/h           | gal/h                |
| 1476:mImpGal/d          | mgal/d               | 1472:mImpGal/h          | mgal/h               |




Table 5.6.3 Display Unit Codes 3

| Units Codes                | Unit on Display [/min] | Units o s               | Unit on Display [/s] |
|----------------------------|------------------------|-------------------------|----------------------|
| 1521:MI/min                | MI/min                 |                         |                      |
| 1348:m3/min                | m <sup>3</sup> /min    | 1347:m3/s               | m <sup>3</sup> /s    |
| 1518:kL/min                | kl/min                 | 1523:kL/s               | kl/s                 |
| 1352:L/min                 | l/min                  | 1351:L/s                | l/s                  |
| 1512:cm3/min               | cm <sup>3</sup> /min   | 1511:cm3/s              | cm <sup>3</sup> /s   |
|                            |                        | 1061:m/s                | m/s                  |
| 1327:t/min                 | t/min                  | 1326:t/s                | t/s                  |
| 1323:kg/min                | kg/min                 | 1322:kg/s               | kg/s                 |
| 1319:g/min                 | g/min                  | 1318:g/s                | g/s                  |
| 1525:kCFM                  | kcf/min                | 1524:kCFS               | kcf/s                |
| 1357:CFM                   | cf/min                 | 1356:CFS                | cf/s                 |
| 1529:mCFM                  | mcf/min                | 1528:mCFS               | mcf/s                |
| 1455:Mgal(US)/min          | Mgal/min               | 1451:Mgal(US)/s         | Mgal/s               |
| 1454:kgal(US)/min          | kgal/min               | 1450:kgal(US)/s         | kgal/s               |
| 1363:GPM                   | gal/min                | 1362:gal(US)/s          | gal/s                |
| 1453:mgal(US)/min          | mgal/min               | 1449:mgal(US)/s         | mgal/s               |
| 1485:kbbbl(US Oil)/min     | kbbbl/min              | 1481:kbbbl(US Oil)/s    | kbbbl/s              |
| 1372:bbbl(US Oil)/min      | bbbl/min               | 1371:bbbl(US Oil)/s     | bbbl/s               |
| 1484:mbbl(US Oil)/min      | mbbl/min               | 1480:mbbl(US Oil)/s     | mbbl/s               |
| 1483:ubbl(US Oil)/min      | μbbbl/min              | 1479:ubbl(US Oil)/s     | μbbbl/s              |
| 1532:kbbbl(US Federal)/min | kbbbl/min              |                         |                      |
| 1643:bbbl(US Federal)/min  | bbbl/min               | 1642:bbbl(US Federal)/s | bbbl/s               |
| 1540:mbbl(US Federal)/min  | mbbl/min               | 1539:mbbl(US Federal)/s | mbbl/s               |
| 1544:ubbl(US Federal)/min  | μbbbl/min              | 1543:ubbl(US Federal)/s | μbbbl/s              |
|                            |                        | 1067:ft/s               | ft/s                 |
| 1546:klb(US)/min           | klb/min                | 1545:klb(US)/s          | klb/s                |
| 1331:lb(US)/min            | lb/min                 | 1330:lb(US)/s           | lb/s                 |
| 1335:STON/min              | STon/min               | 1334:STON/s             | STon/s               |
| 1339:LTON/min              | LTON/min               | 1338:LTON/s             | LTON/s               |
| 1470:MImpGal/min           | Mgal/min               | 1466:MImpGal/s          | Mgal/s               |
| 1469:kImpGal/min           | kgal/min               | 1465:kImpGal/s          | kgal/s               |
| 1368:ImpGal/min            | gal/min                | 1367:ImpGal/s           | gal/s                |
| 1468:mImpGal/min           | mgal/min               | 1464:mImpGal/s          | mgal/s               |


**Flow Rate (Bar)**

Bi Direction is set "Unidirectional"



F0508.eps



Bi Direction is set "Bidirectional"



F0509.eps

**Totalized Flow Rate1, 2, 3**

The maximum number of figures is eight in addition to sign (±) for Totalized Flow Rate display.



F0510.eps

**Totalized Flow Rate Unit Display**


Table 5.6.4 Totalized Flow Rate Unit

| Units Codes | Display | Units Codes          | Display |
|-------------|---------|----------------------|---------|
| 1549:MI     | MI      | 1091:Mg              | Mgl     |
| 1034:m³     | m³      | 1088:kg              | kg      |
| 1035:dm³    | dm³     | 1089:g               | g       |
| 1517:kL     | kl      | 1090:mg              | mg      |
| 1041:hL     | hl      | 1043:CF              | cf      |
| 1038:L      | l       | 1048:gallon          | gal     |
| 1040:mL     | ml      | 1051:bbl             | bbl     |
| 1036:cm³    | cm³     | 1094:lb              | lb      |
| 1092:t      | t       | 1641:bbl(US Federal) | bbl     |

T0511.eps

**Tag No.**

The third line shows the example of Tag No. display. Maximum number of figures is 16, on LCD the head 16 characters out of 32 characters of management Tag No. can be displayed.



F0511.eps

**Adhesion Check**

When Adhesion Check display is selected result is displayed as below showing the level number.


**Adhesion Check Level Judge**

Level4 : Adh Measure Value > Adhesion Level4




F0513.eps

Level3 : Adhesion Level4 ≥ Adh Measure Value > Adhesion Level3




F0514.eps

Level2 : Adhesion Level3 ≥ Adh Measure Value > Adhesion Level2




F0515.eps

Level1 : Adhesion Level2 ≥ Adh Measure Value > Adhesion Level1



F0516.eps


Level0 : Adhesion Level1 ≥ Adh Measure Value



F0517.eps

**Communication**

The third line shows the example of Communication display.



F0518.eps

### 5.6.2 Display Modes

ADMAG AXF has following display modes.

- Normal Display
- Alarm Display
- Warning Display
- Autozero Display

#### Display Renewal Time

Display renewal time for each display modes depends on Display Cycle setting;

| Display Mode    | Display Cycle set Time |    |    |
|-----------------|------------------------|----|----|
|                 | 2s,1s,400ms,200ms      | 4s | 8s |
| Normal Display  | 2s                     | 4s | 8s |
| Alarm Display   | 4s                     | 4s | 8s |
| Warning Display | 4s                     | 4s | 8s |


T0512.eps

#### Normal Display


In this display mode various flow data from one to three lines are displayed as described in 5.6.1.

### Alarm Display


When alarm is generated, alarm message is displayed alternatively at the first line. Followings are an example of alarm display situation.



Normal mode screen



Alarm information screen



Normal mode screen

F0519.eps

### Alarm Message / Countermeasure Message

On the Integral LCD indicator, following messages are displayed when alarm is generated.


Table 5.6.5 Alarm Message Display

| Category                | Display Message                         | Countermeasure Message   | Alarm Description   |
|-------------------------|---|--|---|
| System Alarms           | 10:uP Fault                             | Contact nearest office or service center                               | Microprocessor error  |
|                         | 11:EEPROM Fault                         |  | EEPROM error  |
|                         | 12:A/D(H) Fault                         |  | A/D converter error   |
|                         | 13:A/D(L) Fault                         |  |   |
|                         | 14:A/D(Z) Fault                         | Cut the power and check coil & EX cables                               | Flowtube coil open-circuit  |
|                         | 15:Coil Open                            |  | EEPROM default values   |
|                         | 16:EEPROM Dflt                          | Contact nearest office or service center                               | FB Microprocessor error   |
|                         | 100:Comm uP Fault                       |  | FB EEPROM error   |
|                         | 101:Comm EEPROM Fault                   |  | Total1 had not been stored when the device was turned off.  |
|                         | 102:Total1 Not Saved                    |  | Total2 had not been stored when the device was turned off.  |
|                         | 103:Total2 Not Saved                    |  | Total3 had not been stored when the device was turned off.  |
|                         | 104:Total3 Not Saved                    |  |   |
|                         | 105:Comm Error1                         | Contact nearest office or service center                               | Communication error   |
| 106:Comm Error2         | Communication error                     |  |   |
| Process Alarms          | 30 Sig Overflow                         | Check signal cable and grounding                                       | Input signal error  |
|                         | 31:Empty Pipe                           | Fill flow tube with fluid  | Flowtube is not filled with fluid   |
|                         | 33:Adhesion Alm                         | Clean electrodes   | Electrode adhesion alarm  |
|                         | 110:AI Lo Lo Alm                        | Check the flow rate and setting value.                                 | Process alarm in AI function block.   |
|                         | 111:AI Hi Hi Alm                        |  | Process alarm in AI function block.   |
| O/S Mode Alarms         | 40:PB O/S Mode                          |  | RS.TARGET_MODE is O/S mode.   |
|                         | 41:TB O/S Mode                          |  | TB.TARGET_MODE is O/S mode.   |
|                         | 42:AI FB O/S Mode                       |  | AI.TARGET_MODE is O/S mode.   |
|                         | 43:Total1 FB O/S Mode                   |  | Total1.TARGET_MODE is O/S mode.   |
|                         | 44:Total2 FB O/S Mode                   |  | Total2.TARGET_MODE is O/S mode.   |
|                         | 45:Total3 FB O/S Mode                   |  | Total3.TARGET_MODE is O/S mode.   |
|                         | 46:DI1 FB O/S Mode                      |  | DI1.TARGET_MODE is O/S mode.  |
| Setting Alarms          | 47:DI2 FB O/S Mode                      |  | DI2.TARGET_MODE is O/S mode.  |
|                         | 50:Span > 10m/s                         | Check parameter 27 of AI and 34 of TB                                  | Span flow velocity setting is 11 m/s or more  |
|                         | 51:Span < 0.1m/s                        |  | Span flow velocity setting is 0.05 m/s or less  |
|                         | 57:Dens Set Err                         | Check parameter 34, 76 and 77 of TB                                    | Mass units have been selected for Base Flow Unit but density is set to 0.                         |
|                         | 71:Meas Mod Set                         | Check parameter 70 of TB   | Measure_Mode is set to Enhanced DF without selecting an optional specification code /HF1 or /HF2. |
|                         | 72:Size Set Err                         | Check parameter 31 and 32 of TB  | A value of 3000.1 mm or more is set for Nominal_Size.   |
|                         | 73:Adh Set Err                          | Check parameter 115 to 118 of TB                                       | The condition in Adhesion detection level, Level:1<Level:2<Level:3<Level:4 is not satisfied.      |
| 120:Total1 Unit Set Err | Unify the unit between volume and mass. | The mismatch of the unit set as TOTAL1 UNIT_TOT and VOLUME_FLOW_UNITS. |   |
| 121:Total2 Unit Set Err |   | The mismatch of the unit set as TOTAL2 UNIT_TOT and VOLUME_FLOW_UNITS. |   |
| 122:Total3 Unit Set Err |   | The mismatch of the unit set as TOTAL3 UNIT_TOT and VOLUME_FLOW_UNITS. |   |

T0513.eps

### Warning Display


When warning is generated, warning message is displayed alternatively at the third line. Followings are an example of warning display situation.



Normal mode screen



Alarm information screen



Normal mode screen

F0520.eps



# 6. IN-PROCESS OPERATION

This chapter describes the procedure performed when changing the operation of the function block of the AXF in process.

## 6.1 Mode Transition

When the function block mode is changed to Out\_Of\_Service, the function block pauses and a block alarm is issued.

When the function block mode is changed to Manual, the function block suspends updating of output values. In this case alone, it is possible to write a value to the OUT parameter of the block for output. Note that no parameter status can be changed.

## 6.2 Generation of Alarm

### 6.2.1 Indication of Alarm

When the self-diagnostics function indicates that a device is faulty, a diagnostic message (DIAGNOSIS or DIAGNOSIS\_EXTENSION) is issued from the physical block. When a diagnostic message is detected in each function block or a diagnostic message in the process value (process alarm) is detected, a diagnostic message is issued from each block. If a LCD indicator is installed, the error number is displayed. If two or more alarms are issued, multiple error messages are displayed.

When an alarm has been occurred, the corresponding alarm name, description, and suitable countermeasure will be displayed on the display unit. The normal Display Mode and Alarm Mode may be displayed alternatively. When a warning has been issued, the corresponding content will be shown in the third line in the Display Mode.




Figure 6.1 Error Identification on Indicator

### 6.2.2 Alarms and Warnings

The alarm and warning lists in each function block are shown in table 6.1 and 6.2.

**Table 6.1 Status of each parameter in failure mode (1/2)**

| Category          | Alarm                 | AI Block                                 |  |  | TOT Block  |  |  | DI Block                        |                                 |                             |
|-------------------|-----------------------|--|--|--|--|--|--|---------------------------------|---------------------------------|-----------------------------|
|                   |                       | FSAFE_TYPE = 0                           | FSAFE_TYPE = 1                           | FSAFE_TYPE = 2                           | FAIL_TOT = 0   | FAIL_TOT = 1   | FAIL_TOT = 2   | FSAFE_TYPE = 0                  | FSAFE_TYPE = 1                  | FSAFE_TYPE = 2              |
| System Alarms     | 10:uP Fault           | Uncertain; Substitute Value, ok          | Uncertain; Last Usage Value, ok          | Bad; Device Failure, Const.              | Uncertain Non Specific, ok   | Uncertain; Last Usable Value, Const.                                   | Uncertain Non Specific, ok   | Uncertain; Substitute Value, ok | Uncertain; Last Usage Value, ok | Bad; Device Failure, Const. |
|                   | 11:EEPROM Fault       |  |  |  |  |  |  |                                 |                                 |                             |
|                   | 12:A/D(H) Fault       |  |  |  |  |  |  |                                 |                                 |                             |
|                   | 13:A/D(L) Fault       |  |  |  |  |  |  |                                 |                                 |                             |
|                   | 14:A/D(Z) Fault       |  |  |  |  |  |  |                                 |                                 |                             |
|                   | 15:Coil Open          |  |  |  |  |  |  |                                 |                                 |                             |
|                   | 16:EEPROM Dflt        | Bad; Sensor Failure, Const.              | Bad; Device Failure, Const.              |  |  |  |  |                                 |                                 |                             |
|                   | 100:Comm uP Fault     | Bad; Device Failure, Const.              | Bad; Device Failure, Const.              |  |  |  |  |                                 |                                 |                             |
|                   | 101:Comm EEPROM Fault | Bad; Device Failure, ok                  | Bad; Device Failure, ok                  |  |  |  |  |                                 |                                 |                             |
|                   | 102:Total1 Not Saved  | -  | -  | -  | -  | -  | -  | -                               | -                               | -                           |
|                   | 103:Total2 Not Saved  | -  | -  | -  | -  | -  | -  | -                               | -                               | -                           |
|                   | 104:Total3 Not Saved  | -  | -  | -  | -  | -  | -  | -                               | -                               | -                           |
|                   | 105:Comm Error1       | Uncertain; Substitute Value, ok          | Uncertain; Last Usage Value, ok          | Bad; Device Failure, ok                  | Uncertain Non Specific, ok   | Uncertain; Last Usable Value, Const.                                   | Uncertain Non Specific, ok   | Uncertain; Substitute Value, ok | Uncertain; Last Usage Value, ok | Bad; Device Failure, ok     |
|                   | 106:Comm Error2       | -  | -  | -  | -  | -  | -  | -                               | -                               | -                           |
| 107:DL Incomplete | -                     | -  | -  | -  | -  | -  | -  | -                               | -                               |                             |
| 108:Download Fail | -                     | -  | -  | -  | -  | -  | -  | -                               | -                               |                             |
| Process Alarms    | 30:Sig Overflow       | Uncertain; Substitute Value, ok          | Uncertain; Last Usage Value, ok          | Bad; Sensor Failure, Const.              | Uncertain Non Specific, ok   | Uncertain; Last Usable Value, Const.                                   | Uncertain Non Specific, ok   | Uncertain; Substitute Value, ok | Uncertain; Last Usage Value, ok | Bad; Sensor Failure, Const. |
|                   | 31:Empty Pipe         | -  | -  | -  | -  | -  | -  | -                               | -                               | -                           |
|                   | 32:HH/LL Alm          | -  | -  | -  | -  | -  | -  | -                               | -                               | -                           |
|                   | 33:Adhesion Alm       | Uncertain; Substitute Value, ok          | Uncertain; Last Usage Value, ok          | Bad; Sensor Failure, Const.              | Uncertain Non Specific, ok   | Uncertain; Last Usable Value, Const.                                   | Uncertain Non Specific, ok   | Uncertain; Substitute Value, ok | Uncertain; Last Usage Value, ok | Bad; Sensor Failure, Const. |
|                   | 34:Insulation Alm     | -  | -  | -  | -  | -  | -  | -                               | -                               | -                           |
|                   | 110:AI Lo Lo Alm      | Good; Active Critical Alarm, Low limit.  | Good; Active Critical Alarm, Low limit.  | Good; Active Critical Alarm, Low limit.  | -  | -  | -  | -                               | -                               | -                           |
|                   | 111:AI Hi Hi Alm      | Good; Active Critical Alarm, High limit. | Good; Active Critical Alarm, High limit. | Good; Active Critical Alarm, High limit. | -  | -  | -  | -                               | -                               | -                           |
|                   | AI Lo Alm             | Good; Active Advisory Alarm, Low limit.  | Good; Active Advisory Alarm, Low limit.  | Good; Active Advisory Alarm, Low limit.  | -  | -  | -  | -                               | -                               | -                           |
|                   | AI Hi Alm             | Good; Active Advisory Alarm, High limit. | Good; Active Advisory Alarm, High limit. | Good; Active Advisory Alarm, High limit. | -  | -  | -  | -                               | -                               | -                           |
|                   | Total1 Lo Lo Alm      | -  | -  | -  | TOT1: Good; Active Critical Alarm, Low limit.<br>TOT2: --<br>TOT3: --  | TOT1: Good; Active Critical Alarm, Low limit.<br>TOT2: --<br>TOT3: --  | TOT1: Good; Active Critical Alarm, Low limit.<br>TOT2: --<br>TOT3: --  | -                               | -                               | -                           |
|                   | Total1 Hi Hi Alm      | -  | -  | -  | TOT1: Good; Active Critical Alarm, High limit.<br>TOT2: --<br>TOT3: -- | TOT1: Good; Active Critical Alarm, High limit.<br>TOT2: --<br>TOT3: -- | TOT1: Good; Active Critical Alarm, High limit.<br>TOT2: --<br>TOT3: -- | -                               | -                               | -                           |
|                   | Total1 Lo Alm         | -  | -  | -  | TOT1: Good; Active Advisory Alarm, Low limit.<br>TOT2: --<br>TOT3: --  | TOT1: Good; Active Advisory Alarm, Low limit.<br>TOT2: --<br>TOT3: --  | TOT1: Good; Active Advisory Alarm, Low limit.<br>TOT2: --<br>TOT3: --  | -                               | -                               | -                           |
|                   | Total1 Hi Alm         | -  | -  | -  | TOT1: Good; Active Advisory Alarm, High limit.<br>TOT2: --<br>TOT3: -- | TOT1: Good; Active Advisory Alarm, High limit.<br>TOT2: --<br>TOT3: -- | TOT1: Good; Active Advisory Alarm, High limit.<br>TOT2: --<br>TOT3: -- | -                               | -                               | -                           |
|                   | Total2 Lo Lo Alm      | -  | -  | -  | TOT1: --<br>TOT2: Good; Active Critical Alarm, Low limit.<br>TOT3: --  | TOT1: --<br>TOT2: Good; Active Critical Alarm, Low limit.<br>TOT3: --  | TOT1: --<br>TOT2: Good; Active Critical Alarm, Low limit.<br>TOT3: --  | -                               | -                               | -                           |
|                   | Total2 Hi Hi Alm      | -  | -  | -  | TOT1: --<br>TOT2: Good; Active Critical Alarm, High limit.<br>TOT3: -- | TOT1: --<br>TOT2: Good; Active Critical Alarm, High limit.<br>TOT3: -- | TOT1: --<br>TOT2: Good; Active Critical Alarm, High limit.<br>TOT3: -- | -                               | -                               | -                           |
|                   | Total2 Lo Alm         | -  | -  | -  | TOT1: --<br>TOT2: Good; Active Advisory Alarm, Low limit.<br>TOT3: --  | TOT1: --<br>TOT2: Good; Active Advisory Alarm, Low limit.<br>TOT3: --  | TOT1: --<br>TOT2: Good; Active Advisory Alarm, Low limit.<br>TOT3: --  | -                               | -                               | -                           |
|                   | Total2 Hi Alm         | -  | -  | -  | TOT1: --<br>TOT2: Good; Active Advisory Alarm, High limit.<br>TOT3: -- | TOT1: --<br>TOT2: Good; Active Advisory Alarm, High limit.<br>TOT3: -- | TOT1: --<br>TOT2: Good; Active Advisory Alarm, High limit.<br>TOT3: -- | -                               | -                               | -                           |
|                   | Total3 Lo Lo Alm      | -  | -  | -  | TOT1: --<br>TOT2: --<br>TOT3: Good; Active Critical Alarm, Low limit.  | TOT1: --<br>TOT2: --<br>TOT3: Good; Active Critical Alarm, Low limit.  | TOT1: --<br>TOT2: --<br>TOT3: Good; Active Critical Alarm, Low limit.  | -                               | -                               | -                           |
|                   | Total3 Hi Hi Alm      | -  | -  | -  | TOT1: --<br>TOT2: --<br>TOT3: Good; Active Critical Alarm, High limit. | TOT1: --<br>TOT2: --<br>TOT3: Good; Active Critical Alarm, High limit. | TOT1: --<br>TOT2: --<br>TOT3: Good; Active Critical Alarm, High limit. | -                               | -                               | -                           |
|                   | Total3 Lo Alm         | -  | -  | -  | TOT1: --<br>TOT2: --<br>TOT3: Good; Active Advisory Alarm, Low limit.  | TOT1: --<br>TOT2: --<br>TOT3: Good; Active Advisory Alarm, Low limit.  | TOT1: --<br>TOT2: --<br>TOT3: Good; Active Advisory Alarm, Low limit.  | -                               | -                               | -                           |
|                   | Total3 Hi Alm         | -  | -  | -  | TOT1: --<br>TOT2: --<br>TOT3: Good; Active Advisory Alarm, High limit. | TOT1: --<br>TOT2: --<br>TOT3: Good; Active Advisory Alarm, High limit. | TOT1: --<br>TOT2: --<br>TOT3: Good; Active Advisory Alarm, High limit. | -                               | -                               | -                           |

Table 6.1 Status of each parameter in failure mode (2/2)

| Category                | Alarm                   | AI Block                        |                                 |   | TOT Block   |   |   | DI Block                                   |  |  |
|-------------------------|-------------------------|---------------------------------|---------------------------------|---|---|---|---|--|--|--|
|                         |                         | FSAFE_TYPE = 0                  | FSAFE_TYPE = 1                  | FSAFE_TYPE = 2  | FAIL_TOT = 0  | FAIL_TOT = 1  | FAIL_TOT = 2  | FSAFE_TYPE = 0                             | FSAFE_TYPE = 1                             | FSAFE_TYPE = 2                             |
| O/S Mode Alarms         | 40:PB O/S Mode          | Bad; Out of Service, Const.     | Bad; Out of Service, Const.     | Bad; Out of Service, Const.                             | Bad; Out of Service, Const.                             | Bad; Out of Service, Const.                             | Bad; Out of Service, Const.                             | Bad; Out of Service, Const.                | Bad; Out of Service, Const.                | Bad; Out of Service, Const.                |
|                         | 41:TB O/S Mode          | Uncertain; Substitute Value, ok | Uncertain; Last Usage Value, ok | Bad; Out of Service, ok                                 | Uncertain Non Specific, ok                              | Uncertain; Last Usable Value, Const.                    | Uncertain Non Specific, ok                              | Uncertain; Substitute Value, ok            | Uncertain; Last Usage Value, ok            | Bad; Out of Service, ok                    |
|                         | 42:AI FB O/S Mode       | Bad; Out of Service, Const.     | Bad; Out of Service, Const.     | Bad; Out of Service, Const.                             | -   | -   | -   | -  | -  | -  |
|                         | 43:Total1 FB O/S Mode   | -                               | -                               | -   | TOT1: Bad; Out of Service, Const.<br>TOT2: -<br>TOT3: - | TOT1: Bad; Out of Service, Const.<br>TOT2: -<br>TOT3: - | TOT1: Bad; Out of Service, Const.<br>TOT2: -<br>TOT3: - | -  | -  | -  |
|                         | 44:Total2 FB O/S Mode   | -                               | -                               | -   | TOT1: -<br>TOT2: Bad; Out of Service, Const.<br>TOT3: - | TOT1: -<br>TOT2: Bad; Out of Service, Const.<br>TOT3: - | TOT1: -<br>TOT2: Bad; Out of Service, Const.<br>TOT3: - | -  | -  | -  |
|                         | 45:Total3 FB O/S Mode   | -                               | -                               | -   | TOT1: -<br>TOT2: -<br>TOT3: Bad; Out of Service, Const. | TOT1: -<br>TOT2: -<br>TOT3: Bad; Out of Service, Const. | TOT1: -<br>TOT2: -<br>TOT3: Bad; Out of Service, Const. | -  | -  | -  |
|                         | 46:DI1 FB O/S Mode      | -                               | -                               | -   | -   | -   | -   | DI1: Bad; Out of Service, Const.<br>DI2: - | DI1: Bad; Out of Service, Const.<br>DI2: - | DI1: Bad; Out of Service, Const.<br>DI2: - |
|                         | 47:DI2 FB O/S Mode      | -                               | -                               | -   | -   | -   | -   | DI1: -<br>DI2: Bad; Out of Service, Const. | DI1: -<br>DI2: Bad; Out of Service, Const. | DI1: -<br>DI2: Bad; Out of Service, Const. |
| Setting Alarms          | 50:Span > 10m/s         | Uncertain; Substitute Value, ok | Uncertain; Last Usage Value, ok | Bad; Non specific, Const.                               | Uncertain Non Specific, ok                              | Uncertain; Last Usable Value, Const.                    | Uncertain Non Specific, ok                              | Uncertain; Substitute Value, ok            | Uncertain; Last Usage Value, ok            | Bad; Non specific, Const.                  |
|                         | 51:Span < 0.1m/s        | -                               | -                               | -   | -   | -   | -   | -  | -  | -  |
|                         | 56:H/L HH/LL Set        | -                               | -                               | -   | -   | -   | -   | -  | -  | -  |
|                         | 57:Dens Set Err         | Uncertain; Substitute Value, ok | Uncertain; Last Usage Value, ok | Bad; Non specific, Const.                               | Uncertain Non Specific, ok                              | Uncertain; Last Usable Value, Const.                    | Uncertain Non Specific, ok                              | Uncertain; Substitute Value, ok            | Uncertain; Last Usage Value, ok            | Bad; Non specific, Const.                  |
|                         | 71:Meas Mod Set         | -                               | -                               | -   | -   | -   | -   | -  | -  | -  |
|                         | 72:Size Set Err         | -                               | -                               | -   | -   | -   | -   | -  | -  | -  |
|                         | 73:Adh Set Err          | -                               | -                               | -   | -   | -   | -   | -  | -  | -  |
|                         | 120:Total1 Unit Set Err | -                               | -                               | -   | TOT1:Bad; Configuration Error, ok<br>TOT2: -<br>TOT3: - | TOT1:Bad; Configuration Error, ok<br>TOT2: -<br>TOT3: - | TOT1:Bad; Configuration Error, ok<br>TOT2: -<br>TOT3: - | -  | -  | -  |
| 121:Total2 Unit Set Err | -                       | -                               | -                               | TOT1: -<br>TOT2:Bad; Configuration Error, ok<br>TOT3: - | TOT1: -<br>TOT2:Bad; Configuration Error, ok<br>TOT3: - | TOT1: -<br>TOT2:Bad; Configuration Error, ok<br>TOT3: - | -   | -  | -  |  |
| 122:Total3 Unit Set Err | -                       | -                               | -                               | TOT1: -<br>TOT2: -<br>TOT3:Bad; Configuration Error, ok | TOT1: -<br>TOT2: -<br>TOT3:Bad; Configuration Error, ok | TOT1: -<br>TOT2: -<br>TOT3:Bad; Configuration Error, ok | -   | -  | -  |  |



**Table 6.2 Status of each parameter in warning mode**

| Category               | Warning                            | AI Block                                       |  |  | TOT Block  |  |  | DI Block  |   |   |
|------------------------|------------------------------------|--|--|--|--|--|--|---|---|---|
|                        |                                    | FSAFE_TYPE = 0                                 | FSAFE_TYPE = 1                                 | FSAFE_TYPE = 2                                 | FAIL_TOT = 0   | FAIL_TOT = 1   | FAIL_TOT = 2   | FSAFE_TYPE = 0                                  | FSAFE_TYPE = 1                                  | FSAFE_TYPE = 2                                  |
| Warning                | 80:Adhesion Wng                    | Good (NC);<br>Maintenance<br>required, ok      | Good (NC);<br>Maintenance<br>required, ok      | Good (NC);<br>Maintenance<br>required, ok      | Good (NC);<br>Maintenance<br>required, ok                    | Good (NC);<br>Maintenance<br>required, ok                    | Good (NC);<br>Maintenance<br>required, ok                    | Good (NC);<br>Maintenance<br>required, ok       | Good (NC);<br>Maintenance<br>required, ok       | Good (NC);<br>Maintenance<br>required, ok       |
|                        | 81:Insu-Brk Wng                    | Good (NC);<br>Maintenance<br>required, ok      | Good (NC);<br>Maintenance<br>required, ok      | Good (NC);<br>Maintenance<br>required, ok      | Good (NC);<br>Maintenance<br>required, ok                    | Good (NC);<br>Maintenance<br>required, ok                    | Good (NC);<br>Maintenance<br>required, ok                    | Good (NC);<br>Maintenance<br>required, ok       | Good (NC);<br>Maintenance<br>required, ok       | Good (NC);<br>Maintenance<br>required, ok       |
|                        | 82:Auto Zero Wng                   | Uncertain;<br>Non specific,<br>ok              | Uncertain;<br>Non specific,<br>ok              | Uncertain;<br>Non specific,<br>ok              | Uncertain;<br>Non specific,<br>ok                            | Uncertain;<br>Non specific,<br>ok                            | Uncertain;<br>Non specific,<br>ok                            | Uncertain;<br>Non specific,<br>ok               | Uncertain;<br>Non specific,<br>ok               | Uncertain;<br>Non specific,<br>ok               |
|                        | 84:Disp Over Wng                   | -  | -  | -  | -  | -  | -  | -   | -   | -   |
|                        | 85:FLow Vel Over                   | Uncertain;<br>Non specific,<br>Low/High limit. | Uncertain;<br>Non specific,<br>Low/High limit. | Uncertain;<br>Non specific,<br>Low/High limit. | Uncertain;<br>Non specific,<br>Low/High limit.               | Uncertain;<br>Non specific,<br>Low/High limit.               | Uncertain;<br>Non specific,<br>Low/High limit.               | Uncertain;<br>Non specific,<br>Low/High limit.  | Uncertain;<br>Non specific,<br>Low/High limit.  | Uncertain;<br>Non specific,<br>Low/High limit.  |
|                        | 90:Display Sw                      | -  | -  | -  | -  | -  | -  | -   | -   | -   |
|                        | 140:Sim. Jmpr On                   | -  | -  | -  | -  | -  | -  | -   | -   | -   |
|                        | 141:PB Sim.<br>enabled (Note1)     | -  | -  | -  | -  | -  | -  | -   | -   | -   |
|                        | 142:TB VF Sim.<br>enabled (Note1)  | -  | -  | -  | -  | -  | -  | -   | -   | -   |
|                        | 143:AI Sim.<br>enabled (Note1)     | Depend on<br>SIMULATE.Status                   | Depend on<br>SIMULATE.Status                   | Depend on<br>SIMULATE.Status                   | -  | -  | -  | -   | -   | -   |
|                        | 144:Total1 Sim.<br>enabled (Note1) | -  | -  | -  | TOT1: Depend on<br>SIMULATE.<br>Status<br>TOT2: -<br>TOT3: - | TOT1: Depend on<br>SIMULATE.<br>Status<br>TOT2: -<br>TOT3: - | TOT1: Depend on<br>SIMULATE.<br>Status<br>TOT2: -<br>TOT3: - | -   | -   | -   |
|                        | 145:Total2 Sim.<br>enabled (Note1) | -  | -  | -  | TOT1: -<br>TOT2: Depend on<br>SIMULATE.<br>Status<br>TOT3: - | TOT1: -<br>TOT2: Depend on<br>SIMULATE.<br>Status<br>TOT3: - | TOT1: -<br>TOT2: Depend on<br>SIMULATE.<br>Status<br>TOT3: - | -   | -   | -   |
|                        | 146:Total3 Sim.<br>enabled (Note1) | -  | -  | -  | TOT1: -<br>TOT2: -<br>TOT3: Depend on<br>SIMULATE.<br>Status | TOT1: -<br>TOT2: -<br>TOT3: Depend on<br>SIMULATE.<br>Status | TOT1: -<br>TOT2: -<br>TOT3: Depend on<br>SIMULATE.<br>Status | -   | -   | -   |
|                        | 147:DI1 Sim.<br>enabled (Note1)    | -  | -  | -  | -  | -  | -  | DI1: Depend on<br>SIMULATE.<br>Status<br>DI2: - | DI1: Depend on<br>SIMULATE.<br>Status<br>DI2: - | DI1: Depend on<br>SIMULATE.<br>Status<br>DI2: - |
|                        | 148:DI2 Sim.<br>enabled (Note1)    | -  | -  | -  | -  | -  | -  | DI1: -<br>DI2: Depend on<br>SIMULATE.<br>Status | DI1: -<br>DI2: Depend on<br>SIMULATE.<br>Status | DI1: -<br>DI2: Depend on<br>SIMULATE.<br>Status |
|                        | 150:AI FB Man<br>Mode              | -  | -  | -  | -  | -  | -  | -   | -   | -   |
|                        | 151:Total1 FB Man<br>Mode          | -  | -  | -  | -  | -  | -  | -   | -   | -   |
|                        | 152:Total2 FB Man<br>Mode          | -  | -  | -  | -  | -  | -  | -   | -   | -   |
|                        | 153:Total3 FB Man<br>Mode          | -  | -  | -  | -  | -  | -  | -   | -   | -   |
|                        | 154:DI1 FB Man<br>Mode             | -  | -  | -  | -  | -  | -  | -   | -   | -   |
| 155:DI2 FB Man<br>Mode | -                                  | -  | -  | -  | -  | -  | -  | -   | -   |   |

Note1: Make it the condition that the hardware simulation jumper is ON.

## 6.3 Simulation Function


The AXF has a simulation function and it is possible to conduct testing for the downstream function blocks or alarm processes. Following description is how to use and how to set parameters in this function.

A SIMULATE\_ENABLE switch is mounted in the AXF amplifier (See Figure 6.3.1). This is to prevent the accidental operation of this function. When the No 2 switch is ON, simulation function is enabled.

The [Target Mode] in each function block must be also changed from [AUTO] to [O/S] before setting the simulation parameters.

The simulation parameters in each function block including alarm set as diagnosis in the AI block are described below.

The SIMULATE\_ENABLE switch (No 2 switch) and the [Target Mode] in each function block must be returned “OFF” / “AUTO” when the simulation operation was finished.



F0602.eps

Figure 6.3.1 SIMULATE\_ENABLE Switch Position



### WARNING

When opening the cover, wait for more than 10 minutes after turning off the power. Furthermore, opening of the cover must also be carried out by the trained personnel having knowledge of safety standard.




### IMPORTANT

- To preserve the safety, do not touch the electrical circuit and cable except the SIMULATE\_ENABLE switch.
- Removing and installing cover are necessary for the setting SIMULATE\_ENABLE switch. Perform removing and installing cover as described in following Section of user's manual. Refer to Subsection 5.4.2 of IM 01E20D01-01E, or refer to Subsection 10.1.2 of IM 01E20C02-01E.

### 6.3.1 Transducer Block

The configuration of transducer block for this function is shown at Figure 6.3.2. It is necessary to set parameters as shown in Table 6.3.1 when the simulation function is used.



F0603.EPS

Figure 6.3.2 Configuration of Simulation function in the Transducer block

Table 6.3.1 Simulation parameters in the Transducer Block

| Index | Parameters           | Description  | Valid Range  | Initial Value             |
|-------|----------------------|--|--|---------------------------|
| 96    | SIMULATE_MODE        | Select "1: Volume Flow" when the simulation function is used.  | 0: Off<br>1: Volume Flow                             | 0: Off                    |
| 97    | SIMULATE_TYPE        | Set the SIMULATE TYPE.   | 0: Fixed,<br>1: 2 points,<br>2: 3 points,<br>3: Ramp | 0: Fixed                  |
| 98    | SIMULATE_VOLUME_FLOW | Set the value to be simulated.   | None<br>(Treated as VOLUME_FLOW_UNITS)               | Value: 0,<br>Status: Good |
| 99    | SIMULATE_UP_VALUE    | Set the simulated upper value when SIMULATE_TYPE is selected as 1, 2 or 3.   | Except SIMULATE_LO_VALUE                             | 0                         |
| 100   | SIMULATE_LO_VALUE    | Set the simulated lower value when SIMULATE_TYPE is selected as 1, 2 or 3.   | Except SIMULATE_UP_VALUE                             | 0                         |
| 101   | SIMULATE_TIME        | Show the time to maintain a constant value when SIMULATE_TYPE is selected as 1 or 2. When SIMULATE_TYPE is selected as 3, show the time to maintain a constant change. | Except 0   | 30 Sec                    |

T0603.EPS

**6.3.2 AI / TOT / DI Blocks**

When the parameters are set in the transducer block, it is necessary to set parameters as shown in Table 6.3.2 in the AI, TOT and DI blocks next. When Simulate\_Enabled in each function block described at Table 6.3.2 is set to “1: Enabled”, the applicable function block uses the simulation value set in this parameter instead of the data from the transducer block.


**Table 6.3.2 Simulation parameters in the AI, TOT and DI Blocks**

| Sub-index | Parameters       | Description                                     | Valid Range             | Initial Value |
|-----------|------------------|---|-------------------------|---------------|
| 1         | Simulate_Status  | Set the data status to be simulated.            | Unsigned8               | 0             |
| 2         | Simulate_Value   | Set the value of the data to be simulated.      | Float                   | 0             |
| 3         | Simulate_Enabled | Controls the simulation function of this block. | 0: Disabled, 1: Enabled | 0: Disabled   |

T0604.EPS

**6.3.3 Physical Block**

It is also necessary to set alarms as diagnosis in the Physical block at the same time when the simulation function is used. The Figure 6.3.3 shows the configuration of alarm for simulation function and the Table 6.3.3 is described its parameter setting.



F0604.EPS

**Figure 6.3.3 Configuration of simulated alarm in the Physical block**

**Table 6.3.3 Alarm parameters as simulation function in the Physical block**

| Index | Parameters              | Explanation   | Valid Range                  | Initial Value                      |
|-------|-------------------------|---|------------------------------|------------------------------------|
| 52    | DIAGNOSIS_SIM_MODE      | When the hardware simulation jumper is on, DIAGNOSIS_SIM_MODE is set to enable, and the bits are set to "on", the alarms (or warnings) can be modified. | 0: Disabled,<br>1: Enabled   | 0: Disabled                        |
| 53    | DIAGNOSIS_SIM_EXTENSION | Definition of supported DIAGNOSIS_EXTENSION information-bits for testing alarms and warnings can be modified.   | 0: Off,<br>1: On<br>(Note 1) | 0x0000 0000 0000<br>0000 0000 0000 |

Note 1: When the valid range is set to "1: ON", the following data is necessary to set.

| Octet | Bit | Alarm |                   |
|-------|-----|-------|-------------------|
|       |     | No.   | Name              |
| 1     | 0   | 10    | uP Fault          |
|       | 1   | 11    | EEPROM Fault      |
|       | 2   | 12    | A/D(H) Fault      |
|       | 3   | 13    | A/D(L) Fault      |
|       | 4   | 14    | A/D(Z) Fault      |
|       | 5   | 15    | Coil Open         |
|       | 6   | 16    | EEPROM Dflt       |
|       | 7   | 100   | Comm uP Fault     |
| 2     | 0   | 101   | Comm EEPROM Fault |
|       | 1   | 102   | Total1 Not Saved  |
|       | 2   | 103   | Total2 Not Saved  |
|       | 3   | 104   | Total3 Not Saved  |
|       | 4   | 105   | Comm Error1       |
|       | 5   | 106   | Comm Error2       |
|       | 6   | 107   | (Reserved)        |
|       | 7   | 108   | (Reserved)        |
| 3     | 0   |       | (Not Used)        |
|       | 1   |       | (Not Used)        |
|       | 2   |       | (Not Used)        |
|       | 3   |       | (Not Used)        |
|       | 4   | 30    | Sig Overflow      |
|       | 5   | 31    | Empty Pipe        |
|       | 6   | 33    | Adhesion Alm      |
|       | 7   | 34    | (Reserved)        |

| Octet | Bit | Alarm |               |
|-------|-----|-------|---------------|
|       |     | No.   | Name          |
| 4     | 0   | 50    | Span > 10m/s  |
|       | 1   | 51    | Span < 0.1m/s |
|       | 2   | 57    | Dens Set Err  |
|       | 3   | 71    | Meas Mod Set  |
|       | 4   | 72    | Size Set Err  |
|       | 5   | 73    | Adh Set Err   |
|       | 6   |       | (Not Used)    |
|       | 7   |       | (Not Used)    |
| 5     | 0   |       | (Not Used)    |
|       | 1   |       | (Not Used)    |
|       | 2   |       | (Not Used)    |
|       | 3   |       | (Not Used)    |
|       | 4   | 80    | Adhesion Wng  |
|       | 5   | 81    | (Reserved)    |
|       | 6   | 82    | Auto Zero Wng |
|       | 7   | 85    | Flow Vel Over |
| 6     | 0   | 90    | (Reserved)    |
|       | 1   |       | (Not Used)    |
|       | 2   |       | (Not Used)    |
|       | 3   |       | (Not Used)    |
|       | 4   |       | (Not Used)    |
|       | 5   |       | (Not Used)    |
|       | 6   |       | (Not Used)    |
|       | 7   | 140   | Sim. Jmpr On  |

T0605.EPS

### 6.3.4 Simulation Parameter Setup by FieldMate R1.03

This section describes the procedure taken to set and change the parameters in a use of simulation function in each function block.



#### IMPORTANT

- Before running the program, log-in to Windows as an Administrator or as a user with administrative authority.
- When comm. DTM is connected to the PROFIBUS network with class 1 master running, set the same busparameters of class 1 master.

It is mandatory to change the [Target Mode] from [AUTO] to [O/S] before using this function in each function block. Also the hardware slide switch (No 2) in the AXF amplifier must be set “ON” beforehand when this function is used.

The hardware slide switch and the [Target Mode] in each function block must be returned “OFF” / “AUTO” when the simulation operation was finished.



#### IMPORTANT

Do not turn power OFF immediately after parameter setting. When parameters are saved to the EEPROM, the redundant processing is executed for an improvement of reliability. Should the power be turned OFF within 60 seconds after setting of parameters, changed parameters are not saved and may return to their original values.

#### (1) Simulate Measured Value Setup in the Transducer Block

Entry simulation, its type, its values at [Simulate Measured Value] in the [Transducer Block] menu.




Figure 6.3.4 Simulate Measured Value Setup

#### (2) Simulation Setup in the AI Block

Entry the simulation value, simulation quality, status and simulation in the [Analog Input] menu.




Figure 6.3.5 Simulation Setup

#### (3) Simulation Setup in the TOT Block

Select adequate [Simulation Value], [Simulation Quality], [Simulation] and [Status] in each [Totalizer] menu.




Figure 6.3.6 Simulation Setup

#### (4) Simulation Setup in the DI Block

Select the adequate type at [Simulation Value], [Simulation Quality], [Simulation] and [Status] in each [Discrete Input] menu.




Figure 6.3.7 Simulation Setup

#### (5) Simulate Diagnosis setup in the Physical Block

Select a use of Simulation function and parameters at [Simulation Diagnosis] in the [Physical Block] menu.




Figure 6.3.8 Simulate Diagnosis Setup

# 7. DIAGNOSTIC INFORMATION

## 7.1 DEVICE STATUS

Diagnostic information and failures of the AXF are indicated by using parameter DIAGNOSIS (slot 0, index 29) and DIAGNOSIS\_EXTENSION (slot:0, index 30) in Physical Block. Each diagnostic information is supported when the corresponding bit in DIAGNOSIS\_MASK and DIAGNOSIS\_EXTENSION is set. Diagnosis and Diagnosis Extension are listed in Table 7.1 and Table 7.2.

**Table 7.1 Contents of DIAGNOSIS**

| Octet | Bit                    | Mnemonic   | Description  | Remarks  | Mask |
|-------|------------------------|--|--|--|------|
| 1     | 0                      | DIA_HW_ELECTR  | Hardware failure of the electronic                       | 10:uP Fault<br>17:Comm uP Fault<br>19:I/F Module Fault<br>12:A/D(H) Fault<br>13:A/D(L) Fault<br>14:A/D(Z) Fault<br>100:Comm uP Fault<br>105:Comm Error1<br>106:Comm Error2 | 1    |
|       | 1                      | DIA_HW_MECH  | Hardware failure mechanics                               | 15:Coil Open   | 1    |
|       | 2                      | DIA_TEMP_MOTOR   | Motor temperature too high                               | –  | 0    |
|       | 3                      | DIA_TEMP_ELECTR  | Electronic temperature too high                          | –  | 0    |
|       | 4                      | DIA_MEM_CHKSUM   | Memory error   | 11:EEPROM Fault<br>101:Comm EEPROM Fault   | 1    |
|       | 5                      | DIA_MEASUREMENT  | Failure in Measurement                                   | 30:Sig Overflow  | 1    |
|       | 6                      | DIA_NOT_INIT   | Device not initialized (No self calibration)             | 16:EEPROM Dflt   | 1    |
|       | 7                      | DIA_INIT_ERR   | Self calibration failed                                  | –  | 0    |
| 2     | 0                      | DIA_ZERRO_ERR  | Zero point error (limit position)                        | 82:Auto Zero Wng   | 1    |
|       | 1                      | DIA_SUPPLY   | 1 DIA_SUPPLY Power supply failed (electrical, pneumatic) | –  | 0    |
|       | 2                      | DIA_CONF_INVALID   | Configuration not valid                                  | 50:Span > 10m/s<br>51:Span < 0.1m/s<br>57:Dens Set Err<br>71:Meas Mod Set<br>72:Size Set Err<br>73:Adh Set Err   | 1    |
|       | 3                      | DIA_WARMSTART  | New-start-up (warm start up) carried out.                | hot start  | 0    |
|       | 4                      | DIA_COLDSTART  | Re-start-up (cold start up) carried out.                 | HW,SW,DL restart power fail  | 0    |
|       | 5                      | DIA_MAINTENANCE  | Maintenance required                                     | 31:Empty Pipe<br>33:Adhesion Alm<br>80:Adhesion Wng<br>85:Flow Vel Over  | 1    |
|       | 6                      | DIA_CHARACTER  | Characterization invalid                                 | –  | 0    |
| 7     | IDENT_NUMBER_Violation | Set to 1 (one), if the Ident_Number of the running cyclic data transfer and the value of Physical Block IDENT_NUMBER_SELECTOR parameter are different. |  | 1  |      |
| 3     | 0-7                    | Reserved   | Reserved for use within the PNO                          |  | X    |
| 4     | 0-6                    | Reserved   | Reserved for use within the PNO                          |  | X    |
|       | 7                      | EXTENSION_AVAILABLE  | More diagnosis information is available.                 |  | 1    |

T0701.EPS



Table 7.2 List of DIAGNOSIS\_EXTENSION

| Category       | DIAGNOSIS_EXTENSION |                 | Display Message       | Countermeasure Message                                     | Alarm Description   |  |
|----------------|---------------------|-----------------|-----------------------|--|---|--|
|                | Octet               | Bit             |                       |  |   |  |
| System Alarms  | 1                   | 0               | 10:uP Fault           | Contact nearest office or service center                   | Microprocessor error  |  |
|                |                     | 1               | 11:EEPROM Fault       |  | A/D converter error   |  |
|                |                     | 2               | 12:A/D(H) Fault       |  |   |  |
|                |                     | 3               | 13:A/D(L) Fault       |  |   |  |
|                |                     | 4               | 14:A/D(Z) Fault       | Cut the power and check coil & EX cables                   | Flowtube coil open-circuit  |  |
|                |                     | 5               | 15:Coil Open          |  | EEPROM default values   |  |
|                |                     | 6               | 16:EEPROM Dflt        |  | FB Microprocessor error   |  |
|                | 2                   | 0               | 100:Comm uP Fault     | Contact nearest office or service center                   | FB EEPROM error   |  |
|                |                     | 1               | 101:Comm EEPROM Fault |  | Total1 had not been stored when the device was turned off.  |  |
|                |                     | 2               | 102:Total1 Not Saved  | Total2 had not been stored when the device was turned off. |   |  |
|                |                     | 3               | 103:Total2 Not Saved  | Total3 had not been stored when the device was turned off. |   |  |
|                |                     | 4               | 104:Total3 Not Saved  | Contact nearest office or service center                   | Communication error   |  |
|                |                     | 5               | 105:Comm Error1       | Contact nearest office or service center                   | Communication error   |  |
|                |                     | 6               | 106:Comm Error2       |  |   |  |
| (Not Used)     | 3                   | 0               | (Not Used)            |  |   |  |
|                |                     | 1               | (Not Used)            |  |   |  |
|                |                     | 2               | (Not Used)            |  |   |  |
|                |                     | 3               | (Not Used)            |  |   |  |
|                |                     | 4               | 30 Sig Overflow       | Check signal cable and grounding                           | Input signal error  |  |
|                |                     | 5               | 31:Empty Pipe         | Fill flow tube with fluid                                  | Flowtube is not filled with fluid   |  |
|                |                     | 6               | 33:Adhesion Alm       | Clean electrodes   | Electrode adhesion alarm  |  |
| Setting Alarms | 4                   | 0               | 50:Span > 10m/s       | Check parameter 27 of AI and 34 of TB                      | Span flow velocity setting is 11 m/s or more  |  |
|                |                     | 1               | 51:Span < 0.1m/s      |  | Span flow velocity setting is 0.05 m/s or less  |  |
|                |                     | 2               | 57:Dens Set Err       | Check parameter 34, 76 and 77 of TB                        | Mass units have been selected for Base Flow Unit but density is set to 0.                         |  |
|                |                     | 3               | 71:Meas Mod Set       | Check parameter 70 of TB                                   | Measure_Mode is set to Enhanced DF without selecting an optional specification code /HF1 or /HF2. |  |
|                |                     | 4               | 72:Size Set Err       | Check parameter 31 and 32 of TB                            | A value of 3000.1 mm or more is set for Nominal_Size.   |  |
|                |                     | 5               | 73:Adh Set Err        | Check parameter 115 to 118 of TB                           | The condition in Adhesion detection level, Level:1<Level:2<Level:3<Level:4 is not satisfied.      |  |
|                |                     | 6               | (Not Used)            |  |   |  |
|                | (Not Used)          | 5               | 0                     | (Not Used)   |   |  |
|                |                     |                 | 1                     | (Not Used)   |   |  |
|                |                     |                 | 2                     | (Not Used)   |   |  |
|                |                     |                 | 3                     | (Not Used)   |   |  |
|                |                     |                 | 4                     | 80:Adhesion Wng  |   | Slight adhesion to electrodes.   |
|                |                     |                 | 5                     | (Reserved)   |   |  |
|                |                     |                 | 6                     | 82:Auto Zero Wng   |   | Results of automatic zero adjustment are higher than the rated values. |
| (Not Used)     | 6                   | 0               | (Reserved)            |  | Flow velocity overflow.   |  |
|                |                     | 1               | (Not Used)            |  |   |  |
|                |                     | 2               | (Not Used)            |  |   |  |
|                |                     | 3               | (Not Used)            |  |   |  |
|                |                     | 4               | (Not Used)            |  |   |  |
|                |                     | 5               | (Not Used)            |  |   |  |
|                |                     | 6               | (Not Used)            |  |   |  |
| Warning        | 7                   | 140:Sim.Jmpr On |                       | Simulation Jumper is set to ON (Hardware).                 |   |  |

T0702.EPS

# 8. GENERAL SPECIFICATIONS

## 8.1 STANDARD SPECIFICATIONS

For items other than those described below, refer to IM 01E20D01-01E, IM 01E20C02-01E.

### Applicable Models:

Integral Flowmeter AXF  
Remote Converter AXFA14

### Output Signal:

Digital communication signal based on PROFIBUS PA protocol.

### Output data

Volumetric flow, Totalized value, Status output (Adhesion alarm, HH/H/L/LL alarm)

### Input data

Totalized value reset

### Function Blocks:

One AI Function block, Three Totalizer function blocks and Two DI function blocks are available (PROFIBUS Profile 3.01 Compliant)

### Conditions of Communication Line:

Supply voltage from the Bus: 9 to 32 V DC  
Current Draw: 15mA (maximum)

### Bus Address Switch:

via Hardware Address Switch or via Software

### FDE (Fault Disconnection Electronic):

0 mA

### Alarm Selection Function:

These informations are indicated in DIAGNOSTICS parameter, which can be handled during normal operation.

(Note 1) The following functions are not supported in the PROFIBUS model.

- Pulse Output
- Multi-range Function
- Totalization Switch
- Alarm Output

### Power Supply Voltage:

#### Power supply code 1:

- AC specifications  
Rated power supply: 100 to 240 V AC, 50/60 Hz
- DC specifications  
Rated power supply: 100 to 120 V DC

#### Power supply code 2:

- AC specifications  
Rated power supply: 24 V AC, 50/60 Hz
- DC specifications  
Rated power supply: 24 V DC

### Displayed Language:

In the case of PROFIBUS PA communication type, only English is provided.

## STANDARD PERFORMANCE

### Accuracy:

Note: The accuracy of a product before shipment is defined as totalized value at the result of calibration test in our water actual flow test facility.

Calibrated conditions in our water actual test facility are as follows:

Fluid temperature; 20 ± 10°C  
Ambient temperature; 20 ± 5°C  
Length of straight runs; 10 D or more on the upstream side; 5 D or more on the downstream side  
Reference conditions; Similar to BS EN29104 (1993); ISO 9104 (1991)

### PFA/Ceramics Lining;

| Size mm (in.)         | Flow Velocity V m/s (ft/s) | Standard Accuracy (Calibration code B) | Flow Velocity V m/s (ft/s) | High Grade Accuracy (Calibration code C) |
|-----------------------|----------------------------|--|----------------------------|--|
| 2.5 (0.1) to 15 (0.5) | V < 0.3 (1)                | ±1.0 mm/s                              | —                          | —  |
|                       | 0.3 ≤ V ≤ 10 (1) (33)      | ±0.35% of Rate                         |                            |  |
| 25 (1.0) to 200 (8.0) | V < 0.15 (0.5)             | ±0.5 mm/s                              | V < 0.15 (0.5)             | ±0.5 mm/s                                |
|                       | 0.15 ≤ V ≤ 10 (0.5) (33)   | ±0.35% of Rate                         | 0.15 ≤ V < 1 (0.5) (3.3)   | ±0.18% of Rate<br>± 0.2mm/s              |
|                       |                            |  | 1 ≤ V ≤ 10 (3.3) (33)      | ±0.2% of Rate                            |
| 250 (10) to 400 (16)  | V < 0.15 (0.5)             | ±0.5 mm/s                              | —                          | —  |
|                       | 0.15 ≤ V ≤ 10 (0.5) (33)   | ±0.35% of Rate                         |                            |  |

T02.EPS

### Polyurethane Rubber /Natural Soft Rubber / EPDM Rubber Lining;

| Size mm (in.)        | Flow Velocity V m/s (ft/s) | Standard Accuracy (Calibration code B) |
|----------------------|----------------------------|--|
| 25 (1.0) to 400 (16) | V < 0.3 (1.0)              | ±1.0 mm/s                              |
|                      | 0.3 ≤ V ≤ 10 (1.0) (33)    | ±0.35% of Rate                         |

T03.EPS

Enhanced dual frequency excitation  
(Option code HF2): Standard accuracy  $\pm 1$  mm/s

**Repeatability:**

- $\pm 0.1\%$  of Rate ( $V \geq 1$  m/s (3.3 ft/s))
- $\pm 0.05\%$  of Rate  $\pm 0.5$  mm/s ( $V < 1$  m/s (3.3 ft/s))

**MODEL AND SUFFIX CODE**

Integral Flowmeter AXF:

AXF□□□□-G□□□□□-□□□□-□□□□/□

Remote Converter AXFA14:

AXFA14□-G□-□□□□

(Note1) "G" following the first dash indicates that the output is digital communication compliant with the PROFIBUS PA protocol.

**8.2 OPTIONAL SPECIFICATIONS**

For options other than below, refer to IM 01E20D01-01E and IM 01E20C02-01E  
(Optional codes C1, C2, C3, EM, G11 and G13 are unable to select).

**<Factory Setting>**


|  |   |
|--|---|
| Tag Number (Name Plate and/or stainless steel tag plate) | As specified in order   |
| Software Tag (TAG NO)                                    | In case of different Software Tag (TAG NO) is required from Tag Number above in the amplifier memory, specify at Software Tag. Default (FT2001) be set for TAG NO unless otherwise both Tag Number and Software Tag specified in order. |
| Node ADDRESS (Bus Address)                               | '0x7E' unless otherwise specified in order  |
| Output Mode (Characterization Type)                      | Always set as 'No Linearization'  |
| Calibration Range (PV SCALE) Lower/Higher Range Value    | FROWRATE SPAN of flowtube order information be set in PV SCALE. Lower Range Value be always zero.   |
| Calibration Range Unit                                   | Refer to Table below.   |
| Output Scale (OUT SCALE) Lower/Higher Range Value        | 'OUT SCALE' always be the same as 'PV SCALE'.   |

T05.EPS

### 8.3 TERMINAL CONNECTION

#### Integral Flowmeter AXF

##### Terminal configuration



##### Terminal wiring

| Terminal Symbols | Description                                    |
|------------------|--|
|                  | Functional grounding                           |
| N/-<br>L/+       | Power supply                                   |
| FB+<br>FB-       |  |
|                  | Protective grounding (Outside of the terminal) |


T06.EPS

CAUTION

Do not connect to these terminals which are marked "CAUTION Don't connect".

#### Remote Type Converter AXFA14

##### Terminal configuration



##### Terminal wiring

| Terminal Symbols   | Description               | Terminal Symbols | Description                                    |
|--------------------|---------------------------|------------------|--|
| EX1<br>EX2         | Excitation current Output |                  | Functional grounding                           |
| C                  |                           | N/-<br>L/+       | Power supply                                   |
| SA<br>A<br>B<br>SB | Flow signal input         | FB+<br>FB-       |  |
|                    |                           |                  | Protective grounding (Outside of the terminal) |

T07.EPS

# 9. PARAMETER LISTS

Note The Write Mode column indicates the mode in which the parameter is write enabled.

O/S: Write enabled in O/S mode.

MAN: Write enabled in manual mode.

AUTO: Write enabled in auto mode, manual mode, and O/S mode.

–: Read only.

## 9.1 Physical Block Parameter List (Slot 0)

| Index | Parameter                | Write Mode     | Valid Range                          | Initial Value                        | Description  |  |
|-------|--------------------------|----------------|--------------------------------------|--------------------------------------|--|--|
| 16    | BLOCK_OBJECT             | –              |                                      |                                      | Information on this block such as Block Tag, DD Revision, Execution Time etc.  |  |
| 17    | ST_REV                   | –              |                                      | 0                                    | The revision level of the static data associated with the function block. The revision value will be incremented each time a static parameter value in the block is changed.   |  |
| 18    | TAG_DESC                 | Auto           |                                      | Specified at the time of order       | The user description of the intended application of the block.   |  |
| 19    | STRATEGY                 | Auto           | 0 to 65535                           | 0                                    | The strategy field can be used to identify grouping of blocks. This data is not checked or processed by the block.   |  |
| 20    | ALERT_KEY                | Auto           | 0 to 255                             | 0                                    | The identification number of the plant unit. This information may be used in the host for sorting alarms, etc...   |  |
| 21    | TARGET_MODE              | Auto           | The permitted bit is only available. | Auto                                 | Set the Target of block mode (MODE_BLK) to Auto or O/S according to the Write Mode of the parameter to be set or changed.  |  |
| 22    | MODE_BLK<br>(DS-37)      | Actual         | –                                    | Auto                                 | The mode parameter is a structured parameter composed of the actual mode, the normal mode and the permitted mode.<br>Actual: Indicates the current operating condition.<br>Permit: Indicates the operating condition that the block is allowed to take.<br>Normal: Indicates the operating condition that the block will usually take. |  |
|       |                          | Permitted      | –                                    | O/S, Auto bit                        |  | O/S, Auto  |
|       |                          | Normal         | –                                    | The permitted bit is only available. |  | Auto   |
| 23    | ALARM_SUM<br>(DS-42)     | Current        | –                                    | Bit7 is only available.              | 0  | The current alert status, unacknowledged status, unreported status and disabled status of the alarms associated with the function block. |
|       |                          | Unacknowledged | –                                    |                                      | 0  | for future use   |
|       |                          | Unreported     | –                                    |                                      | 0  | for future use   |
|       |                          | Disabled       | –                                    |                                      | 0  | for future use   |
| 24    | SOFTWARE_REVISION        | –              |                                      |                                      | Revision-number of the software of the field device.   |  |
| 25    | HARDWARE_REVISION        | –              |                                      |                                      | Revision-number of the hardware of the field device.   |  |
| 26    | DEVICE_MAN_ID            | –              |                                      | 55 (0x37)                            | Identification code of the manufacturer of the field device.   |  |
| 27    | DEVICE_ID                | –              |                                      | AXF                                  | Manufacturer specific identification of the field device.  |  |
| 28    | DEVICE_SER_NUM           | Auto           |                                      | Serial No.                           | Serial number of the field device.   |  |
| 29    | DIAGNOSIS                | –              |                                      | 0                                    | Detailed information of the device, bitwise coded. More than one message possible at once.   |  |
| 30    | DIAGNOSIS_EXTENSION      | –              |                                      | 0                                    | Additional manufacturer-specific information of the device, bitwise coded.   |  |
| 31    | DIAGNOSIS_MASK           | –              | 0: Not supported<br>1: Supported     | 1: Supported                         | Definition of supported DIAGNOSIS information-bits.  |  |
| 32    | DIAGNOSIS_MASK_EXTENSION | –              | 0: Not supported<br>1: Supported     | 1: Supported                         | Definition of supported DIAGNOSIS_EXTENSION information-bits.  |  |
| 33    | DEVICE_CERTIFICATION     | –              | No information                       | Space                                | Not used for ADMAG AXF   |  |
| 34    | WRITE_LOCKING            | Auto           | 0: Lock<br>2457: Disabled            | 2457 (0x999)                         | If set, no writes from anywhere are allowed, except to clear WRITE_LOCKING.  |  |

T0901-1.EPS

## 9. PARAMETER LISTS

| Index | Parameter               | Write Mode | Valid Range  | Initial Value           | Description   |
|-------|-------------------------|------------|--|-------------------------|---|
| 35    | FACTORY_RESET           | Auto       | 0: No function<br>1: Factory Reset<br>2506: Warm start<br>2712: Reset Address to "126" | 0                       | Allows a manual restart to be initiated.<br>0: No function.<br>1: Resetting device to the factory default.<br>2506: Warm start of the device.<br>All parameterization remains unchanged.<br>2712: Reset the bus address to "126".   |
| 36    | DESCRIPTOR              | Auto       |  |                         | User definition text (a string) to describe the device within the application.  |
| 37    | DEVICE_MESSAGE          | Auto       |  |                         | User definable MESSAGE (a string) to describe the device within the application or in the plant.  |
| 38    | DEVICE_INSTAL_DATE      | Auto       |  |                         | Date of installation of the device.   |
| 39    | Not used                |            |  |                         |   |
| 40    | IDENT_NUMBER_SELECTOR   | Auto       | 0: PROFILE ID<br>1: device-specific ID   | 1                       | Each PROFIBUS-DP device shall have an Ident_Number provided by the PNO.   |
| 41    | HW_WRITE_PROTECTION     | –          | 0: Unprotected<br>1: Protected   | 0                       | This parameter is used in order to indicate the position of a write blocking mechanism which protects all acyclic write access to all writable parameters of a device.  |
| 42-48 | reserved by PNO         |            |  |                         |   |
| 49    | SOFT_DESC               | –          |  |                         | Yokogawa internal use.  |
| 50    | SET_ADDRESS             | O/S        | 0 to 126   | 0                       | This parameter is used in order to set or change the station address.   |
| 51    | FUNCTION_BLOCK_STATUS   | Auto       |  | 0x00...0<br>(12 digits) | This parameter is used in order to indicate the status of the function block. (0x000000000000)  |
| 52    | DIAGNOSIS_SIM_MODE      | Auto       | 0: Disabled<br>1: Enabled  | 0: Disabled             | For testing alarms and warnings can be modified. Switch to enable or disable alarm simulation.<br>When this parameter is set to enable and the hardware simulation jumper is on, all of alarms and warnings in DIAGNOSIS_EXTENSION can be modified with DIAGNOSIS_SIM_EXTENSION.            |
| 53    | DIAGNOSIS_SIM_EXTENSION | Auto       |  | 0x00...0<br>(12 digits) | Definision of supported DIAGNOSIS_EXTENSION information-bits. For testing alarms and warnings can be modified.<br>When the hardware simulation jumper is on, DIAGNOSIS_SIM_MODE is set to enable, and the bits are set to "on", the arlarms (or warnings) can be modified. (0x000000000000) |
| 54    | VIEW_PHYSICAL_BLOCK     | –          |  |                         | View objects allow the following groups of physical block parameter values to be read with one read request.<br>ST_REV, MODE_BLK, ALARM_SUM, DIAGNOSIS  |

T0901-2.EPS

## 9.2 AI Block Parameter List (Slot 1)

| Index | Parameter            | Write Mode     | Valid Range                                       | Initial Value  | Description  |  |
|-------|----------------------|----------------|---|--|--|--|
| 16    | BLOCK_OBJECT         | –              |   |  | Information on this block such as Block Tag, DD Revision, Execution Time etc.  |  |
| 17    | ST_REV               | –              |   | 0  | The revision level of the static data associated with the function block. The revision value will be incremented each time a static parameter value in the block is changed.   |  |
| 18    | TAG_DESC             | Auto           |   |  | The user description of the intended application of the block.   |  |
| 19    | STRATEGY             | Auto           | 0 to 65535  | 0  | The strategy field can be used to identify grouping of blocks. This data is not checked or processed by the block.   |  |
| 20    | ALERT_KEY            | Auto           | 0 to 255  | 0  | The identification number of the plant unit. This information may be used in the host for sorting alarms, etc.   |  |
| 21    | TARGET_MODE          | Auto           | The permitted bit is only available.              | Auto   | Set the Target of block mode (MODE_BLK) to Auto or O/S according to the Write Mode of the parameter to be set or changed.  |  |
| 22    | MODE_BLK<br>(DS-37)  | Actual         | –   | Auto   | The mode parameter is a structured parameter composed of the actual mode, the normal mode and the permitted mode.<br>Actual: Indicates the current operating condition.<br>Permit: Indicates the operating condition that the block is allowed to take.<br>Normal: Indicates the operating condition that the block will usually take. |  |
|       |                      | Permitted      | –   | O/S bit, Man bit, Auto bit                             |  | O/S, Man, Auto   |
|       |                      | Normal         | –   | Permitted bit is only available.                       |  | Auto   |
| 23    | ALARM_SUM<br>(DS-42) | Current        | –   | Bit1, 2, 3, 4, and 7 are available.                    | 0  | The current alert status, unacknowledged status, unreported status and disabled status of the alarms associated with the function block.   |
|       |                      | Unacknowledged | –   |  | 0  | for future use   |
|       |                      | Unreported     | –   |  | 0  | for future use   |
|       |                      | Disabled       | –   |  | 0  | for future use   |
| 24    | BATCH<br>(DS-67)     | BATCH_ID       | Auto  |  | 0  | This parameter is intended to be used in Batch applications in line with IEC 61512.  |
|       |                      | RUP            | Auto  |  | 0  |  |
|       |                      | OPERATION      | Auto  |  | 0  |  |
|       |                      | PHASE          | Auto  |  | 0  |  |
| 25    | Not used             |                |   |  |  |  |
| 26    | OUT<br>(DS-33)       | Value          | Man   |  | 0  | This parameter contains the current measurement value from Transducer Block or configuration adjusted engineering unit and the belonging state in AUTO MODE.<br>OUT contains the value and status set by an operator in MAN MODE.  |
|       |                      | Status         | Man   |  | 0  |  |
| 27    | PV_SCALE             | Array 1        | O/S   | 0.00001 to 32000 or 0                                  | Specified at the time of order   | Conversion of the Process Variable into percent using the high and low scale values.<br>The engineering unit of PV_SCALE high and low scale values are direct related to the PRIMARY_VALUE_UNIT of the configured Transducer Block (configured via Channel parameter).<br>The PV_SCALE high and low scale values follow the changes of the PRIMARY_VALUE_UNIT of the related Transducer Block automatically, i.e. a change of the Transducer Block PRIMARY_VALUE_Unit causes no bump at OUT from AI. |
|       |                      | Array 2        | O/S   | 0.00001 to 32000 or 0                                  | 0  |  |
| 28    | OUT_SCALE<br>(DS-68) | EU at 100%     | O/S   |  | Specified at the time of order   | Scale of the Process Variable.<br>This parameter contains the values of the lower limit and upper limit effective range, the code number of the engineering unit of Process Variable and the number of digits on the right hand side of the decimal point.   |
|       |                      | EU at 0%       | O/S   |  | 0  |  |
|       |                      | Units Index    | O/S   | 1342: %, 1355:ML/d<br>1522: ML/h<br>1521: ML/min , etc | Specified at the time of order   |  |
|       |                      | Decimal Point  | O/S   | Auto exclude<br>0, 1, 2, 3                             | 4  |  |
| 29    | LIN_TYPE             | O/S            | 0: no linearisation<br>250: Not used<br>251: None | 0  | This parameter is used in order to select the type of linearization.   |  |
| 30    | CHANNEL              | O/S            | 273   | 273  | Reference to the active Transducer Block which provides the measurement value to the Function Block.   |  |
| 31    | Not used             |                |   |  |  |  |
| 32    | PV_FTIME             | Auto           | more than 0sec                                    | 0.000  | Time constant of a single exponential filter for the PV, in seconds.   |  |

## 9. PARAMETER LISTS

| Index | Parameter            | Write Mode       | Valid Range   | Initial Value                         | Description   |
|-------|----------------------|------------------|---|---------------------------------------|---|
| 33    | FSAFE_TYPE           | Auto             | 0: Failsafe Value<br>1: Last Valid OUT Value<br>2: Wrong Calculated Value | 1: Last Valid OUT Value               | Defines reaction of device, if a fault is detected.   |
| 34    | FSAFE_VALUE          | Auto             |   | 0.0                                   | Default value for the OUT parameter, if sensor or sensor electronic fault is detected. The unit of this parameter is the same like the OUT one.   |
| 35    | ALARM_HYS            | Auto             | 0.0 to 50.0% of range   | 0.5% of range                         | Amount the PV must return within the alarm limits before the alarm condition clears. Alarm Hysteresis is expressed as engineering units of the PV span.   |
| 37    | HI_HI_LIM            | Auto             | max. Value  | +INF                                  | The setting for high high alarm in engineering units.   |
| 39    | HI_LIM               | Auto             | max. Value  | +INF                                  | The setting for high alarm in engineering units.  |
| 41    | LO_LIM               | Auto             | min. Value  | -INF                                  | The setting of the low alarm in engineering units.  |
| 43    | LO_LO_LIM            | Auto             | min. Value  | -INF                                  | The setting of the low low alarm in engineering units.  |
| 46    | HI_HI_ALM<br>(DS-39) | Unacknowledged   | –   | 0                                     | This parameter is used in order to show the state of the upper limit of alarms. This parameter contains the state of the upper limit of an alarm and the related time stamp. The time stamp expresses the time the measured variable has been equal or higher than the upper limit of the alarm.      |
|       |                      | Alarm State      | –   | 0: No alarm<br>Alarm active exclude 0 |   |
|       |                      | Time_Stamp       | –   | 0                                     |   |
|       |                      | Subcode          | –   | 0                                     |   |
|       |                      | Value            | –   | 0                                     |   |
| 47    | HI_ALM<br>(DS-39)    | Unacknowledged   | –   | 0                                     | This parameter is used in order to show the state of the upper limit of warnings. This parameter contains the state of the upper limit of a warning and the related time stamp. The time stamp expresses the time the measured variable has been equal or higher than the upper limit of the warning. |
|       |                      | Alarm State      | –   | 0: No alarm<br>Alarm active exclude 0 |   |
|       |                      | Time_Stamp       | –   | 0                                     |   |
|       |                      | Subcode          | –   | 0                                     |   |
|       |                      | Value            | –   | 0                                     |   |
| 48    | LO_ALM<br>(DS-39)    | Unacknowledged   | –   | 0                                     | This parameter is used in order to show the state of the lower limit of warnings. This parameter contains the state of the lower limit of a warning and the related time stamp. The time stamp expresses the time the measured variable has been equal or lower than the lower limit of the warning.  |
|       |                      | Alarm State      | –   | 0: No alarm<br>Alarm active exclude 0 |   |
|       |                      | Time_Stamp       | –   | 0                                     |   |
|       |                      | Subcode          | –   | 0                                     |   |
|       |                      | Value            | –   | 0                                     |   |
| 49    | LO_LO_ALM<br>(DS-39) | Unacknowledged   | –   | 0                                     | This parameter is used in order to show the state of the lower limit of alarms. This parameter contains the state of the lower limit of an alarm and the related time stamp. The time stamp expresses the time the measured variable has been equal or lower than the lower limit of the alarm.       |
|       |                      | Alarm State      | –   | 0: No alarm<br>Alarm active exclude 0 |   |
|       |                      | Time_Stamp       | –   | 0                                     |   |
|       |                      | Subcode          | –   | 0                                     |   |
|       |                      | Value            | –   | 0                                     |   |
| 50    | SIMULATE<br>(DS-50)  | Simulate_Status  | Auto  | 0                                     | For commissioning and test purposes the input value from the Transducer Block in the Analog Input Function Block AI-FB can be modified. That means that the Transducer and AI-FB will be disconnected.  |
|       |                      | Simulate_Value   | Auto  | 0                                     |   |
|       |                      | Simulate_Enabled | Auto  | 0: Disabled,<br>Enable exclude 0      |   |
| 51    | OUT_UNIT_TEXT        | Auto             | Character   |                                       | If a specific unit of OUT parameter is not in the code list the user has the possibility to write the specific text in this parameter. The unit code is then equal "textual unit definition".   |
| 52-60 | reserved by PNO      |                  |   |                                       |   |
| 61    | VELOCITY_CHECK       | –                | 0 to 99.999   | 0                                     | This parameter is used in order to display the span velocity corresponding to PV_SCALE.EU100 (EU0).   |
| 62    | VIEW_ANALOG_INPUT_FB | –                |   |                                       | View objects allow the following groups of physical block parameter values to be read with one read request.<br>ST_REV, MODE_BLK, ALARM_SUM, OUT  |



### 9.3 Transducer Block Parameter List (Slot 7)

| Index | Parameter            | Write Mode     | Valid Range  | Initial Value                                      | Description  |  |
|-------|----------------------|----------------|--|--|--|--|
| 16    | BLOCK_OBJECT (DS-32) |                |  |  | Information on this block such as Block Tag, DD Revision, Execution Time etc.  |  |
| 17    | ST_REV               | –              |  | 0  | The revision level of the static data associated with the function block. The revision value will be incremented each time a static parameter value in the block is changed.   |  |
| 18    | TAG_DESC             | Auto           |  |  | The user description of the intended application of the block.   |  |
| 19    | STRATEGY             | Auto           | 0 to 65535   | 0  | The strategy field can be used to identify grouping of blocks. This data is not checked or processed by the block.   |  |
| 20    | ALERT_KEY            | Auto           | 0 to 255   | 0  | The identification number of the plant unit. This information may be used in the host for sorting alarms, etc.   |  |
| 21    | TARGET_MODE          | Auto           | The permitted bit is only available.                             | 0x08: Auto   | Set the Target of block mode (MODE_BLK) to Auto or O/S according to the Write Mode of the parameter to be set or changed.  |  |
| 22    | MODE_BLK (DS-37)     | Actual         | –  | 0x08: Auto   | The mode parameter is a structured parameter composed of the actual mode, the normal mode and the permitted mode.<br>Actual: Indicates the current operating condition.<br>Permit: Indicates the operating condition that the block is allowed to take.<br>Normal: Indicates the operating condition that the block will usually take.   |  |
|       |                      | Permitted      | –  | O/S bit, Auto bit<br>0x80: O/S,<br>0x08: Auto      |  |  |
|       |                      | Normal         | –  | The permitted bit is only available.<br>0x08: Auto |  |  |
| 23    | ALARM_SUM (DS-42)    | Current        | –  | Bit7 is only available.                            | 0  | The current alert status, unacknowledged status, unreported status and disabled status of the alarms associated with the function block. |
|       |                      | Unacknowledged | –  |  | 0  | for future use   |
|       |                      | Unreported     | –  |  | 0  | for future use   |
|       |                      | Disabled       | –  |  | 0  | for future use   |
| 24    | CALIBR_FACTOR        | O/S            | 0.01 to 3.0000   | 1.0000   | Gain compensation value for the detector, so that flow indication is accurate.<br>This parameter means the meter factor of low frequency side (LOW_MF).<br>This parameter must not be downloaded by the operator.  |  |
| 25    | LOW_FLOW_CUTOFF      | O/S            | The value which corresponds to 0 to 10% of PV_SPAN is permitted. | 0  | Set the low cut range corresponding 0 to 10 % of the large absolute value between PV_SCALE.Array1 and PV_SCALE.Array2.<br>This value must be set to the lower switching point because this function has a hysteresis.  |  |
| 26    | MEASUREMENT_MODE     | O/S            | 0: Unidirectional<br>1: Bidirectional                            | 0: Unidirectional                                  | Set the mode of the flow measurement, either unidirectional or bidirectional.  |  |
| 27    | FLOW_DIRECTION       | O/S            | 0: Positive<br>1: Negative                                       | 0: Positive  | Assign an arbitrary positive or negative sign to the measured PV value.  |  |
| 28    | ZERO_POINT           | O/S            | -999.9 to 999.9  | 0.000  | This function shows the current zero point compensation value for the sensor.<br>This parameter is used to display the results obtained from ZERO_POINT_ADJUST . Specifically, the correction values displayed, and it is also possible to directly enter correction values.<br>This parameter must not be downloaded by the operator.   |  |
| 29    | ZERO_POINT_ADJUST    | Auto           | 0: Cancel<br>1: Execute  | 0: Cancel  | This parameter executes the automatic zero adjustment function: If "Execute" is selected, this function will be started.<br>"Now Auto Zero Executing..." is indicated while the Auto Zero function is being carried out and After finishing the adjustment, this parameter is set to "Cancel". The result of the automatic zero adjustment is confirmed using ZERO_POINT , and if the result exceeds the rated value, the warning "82: Auto Zero Wng" will be displayed. |  |
| 30    | ZERO_POINT_UNIT      | O/S            | 1062: mm/s   | 1062: mm/s   | This parameter is used in order to select the unit for zero point.   |  |
| 31    | NOMINAL_SIZE         | O/S            | 0.99 to 3000.10 (mm)<br>0.01 to 120.10 (inch)                    | Specified at the time of order                     | This parameter is used in order to set the size (diameter) of the sensor (flow tube).<br>If the setting value exceeds the valid range, the warning "72:Size Set Err" will be displayed.  |  |

T0903-1.EPS

## 9. PARAMETER LISTS

| Index | Parameter             | Write Mode | Valid Range   | Initial Value                  | Description  |
|-------|-----------------------|------------|---|--------------------------------|--|
| 32    | NOMINAL_SIZE_UNITS    | O/S        | 1013: mm<br>1019: inch  | Specified at the time of order | This parameter is used in order to select the unit of size (diameter) of the sensor (flow tube).   |
| 33    | VOLUME_FLOW (DS-33)   | Value      | –   | 0                              | Indicates the current measured value and status as the primary value (volumetric flow). This parameter is input to the AI Function Block and the Totalizer Function Block.   |
|       |                       | Status     | –   | Good                           |  |
| 34    | VOLUME_FLOW_UNITS     | O/S        | See the "Unit" sheet.   | Specified at the time of order | This parameter is used in order to select the unit for VOLUME_FLOW, VOLUME_FLOW_LO_LIMIT and VOLUME_FLOW_HI_LIMIT parameters.  |
| 35    | VOLUME_FLOW_LO_LIMIT  | O/S        | -11.88 to 11.88 m/s<br>or -22.68 to 22.68 m/s<br>The value depends on a volume flow unit.         | Specified at the time of order | This parameter is used in order to enter the lower range value for volumetric flow.  |
| 36    | VOLUME_FLOW_HI_LIMIT  | O/S        | -11.88 to 11.88 m/s<br>or -22.68 to 22.68 m/s<br>The value depends on a volume flow unit.         | Specified at the time of order | This parameter is used in order to enter the upper range value for volumetric flow.  |
| 57    | SAMPLING_FREQ (DS-33) | Value      | –   | 75                             | This parameter is used in order to indicates the field frequency of the sensor (Sensor specific, must not be downloaded).  |
|       |                       | Status     | –   | Good                           |  |
| 58    | SAMPLING_FREQ_UNITS   | O/S        | 1077: Hz  | 1077: Hz                       | This parameter is used in order to selected unit code for SAMPLING_FREQ parameter.   |
| 59-68 | reserved by PNO       |            |   |                                |  |
| 69    | VOLUME_FLOW_FTIME     | O/S        | 0.1 to 200.0  | 3.0                            | Setting of the damping time constant to VOLUME_FLOW. The output to reach 63.2% from 0%.  |
| 70    | DUAL_FREQUENCY_MODE   | O/S        | 0: Standerd DF<br>1: Enhanced DF  | 0: Standard DF                 | Selection of excitation mode. This parameter is effective when FLOW_TUBE is "ADMAG AXF" and NOMINAL_SIZE is in between 25mm to 200mm. Outside the field of that condition, the warning "71:Meas Mod Set" will be displayed.  |
| 71    | LOW_MF                | O/S        | 0.01 to 3.0000  | 1.0000                         | This parameter is used in order to set the low-frequency meter factor. This setting is linked with that of parameter CALIBR_FACTOR.  |
| 72    | HIGH_MF               | O/S        | 0.01 to 3.0000  | 1.0000                         | This parameter is used in order to set the high-frequency meter factor.  |
| 73    | LOW_MF_EDF            | O/S        | 0 to 3.0000   | 1.0000                         | This parameter is used in order to set the low-frequency meter factor as required when Enhanced DF (i.e., enhanced dual frequency excitation) is selected. If "Standard DF" has been selected for Measure_Mode, neither Low_MF(EDF) nor High_MF(EDF) is displayed. |
| 74    | HIGH_MF_EDF           | O/S        | 0 to 3.0000   | 1.0000                         | This parameter is used in order to set the high-frequency meter factor as required when Enhanced DF (i.e., enhanced dual frequency excitation) is selected.  |
| 75    | SELECT_FLOW_TUBE      | O/S        | 0: ADMAG AXF<br>1: ADMAG<br>2: ADMAG AE<br>3: ADMAG SE<br>4: YEW MAG<br>5: Calibrator<br>6: Other | 0: ADMAG AXF                   | This parameter is used in order to set the types of flow tube. When combining this product with an AXF Remote Flow tube, "ADMAG AXF" should be selected.   |
| 76    | DENSITY_UNIT          | O/S        | 1097: kg/m <sup>3</sup><br>1108: lb/gal<br>1107: lb/cf  | 1097: kg/m <sup>3</sup>        | This parameter selects the units for density as required when making settings using Mass_Density.  |

T0903-2.EPS

9. PARAMETER LISTS

| Index | Parameter                | Write Mode | Valid Range                              | Initial Value             | Description  |   |
|-------|--------------------------|------------|--|---------------------------|--|---|
| 77    | MASS_FLOW_DENSITY        | O/S        | 0 to 32000                               | 0                         | Setting of the density for mass-flow rate. This parameter is necessary in situations where t, kg, g, klb or lb has been selected as the mass unit in VOLUME_FLOW_UNITS. If a mass unit is selected in VOLUME_FLOW_UNITS and a value of 0 is set for this parameter, the setting alarm "57: Density SetErr." will be displayed. In such a case, ensure that the density is set correctly. |   |
| 78    | LIMSW_1_VALUE_D (DS-34)  | Value      | –  | 0: not set, set exclude 0 | 0  | This parameter is used in order to indicate the current input value selected LIMSW_1_TARGET. If the target alarm occurred the value is set 1. Refere to LIMSW_1_TARGET. |
|       |                          | Status     | –  |                           | Good   |   |
| 79    | LIMSW_1_TARGET           | O/S        | 0: Volume Flow Value                     | 0                         | This parameter selects the input channel used to LIMSW_1_VALUE_D.  |   |
| 80    | LIMSW_1_SETPOINT         | O/S        |  | -10                       | Sets the threshold of limitswitch 1. If the value of LIMSW_1_ACT_DIRECTION is HIGH LIMIT, limit switch 1 turns ON when LIMSW_1_TARGET has gone beyond LIMSW_1_SETPOINT. If the value of LIMSW_1_ACT_DIRECTION is LO LIMIT, limit switch 1 turns ON when LIMSW_1_TARGET has gone below LIMSW_1_SETPOINT. The unit set in LIMSW_1_UNIT applies.  |   |
| 81    | LIMSW_1_ACT_DIRECTION    | O/S        | 0: Low Limit<br>1: High Limit            | 0: Low Limit              | Selects the direction of the limit switch 1's actions:<br>1: LO LIMIT (Low-limit switch)<br>2: HIGH LIMIT (high-limit switch)  |   |
| 82    | LIMSW_1_HYSTERESIS       | O/S        | 0 or larger.                             | 0.0                       | Sets the hysteresis of limit switch 1 to be applied for resetting the LIMSW_1_VALUE_D to OFF after LIMSW_1_TARGET went beyond LIMSW_1_SETPOINT and LIMSW_1_VALUE_D turned ON (when used as a high-limit switch), or after LIMSW_1_TARGET went below LIMSW_1_SETPOINT and LIMSW_1_VALUE_D turned ON (when used as a low-limit switch).  |   |
| 83    | LIMSW_1_UNIT             | –          |  | 1349: m³/h                | Indicate the unit set in LIMSW_1_TARGET.   |   |
| 84    | LIMSW_2_VALUE_D (DS-34)  | Value      | –  | 0: not set, set exclude 0 | 0  | This parameter is used in order to indicate the current input value selected LIMSW_2_TARGET. If the target alarm occurred the value is set 1. Refere to LIMSW_2_TARGET. |
|       |                          | Status     | –  |                           | Good   |   |
| 85    | LIMSW_2_TARGET           | O/S        | 0: Volume Flow Value                     | 0                         | Select the input channel to LIMSW_2_VALUE_D.   |   |
| 86    | LIMSW_2_SETPOINT         | O/S        |  | 10                        | Sets the threshold of limitswitch 2. If the value of LIMSW_2_ACT_DIRECTION is HIGH LIMIT, limit switch 2 turns ON when LIMSW_2_TARGET has gone beyond LIMSW_2_SETPOINT. If the value of LIMSW_2_ACT_DIRECTION is LO LIMIT, limit switch 2 turns ON when LIMSW_2_TARGET has gone below LIMSW_2_SETPOINT. The unit set in LIMSW_2_UNIT applies.  |   |
| 87    | LIMSW_2_ACT_DIRECTION    | O/S        | 0: Low Limit<br>1: High Limit            | 1: High Limit             | Selects the direction of the limit switch 2's actions<br>0: LO LIMIT (Low-limit switch)<br>1: HIGH LIMIT (high-limit switch)   |   |
| 88    | LIMSW_2_HYSTERESIS       | O/S        | 0 or larger.                             | 0                         | Sets the hysteresis of limit switch 2 to be applied for resetting the LIMSW_2_VALUE_D to OFF after LIMSW_2_TARGET went beyond LIMSW_2_SETPOINT and LIMSW_2_VALUE_D turned ON (when used as a high-limit switch), or after LIMSW_2_TARGET went below LIMSW_2_SETPOINT and LIMSW_2_VALUE_D turned ON (when used as a low-limit switch).  |   |
| 89    | LIMSW_2_UNIT             | –          |  | 1349: m³/h                | Indicate the unit set in LIMSW_2_TARGET.   |   |
| 90    | SWITCH_1_VALUE_D (DS-34) | Value      | –  | 0: not set, set exclude 0 | 0  | Indicate the value of switch 1, which switches ON and OFF depending on the digital value of the target input parameter selected in SWITCH_1_TARGET.                     |
|       |                          | Status     | –  |                           | Good   |   |
| 91    | SWITCH_1_TARGET          | O/S        | 0: Adhesion Alarm<br>1: Adhesion Warning | 0: Adhesion Alarm         | This parameter selects the input channel used to LIMSW_1_VALUE_D.  |   |

T0903-3.EPS

## 9. PARAMETER LISTS

| Index | Parameter                       |        | Write Mode | Valid Range                                       | Initial Value       | Description  |
|-------|---------------------------------|--------|------------|---|---------------------|--|
| 92    | SWITCH_2_VALUE_D<br>(DS-34)     | Value  | –          | 0: not set,<br>set exclude 0                      | 0                   | Indicate the value of switch 2, which switches ON and OFF depending on the digital value of the target input parameter selected in SWITCH_2_TARGET.  |
|       |                                 | Status | –          |   | Good                |  |
| 93    | SWITCH_2_TARGET                 |        | O/S        | 0: Adhesion Alarm<br>1: Adhesion Warning          | 1: Adhesion Warning | This parameter selects the input channel used to LIMSW_2_VALUE_D.  |
| 94    | SIGNAL_LOCK                     |        | Auto       | 0: Unlock<br>1: Lock                              | 0: Unlock           | This parameter executes the signal lock function: If "Lock" is selected, this function will be started.  |
| 95    | ALARM_PERFORM                   |        | O/S        | 0x00000000 to<br>0x003F003F                       | 0x00010033          | This parameter masks Alarm/Warning. By setting "0" to each bit, corresponding Alarm/Warning are cleared. When masked the corresponding bit of DEVICE_STATUS becomes OFF and no alarm is displayed on LCD, and also becomes out of scope of Primary value status, ED_ERROR setting. Valid range is 0x00000000 to 0x003F003F.  |
| 96    | SIMULATE_MODE                   |        | Auto       | 0: Off<br>1: Volume Flow                          | 0: Off              | For commissioning and test purposes the input value from sensor value in the Transducer Block. TB can be modified when the hardware simulation jumper is on. It means that the sensor value and TB will be disconnected.   |
| 97    | SIMULATE_TYPE                   |        | Auto       | 0: Fixed<br>1: 2 points<br>2: 3 points<br>3: Ramp | 0: Fixed            | Select the type of the simulated value.  |
| 98    | SIMULATE_VOLUME_FLOW<br>(DS-33) | Value  | Auto       |   | 0                   | Set the fixed value for simulating the volume flow value when SIMULATE_TYPE is selected "0: Fixed". When SIMULATE_MODE is selected "0: Off", SIMULATE_VOLUME_FLOW.Value has the same value as the current value from the sensor. (That is, the sensor value is copied to this parameter internally at each TB execution.) And SIMULATE_VOLUME_FLOW.Status has the same value as VOLUME_FLOW_VALUE.Status. When SIMULATE_TYPE is not selected "0: Fixed", SIMULATE_VOLUME_FLOW shows the current simulated value. |
|       |                                 | Status | Auto       |   | Good                |  |
| 99    | SIMULATE_UP_VALUE               |        | Auto       | Except<br>SIMULATE_LO_VALUE                       | 0                   | Set the simulated upper value when SIMULATE_TYPE is selected "1: 2 points", "2: 3 points", or "Ramp".  |
| 100   | SIMULATE_LO_VALUE               |        | Auto       | Except<br>SIMULATE_UP_VALUE                       | 0                   | Set the simulated lower value when SIMULATE_TYPE is selected "1: 2 points", "2: 3 points", or "3: Ramp".   |
| 101   | SIMULATE_TIME                   |        | Auto       | Except 0  | 30                  | Show the time to maintain a constant value when SIMULATE_TYPE is selected "1: 2 points" or "2: 3 points". Show the time to maintain a constant change, when SIMULATE_TYPE is selected "3: Ramp".   |
| 102   | OPERATION_TIME                  |        | –          | 0D 00:00 to<br>99999D 23:59                       | 0D 00:00            | This parameter is used to display the operation time. For example, "1D23:45" indicates an operation time of 1 day, 23 hours, and 45 minutes.   |
| 103   | ALM_RECORD1                     |        | –          | 0 to 14   | 0                   | This parameter is used to display the most-recent alarm.   |
| 104   | ALM_RECORD_TIME1                |        | –          | 0D 00:00 to<br>99999D 23:59                       | 0D 00:00            | This parameter is used to display the operation time at which the alarm indicated by Alm_Record1 was occurred. For example, "1D23:45" indicates that an alarm was triggered at the operation time of 1 day, 23 hours, and 45 minutes.  |
| 105   | ALM_RECORD2                     |        | –          | 0 to 14   | 0                   | This parameter is used to display the second most recent alarm.  |
| 106   | ALM_RECORD_TIME2                |        | –          | 0D 00:00 to<br>99999D 23:59                       | 0D 00:00            | This parameter is used to display the operation time at which the alarm indicated by Alm_Record2 was occurred.   |
| 107   | ALM_RECORD3                     |        | –          | 0 to 14   | 0                   | This parameter is used to display the third most recent alarm.   |
| 108   | ALM_RECORD_TIME3                |        | –          | 0D 00:00 to<br>99999D 23:59                       | 0D 00:00            | This parameter is used to display the operation time at which the alarm indicated by Alm_Record3 was occurred.   |
| 109   | ALM_RECORD4                     |        | –          | 0 to 14   | 0                   | This parameter is used to display the fourth most recent alarm.  |
| 110   | ALM_RECORD_TIME4                |        | –          | 0D 00:00 to<br>99999D 23:59                       | 0D 00:00            | This parameter is used to display the operation time at which the alarm indicated by Alm_Record4 was occurred.   |

T0903-4.EPS

## 9. PARAMETER LISTS

| Index | Parameter         | Write Mode | Valid Range   | Initial Value | Description   |
|-------|-------------------|------------|---|---------------|---|
| 111   | DISPLAY_SELECT1   | Auto       | 0 to 4  | 1: Out Value  | This parameter is used in order to set the LCD display mode.  |
| 112   | DISPLAY_SELECT2   | Auto       | 0 to 9  | 0: Off        |   |
| 113   | DISPLAY_SELECT3   | Auto       | 0 to 9  | 0: Off        |   |
| 114   | DISPLAY_CYCLE     | Auto       | 0: 200ms<br>1: 400ms<br>2: 1s,<br>3: 2s,<br>4: 4s,<br>5: 8s | 1: 400ms      | This parameter is used in order to set the renewal cycle of LCD display.<br>Renewal cycle: 200 msec "DISPLAY_CYCLE"   |
| 115   | LANGUAGE          | Auto       | 0: English  | 0: English    |   |
| 116   | RATE_LIMIT        | O/S        | 0 to 10   | 5             | This parameter is used in order to set the rate limit value.  |
| 117   | DEAD_TIME         | O/S        | 0 to 15   | 0             | This parameter is used in order to set the time for application of the rate limit, and if a value of 0 is set, the rate limit function will be terminated.  |
| 118   | PULSING_FLOW      | O/S        | 0: No<br>1: Yes   | 0: No         | This parameter is used in order to set the pulsing flow support.  |
| 119   | POWER_SYNCH       | O/S        | 0: No<br>1: Yes   | 1: Yes        | This parameter is used in order to indicate whether or not the internal frequency is to be synchronized with that of the power supply.  |
| 120   | POWER_FREQUENCY   | O/S        | 47.00 to 63.00  | 50            | This parameter is used in order to set the power frequency.   |
| 121   | SOFTWARE_REV_NO   | –          |   |               | This parameter is used to display the software revision number.   |
| 122   | ADHESION_CHECK    | O/S        | 0: No<br>1: Yes   | 0: No         | This parameter selects whether or not the adhesion diagnostic function will be carried out.<br><b>NOTE</b><br>If the judgment value for Level 3 is exceeded, a warning is displayed; and if the value for Level 4 is exceeded, an alarm is displayed. |
| 123   | ADHESION_LEVEL1   | O/S        | 0.00 to 100.00  | 0.10          | This parameter is used in order to set the resistance value for judgment of Level 1.  |
| 124   | ADHESION_LEVEL2   | O/S        | 0.00 to 100.00  | 0.50          | This parameter is used in order to set the resistance value for judgment of Level 2.  |
| 125   | ADHESION_LEVEL3   | O/S        | 0.00 to 100.00  | 1.00          | This parameter is used in order to set the resistance value for judgment of Level 3.  |
| 126   | ADHESION_LEVEL4   | O/S        | 0.00 to 100.00  | 3.00          | This parameter is used in order to set the resistance value for judgment of Level 4.  |
| 127   | ADH_MEASURE_VALUE | –          | 0.00 to 1000.00   | –             | This parameter displays the value measured using the adhesion diagnostic function.  |

T0903-5.EPS

## 9.4 Totalizer Block Parameter List (TOT1: Slot2, TOT2: Slot3, TOT3: Slot4)

| Index | Parameter            | Write Mode     | Valid Range  | Initial Value                        | Description  |  |
|-------|----------------------|----------------|--|--------------------------------------|--|--|
| 16    | BLOCK_OBJECT (DS-32) | –              |  |                                      | Information on this block such as Block Tag, DD Revision, Execution Time etc.  |  |
| 17    | ST_REV               | –              |  | 0                                    | The revision level of the static data associated with the function block. The revision value will be incremented each time a static parameter value in the block is changed.   |  |
| 18    | TAG_DESC             | Auto           |  | Space                                | The user description of the intended application of the block.   |  |
| 19    | STRATEGY             | Auto           | 0 to 65535   | 0                                    | The strategy field can be used to identify grouping of blocks. This data is not checked or processed by the block.   |  |
| 20    | ALERT_KEY            | Auto           | 0 to 255   | 0                                    | The identification number of the plant unit. This information may be used in the host for sorting alarms, etc.   |  |
| 21    | TARGET_MODE          | Auto           | The permitted bit is only available.   | Auto                                 | Set the Target Auto, Man or O/S according to the Write Mode of the parameter to be set or changed.   |  |
| 22    | MODE_BLK (DS-37)     | Actual         | –  | Auto                                 | The mode parameter is a structured parameter composed of the actual mode, the normal mode and the permitted mode.<br>Actual: Indicates the current operating condition.<br>Permit: Indicates the operating condition that the block is allowed to take.<br>Normal: Indicates the operating condition that the block will usually take. |  |
|       |                      | Permitted      | –  | O/S bit, Man bit, Auto bit           |  | O/S, Man, Auto   |
|       |                      | Normal         | –  | The permitted bit is only available. |  | Auto   |
| 23    | ALARM_SUM (DS-42)    | Current        | –  | Bit1, 2, 3, 4, 7 are available.      | 0  | The current alert status, unacknowledged status, unreported status and disabled status of the alarms associated with the function block.   |
|       |                      | Unacknowledged | –  |                                      | 0  | for future use   |
|       |                      | Unreported     | –  |                                      | 0  | for future use   |
|       |                      | Disabled       | –  |                                      | 0  | for future use   |
| 24    | BATCH (DS-67)        | BATCH_ID       | Auto   |                                      | 0  | This parameter is intended to be used in Batch applications in line with IEC 61512.  |
|       |                      | RUP            | Auto   |                                      | 0  |  |
|       |                      | OPERATION      | Auto   |                                      | 0  |  |
|       |                      | PHASE          | Auto   |                                      | 0  |  |
| 25    | Not used             |                |  |                                      |  |  |
| 26    | TOTAL (DS-33)        | Value          | Man  |                                      | 0  | This parameter contains the integrated quantity of the rate parameter provided by CHANNEL and the associated status.   |
|       |                      | Status         | Man  |                                      | 0  |  |
| 27    | UNIT_TOT             | O/S            | 1549:MI, 1034:m <sup>3</sup> , 1517:kL, 1041:hL, 1038:L, 1040:mL, 1035:dm <sup>3</sup> , 1036:cm <sup>3</sup> , 1092:t, 1091:Mg, 1088:kg, 1089:g, 1090:mg, 1043:CF, 1048:gallon, 1051:bbl 1641:bbl (US federal), 1094:lb | 1034:m <sup>3</sup>                  |  | This parameter is used in order to set the unit of the totalized quantity.<br>The unit must be compatible to VOLUME_FLOW_UNITS.<br>Set UNIT_TOT to a mass unit when a mass unit is set into VOLUME_FLOW_UNITS.<br>If the mismatch units are set, the alarm of "120:Total1 Unit Set Err", "121:Total2 Unit Set Err" or "122:Total3 Unit Set Err" will be displayed. |
| 28    | CHANNEL              | O/S            | 273  | 273                                  |  | Reference to the active Transducer Block which provides the measurement value to the Function Block.   |
| 29    | SET_TOT              | Auto           | 0: TOTALIZE<br>1: RESET<br>2: PRESET   | 0: TOTALIZE                          |  | This parameter is used in order to assign the condition to the totalizer.  |
| 30    | MODE_TOT             | O/S            | 0: BALANCED<br>1: POS_ONLY<br>2: NEG_ONLY<br>3: HOLD   | 0: BALANCED                          |  | This parameter is used in order to define how the totalizer counts.  |
| 31    | FAIL_TOT             | O/S            | 0: RUN<br>1: HOLD<br>2: MEMORY   | 0: RUN                               |  | This parameter is used in order to define error response in the event of the device error or bad measured value.   |

## 9. PARAMETER LISTS

| Index | Parameter         | Write Mode       | Valid Range            | Initial Value                            | Description  |  |
|-------|-------------------|------------------|------------------------|--|--|--|
| 32    | PRESET_TOT        | Auto             | -99999999 to +99999999 | 0.000                                    | This parameter is used in order to define the starting value to the totalizer.   |  |
| 33    | ALARM_HYS         | Auto             | 0 or larger            | 0.000                                    | Amount the PV must return within the alarm limits before the alarm condition clears. Alarm Hysteresis is expressed as a percent of the PV span.  |  |
| 34    | HI_HI_LIM         | Auto             | max. Value             | +INF                                     | The setting for high high alarm in engineering units.  |  |
| 35    | HI_LIM            | Auto             | max. Value             | +INF                                     | The setting for high alarm in engineering units.   |  |
| 36    | LO_LIM            | Auto             | min. Value             | -INF                                     | The setting of the low alarm in engineering units.   |  |
| 37    | LO_LO_LIM         | Auto             | min. Value             | -INF                                     | The setting of the low low alarm in engineering units.   |  |
| 38    | HI_HI_ALM (DS-39) | Unacknowledged   | –                      | 0  | This parameter is used in order to set the state of the upper limit of alarms.<br>This parameter contains the state of the upper limit of an alarm and the related time stamp. The time stamp expresses the time the measured variable has been equal or higher than the upper limit of the alarm.                 |  |
|       |                   | Alarm State      | –                      | 0: No alarm<br>Alarm active<br>exclude 0 |  | 0  |
|       |                   | Time_Stamp       | –                      |  |  | 0  |
|       |                   | Subcode          | –                      |  |  | 0  |
|       |                   | Value            | –                      |  |  | 0  |
| 39    | HI_ALM (DS-39)    | Unacknowledged   | –                      | 0  | This parameter is used in order to set the state of the upper limit of warnings.<br>This parameter contains the state of the upper limit of a warning and the related time stamp. The time stamp expresses the time the measured variable has been equal or higher than the upper limit of the warning.            |  |
|       |                   | Alarm State      | –                      | 0: No alarm<br>Alarm active<br>exclude 0 |  | 0  |
|       |                   | Time_Stamp       | –                      |  |  | 0  |
|       |                   | Subcode          | –                      |  |  | 0  |
|       |                   | Value            | –                      |  |  | 0  |
| 40    | LO_ALM (DS-39)    | Unacknowledged   | –                      | 0  | This parameter is used in order to set the state of the lower limit of warnings.<br>This parameter contains the state of the lower limit of a warning and the related time stamp. The time stamp expresses the time at which the measured variable has been equal to or lower than the lower limit of the warning. |  |
|       |                   | Alarm State      | –                      | 0: No alarm<br>Alarm active<br>exclude 0 |  | 0  |
|       |                   | Time_Stamp       | –                      |  |  | 0  |
|       |                   | Subcode          | –                      |  |  | 0  |
|       |                   | Value            | –                      |  |  | 0  |
| 41    | LO_LO_ALM (DS-39) | Unacknowledged   | –                      | 0  | This parameter is used in order to set the state of the lower limit of alarms.<br>This parameter contains the state of the lower limit of an alarm and the related time stamp. The time stamp expresses the time at which the measured variable has been equal to or lower than the lower limit of the alarm.      |  |
|       |                   | Alarm State      | –                      | 0:No alarm<br>Alarm active<br>exclude 0  |  | 0  |
|       |                   | Time_Stamp       | –                      |  |  | 0  |
|       |                   | Subcode          | –                      |  |  | 0  |
|       |                   | Value            | –                      |  |  | 0  |
| 42-51 | reserved by PNO   |                  |                        |  |  |  |
| 52    | SIMULATE (DS-50)  | Simulate_Status  | Auto                   |  | 0  | For commissioning and test purposes the input value from the Transducer Block in the Totalizer Function Block, TOT-FB can be modified when the hardware simulation jumper is on. That means that the Transducer and TOT-FB will be disconnected. |
|       |                   | Simulate_Value   | Auto                   |  | 0  |  |
|       |                   | Simulate_Enabled | Auto                   | 0: Disabled,<br>Enable exclude 0         | 0: Disabled  |  |
| 53    | VIEW_TOTALIZER_FB | –                |                        |  | View objects allow the following groups of physical block parameter values to be read with one read request.<br>ST_REV, MODE_BLK, ALARM_SUM, TOTAL   |  |

T0904-2.EPS

## 9.5 DI Block Parameter List (DI1: Slot5, DI2: Slot6)

| Index | Parameter               | Write Mode      | Valid Range   | Initial Value                              | Description  |  |              |
|-------|-------------------------|-----------------|---|--|--|--|--------------|
| 16    | BLOCK_OBJECT<br>(DS-32) | –               |   |  | Information on this block such as Block Tag, DD Revision, Execution Time etc.  |  |              |
| 17    | ST_REV                  | –               |   | 0  | The revision level of the static data associated with the function block. The revision value will be incremented each time a static parameter value in the block is changed. |  |              |
| 18    | TAG_DESC                | Auto            |   | Space                                      | The user description of the intended application of the block.   |  |              |
| 19    | STRATEGY                | Auto            | 0 to 65535  | 0  | The strategy field can be used to identify grouping of blocks. This data is not checked or processed by the block.   |  |              |
| 20    | ALERT_KEY               | Auto            | 0 to 255  | 0  | The identification number of the plant unit. This information may be used in the host for sorting alarms, etc.   |  |              |
| 21    | TARGET_MODE             | Auto            | The permitted bit is only available.                                | Auto                                       | Set the Target of block mode (MODE_BLK) to Auto, Man or O/S according to the Write Mode of the parameter to be set or changed.   |  |              |
| 22    | MODE_BLK<br>(DS-37)     | Actual          | –   |  | Auto   | The mode parameter is a structured parameter composed of the actual mode, the normal mode and the permitted mode.<br>Actual: Indicates the current operating condition.<br>Permit: Indicates the operating condition that the block is allowed to take.<br>Normal: Indicates the operating condition that the block will usually take. |              |
|       |                         | Permitted       | –   | O/S bit, Man bit, Auto bit                 |  |  | O/S,Man,Auto |
|       |                         | Normal          | –   | The permitted bit is only available.       |  |  | Auto         |
| 23    | ALARM_SUM<br>(DS-42)    | Current         | –   | Bit0, Bit7 are available.                  | 0  | The current alert status, unacknowledged status, unreported status and disabled status of the alarms associated with the function block.   |              |
|       |                         | Unacknowledged  | –   |  | 0  | for future use   |              |
|       |                         | Unreported      | –   |  | 0  | for future use   |              |
|       |                         | Disabled        | –   |  | 0  | for future use   |              |
| 24    | BATCH<br>(DS-67)        | BATCH_ID        | Auto  |  | 0  | This parameter is intended to be used in Batch applications in line with IEC 61512 .   |              |
|       |                         | RUP             | Auto  |  | 0  |  |              |
|       |                         | OPERATION       | Auto  |  | 0  |  |              |
|       |                         | PHASE           | Auto  |  | 0  |  |              |
| 25    | Not used                |                 |   |  |  |  |              |
| 26    | OUT_D<br>(DS-34)        | Value           | Man   |  | 0  | This parameter contains the current measurement value from Transducer Block or configuration adjusted engineering unit and the belonging state in AUTO MODE.<br>OUT contains the value and status set by an operator in MAN MODE.  |              |
|       |                         | Status          | Man   |  | 0  |  |              |
| 30    | CHANNEL                 | O/S             | 318, 324, 330, 332  | DI1: 0x013E (1, 62),<br>DI2: 0x0144 (1,68) |  | Reference to the active Transducer Block which provides the measurement value to the Function Block.<br>318: LIMSW_1_VALUE_D<br>324: LIMSW_2_VALUE_D<br>330: SWITCH_1_VALUE_D<br>332: SWITCH_2_VALUE_D   |              |
| 31    | INVERT                  | Auto            | 0: not inverted<br>1: invert  | 0: not inverted                            |  | Indicates whether the input value of the PV_D should be logically inverted before it is stored in the OUT_D.   |              |
| 36    | FSAFE_TYPE              | Auto            | 0: FSAFE_VAL,<br>1: last valid OUT Value<br>2: wrong calculated Val | 1: last valid<br>OUT Value                 |  | Defines reaction of device, if a fault is detected.  |              |
| 37    | FSAFE_VAL_D             | Auto            | 0 or 1  | 0  |  | Default value for the OUT_D parameter, if sensor or sensor electronic fault is detected.   |              |
| 40    | SIMULATE<br>(DS-51)     | Simulate_Status | Auto  |  | 0  | For commissioning and test purposes the input value from the Transducer Block in the Discrete Input Function Block, DI-FB can be modified when the hardware simulation jumper is on. That means that the Transducer and DI-FB will be disconnected.  |              |
|       |                         | Simulate_Value  | Auto  |  | 0  |  |              |
|       |                         | Simulate_Value  | Auto  | 0: Disabled,<br>Enable exclude 0           | 0: Disabled  |  |              |
| 41-50 | reserved by PNO         |                 |   |  |  |  |              |
| 51    | VIEW_DI_FB              | –               |   |  |  | View objects allow the following groups of physical block parameter values to be read with one read request.<br>ST_REV, MODE_BLK, ALARM_SUM, OUT_D   |              |

T0905-1.EPS



# 10. MAINTENANCE

---

For maintenance items, please refer to user's manual IM 01E20D01-01E or IM 01E20C02-01E.

# APPENDIX 1. LIST OF DTM MENU

| Label for node and parameter |          |          |                                |                         |
|------------------------------|----------|----------|--------------------------------|-------------------------|
| 1st node                     | 2nd node | 3rd node | 1st row parameter              | 2nd row parameter       |
| <b>Process Variables</b>     |          |          |                                |                         |
|                              |          |          | Measured Value                 | Quality<br>Status       |
|                              |          |          | AI Output Value                | Quality<br>Status       |
|                              |          |          | TOT1 Totalizer Value           | Quality<br>Status       |
|                              |          |          | TOT2 Totalizer Value           | Quality<br>Status       |
|                              |          |          | TOT3 Totalizer Value           | Quality<br>Status       |
| <b>Device Status</b>         |          |          |                                |                         |
|                              |          |          | Not specified here             |                         |
| <b>Diag and Service</b>      |          |          |                                |                         |
|                              |          |          | AI Output Value                | Quality<br>Status       |
|                              |          |          | AI1 Simulation Value           | Quality<br>Status       |
|                              |          |          | AI1 Simulation                 | Status                  |
|                              |          |          | Adhesion Check                 |                         |
|                              |          |          | Adhesion Level 1               |                         |
|                              |          |          | Adhesion Level 2               |                         |
|                              |          |          | Adhesion Level 3               |                         |
|                              |          |          | Adhesion Level 4               |                         |
|                              |          |          | Measure Value                  |                         |
|                              |          |          | Start Adhesion Check           |                         |
| <b>Easy Setup</b>            |          |          |                                |                         |
|                              |          |          | TAG                            | Analog Input            |
|                              |          |          | Descriptor                     | Target Mode             |
|                              |          |          | Message                        | Actual Mode             |
|                              |          |          | Transducer Block               | Filter Time Const       |
|                              |          |          | Target Mode                    | PV Scale:Lower Value    |
|                              |          |          | Actual Mode                    | PV Scale:Upper Value    |
|                              |          |          | Measured Value Unit            | Out Scale:Upper Value   |
|                              |          |          | Filter Time                    | Out Scale:Lower Value   |
|                              |          |          | Local Display                  | Out Scale:Unit          |
|                              |          |          | Select1                        | Out Scale:Decimal Point |
|                              |          |          | Select2                        | Velocity Check          |
|                              |          |          | Select3                        |                         |
| <b>Calibration</b>           |          |          |                                |                         |
|                              |          |          | AI Output Value                | Quality<br>Status       |
|                              |          |          | Zero Point Offset              |                         |
|                              |          |          | Start Zero Point Adjustment    |                         |
| <b>Physical Block</b>        |          |          |                                |                         |
|                              |          |          | Static Revision No.            |                         |
|                              |          |          | Target Mode                    |                         |
|                              |          |          | Actual Mode                    |                         |
| <b>Identification</b>        |          |          |                                |                         |
|                              |          |          | TAG                            |                         |
|                              |          |          | Descriptor                     |                         |
|                              |          |          | Message                        |                         |
|                              |          |          | Manufacturer                   |                         |
|                              |          |          | Product designation            |                         |
|                              |          |          | Device Serial Num              |                         |
|                              |          |          | Software Revision              |                         |
|                              |          |          | Hardware Revision              |                         |
|                              |          |          | Profile Revision               |                         |
|                              |          |          | PROFIBUS Ident Number          |                         |
|                              |          |          | Installation Date              |                         |
|                              |          |          | Software Description           |                         |
| <b>Diagnosis</b>             |          |          |                                |                         |
|                              |          |          | Diagnosis                      |                         |
|                              |          |          | Diagnosis Extension            |                         |
| <b>Simulation Diagnosis</b>  |          |          |                                |                         |
|                              |          |          | Simulation                     |                         |
|                              |          |          | Diagnosis Simulation Extension |                         |
| <b>Function Block Status</b> |          |          |                                |                         |
|                              |          |          | Function Block Status          |                         |
| <b>Configuration</b>         |          |          |                                |                         |
|                              |          |          | Write Locking                  |                         |
|                              |          |          | Factory Reset                  |                         |
|                              |          |          | HW Write Protection            |                         |
| <b>Input</b>                 |          |          |                                |                         |
| <b>Transducer Block</b>      |          |          |                                |                         |
|                              |          |          | Static Revision No.            |                         |
|                              |          |          | Target Mode                    |                         |
|                              |          |          | Actual Mode                    |                         |
|                              |          |          | Measured Value                 | Quality<br>Status       |
|                              |          |          | Gain Compensation Factor       |                         |
|                              |          |          | Measured Value Unit            |                         |
|                              |          |          | Flow Direction                 |                         |
|                              |          |          | Low Flow Cut Off               |                         |
|                              |          |          | Measurement Mode               |                         |

|                                  |  |  |                            |                     |
|----------------------------------|--|--|----------------------------|---------------------|
|                                  |  |  | Nominal Size               |                     |
|                                  |  |  | Nominal Size Unit          |                     |
|                                  |  |  | Lo Limit - Lower Value Min |                     |
|                                  |  |  | Hi Limit - Upper Value Max |                     |
|                                  |  |  | Zero Point Offset          |                     |
|                                  |  |  | Filter Time                |                     |
|                                  |  |  | Density Unit               |                     |
|                                  |  |  | Mass Flow Density          |                     |
|                                  |  |  | Sample Rate                | Quality<br>Status   |
|                                  |  |  | Sample Rate Unit           |                     |
|                                  |  |  | Singal Lock                |                     |
| <b>Flow Tube</b>                 |  |  |                            |                     |
|                                  |  |  | Select Flow Tube           |                     |
|                                  |  |  | Dual Frequency Mode        |                     |
|                                  |  |  | Low MF                     |                     |
|                                  |  |  | High MF                    |                     |
|                                  |  |  | Low MF EDF                 |                     |
|                                  |  |  | High MF EDF                |                     |
| <b>DI Set</b>                    |  |  |                            |                     |
|                                  |  |  | D1 Output Value            | Quality<br>Status   |
|                                  |  |  | D12 Output Value           | Quality<br>Status   |
|                                  |  |  | Limit Switch 1             |                     |
|                                  |  |  | Value                      | Quality<br>Status   |
|                                  |  |  | Target                     |                     |
|                                  |  |  | Setpoint                   |                     |
|                                  |  |  | Direction                  |                     |
|                                  |  |  | Hysteresis                 |                     |
|                                  |  |  | Unit                       |                     |
|                                  |  |  | Limit Switch 2             |                     |
|                                  |  |  | Value                      | Quality<br>Status   |
|                                  |  |  | Target                     |                     |
|                                  |  |  | Setpoint                   |                     |
|                                  |  |  | Direction                  |                     |
|                                  |  |  | Hysteresis                 |                     |
|                                  |  |  | Unit                       |                     |
|                                  |  |  | Switch 1                   |                     |
|                                  |  |  | Value                      | Quality<br>Status   |
|                                  |  |  | Target                     |                     |
|                                  |  |  | Switch 2                   |                     |
|                                  |  |  | Value                      | Quality<br>Status   |
|                                  |  |  | Target                     |                     |
| <b>AUX</b>                       |  |  |                            |                     |
|                                  |  |  | Rate Limit                 |                     |
|                                  |  |  | Dead Time                  |                     |
|                                  |  |  | Pulsing Flow               |                     |
|                                  |  |  | Power Synch                |                     |
|                                  |  |  | Power Frequency            |                     |
|                                  |  |  | Software Rev No            |                     |
| <b>Mask Alarm</b>                |  |  |                            |                     |
|                                  |  |  | Alarm Perform              |                     |
| <b>Simulation Measured Value</b> |  |  |                            |                     |
|                                  |  |  | Measured Value             | Quality<br>Status   |
|                                  |  |  | Simulation Measured Value  | Quality<br>Status   |
|                                  |  |  | Simulation                 |                     |
|                                  |  |  | Type                       |                     |
|                                  |  |  | Upper Value                |                     |
|                                  |  |  | Lower Value                |                     |
|                                  |  |  | Time Interval or Cycle or  |                     |
| <b>Adhesion</b>                  |  |  |                            |                     |
|                                  |  |  | Adhesion Check             |                     |
|                                  |  |  | Adhesion Level 1           |                     |
|                                  |  |  | Adhesion Level 2           |                     |
|                                  |  |  | Adhesion Level 3           |                     |
|                                  |  |  | Adhesion Level 4           |                     |
|                                  |  |  | Measure Value              |                     |
| <b>Alarm Record</b>              |  |  |                            |                     |
|                                  |  |  | Operation Time             |                     |
|                                  |  |  | Alarm Record 1             | Alarm Record Time 1 |
|                                  |  |  | Alarm Record 2             | Alarm Record Time 2 |
|                                  |  |  | Alarm Record 3             | Alarm Record Time 3 |
|                                  |  |  | Alarm Record 4             | Alarm Record Time 4 |
| <b>Local Display</b>             |  |  |                            |                     |
|                                  |  |  | Language                   |                     |
|                                  |  |  | Display Cycle              |                     |
|                                  |  |  | Select1                    |                     |
|                                  |  |  | Select2                    |                     |
|                                  |  |  | Select3                    |                     |

APPENDIX 1. LIST OF DTM MENU

|                            |            |        |
|----------------------------|------------|--------|
| Output                     |            |        |
| Analog Input               |            |        |
| Static Revision No.        |            |        |
| Target Mode                |            |        |
| Actual Mode                |            |        |
| Channel                    |            |        |
| Simulation Value           | Simulation |        |
| Simulation Quality         | Status     |        |
| Fail Safe Mode             |            |        |
| Fail Safe Default Value    |            |        |
| Output Value               | Quality    | Status |
| Filter Time Const          |            |        |
| Characterization Type      |            |        |
| Out unit text              |            |        |
| Velocity Check             |            |        |
| Batch Information          |            |        |
| Batch ID                   |            |        |
| Batch Unit                 |            |        |
| Batch Operation            |            |        |
| Batch Phase                |            |        |
| PV Scale                   |            |        |
| Upper Value                |            |        |
| Lower Value                |            |        |
| Output Scale               |            |        |
| Upper Value                |            |        |
| Lower Value                |            |        |
| Unit                       |            |        |
| Decimal Point              |            |        |
| Warning and Alarm          |            |        |
| Upper Limit Alarm          |            |        |
| Upper Limit Warning        |            |        |
| Lower Limit Warning        |            |        |
| Lower Limit Alarm          |            |        |
| Hysteresis                 |            |        |
| Upper Limit Alarm Status   | Value      |        |
| Upper Limit Warning Status | Value      |        |
| Lower Limit Warning Status | Value      |        |
| Lower Limit Alarm Status   | Value      |        |
| Totalizer 1                |            |        |
| Static Revision No.        |            |        |
| Target Mode                |            |        |
| Actual Mode                |            |        |
| Channel                    |            |        |
| Simulation Value           | Simulation |        |
| Simulation Quality         | Status     |        |
| Fail Safe Mode             |            |        |
| Totalizer Mode             |            |        |
| Preset Value               |            |        |
| Totalizer Unit             |            |        |
| Totalizer Value            | Quality    | Status |
| Batch Information          |            |        |
| Batch ID                   |            |        |
| Batch Unit                 |            |        |
| Batch Operation            |            |        |
| Batch Phase                |            |        |
| Totalizer Reset            |            |        |
| Totalizer Value            | Quality    | Status |
| Preset Value               |            |        |
| Totalizer Set              |            |        |
| Warning and Alarm          |            |        |
| Upper Limit Alarm          |            |        |
| Upper Limit Warning        |            |        |
| Lower Limit Warning        |            |        |
| Lower Limit Alarm          |            |        |
| Limit Hysteresis           |            |        |
| Upper Limit Alarm Status   | Value      |        |
| Upper Limit Warning Status | Value      |        |
| Lower Limit Warning Status | Value      |        |
| Lower Limit Alarm Status   | Value      |        |
| Totalizer 2                |            |        |
| Static Revision No.        |            |        |
| Target Mode                |            |        |
| Actual Mode                |            |        |
| Channel                    |            |        |
| Simulation Value           | Simulation |        |
| Simulation Quality         | Status     |        |
| Fail Safe Mode             |            |        |
| Totalizer Mode             |            |        |
| Preset Value               |            |        |
| Totalizer Unit             |            |        |
| Totalizer Value            | Quality    | Status |
| Batch Information          |            |        |
| Batch ID                   |            |        |

|                            |            |        |
|----------------------------|------------|--------|
| Batch Unit                 |            |        |
| Batch Operation            |            |        |
| Batch Phase                |            |        |
| Totalizer Reset            |            |        |
| Totalizer Value            | Quality    | Status |
| Preset Value               |            |        |
| Totalizer Set              |            |        |
| Warning and Alarm          |            |        |
| Upper Limit Alarm          |            |        |
| Upper Limit Warning        |            |        |
| Lower Limit Warning        |            |        |
| Lower Limit Alarm          |            |        |
| Limit Hysteresis           |            |        |
| Upper Limit Alarm Status   | Value      |        |
| Upper Limit Warning Status | Value      |        |
| Lower Limit Warning Status | Value      |        |
| Lower Limit Alarm Status   | Value      |        |
| Totalizer 3                |            |        |
| Static Revision No.        |            |        |
| Target Mode                |            |        |
| Actual Mode                |            |        |
| Channel                    |            |        |
| Simulation Value           | Simulation |        |
| Simulation Quality         | Status     |        |
| Fail Safe Mode             |            |        |
| Totalizer Mode             |            |        |
| Preset Value               |            |        |
| Totalizer Unit             |            |        |
| Totalizer Value            | Quality    | Status |
| Batch Information          |            |        |
| Batch ID                   |            |        |
| Batch Unit                 |            |        |
| Batch Operation            |            |        |
| Batch Phase                |            |        |
| Totalizer Reset            |            |        |
| Totalizer Value            | Quality    | Status |
| Preset Value               |            |        |
| Totalizer Set              |            |        |
| Warning and Alarm          |            |        |
| Upper Limit Alarm          |            |        |
| Upper Limit Warning        |            |        |
| Lower Limit Warning        |            |        |
| Lower Limit Alarm          |            |        |
| Limit Hysteresis           |            |        |
| Upper Limit Alarm Status   | Value      |        |
| Upper Limit Warning Status | Value      |        |
| Lower Limit Warning Status | Value      |        |
| Lower Limit Alarm Status   | Value      |        |
| Discrete Input 1           |            |        |
| Static Revision No.        |            |        |
| Target Mode                |            |        |
| Actual Mode                |            |        |
| Channel                    |            |        |
| Simulation Value           | Simulation |        |
| Simulation Quality         | Status     |        |
| Invert Input Value         |            |        |
| Fail Safe Mode             |            |        |
| Fail Safe Default Value    |            |        |
| Output Value               | Quality    | Status |
| Batch Information          |            |        |
| Batch ID                   |            |        |
| Batch Unit                 |            |        |
| Batch Operation            |            |        |
| Batch Phase                |            |        |
| Discrete Input 2           |            |        |
| Static Revision No.        |            |        |
| Target Mode                |            |        |
| Actual Mode                |            |        |
| Channel                    |            |        |
| Simulation Value           | Simulation |        |
| Simulation Quality         | Status     |        |
| Invert Input Value         |            |        |
| Fail Safe Mode             |            |        |
| Fail Safe Default Value    |            |        |
| Output Value               | Quality    | Status |
| Batch Information          |            |        |
| Batch ID                   |            |        |
| Batch Unit                 |            |        |
| Batch Operation            |            |        |
| Batch Phase                |            |        |

# APPENDIX 2. LIST OF PDM (EDDL) MENU

|                            |                              |
|----------------------------|------------------------------|
| AXF PA                     |                              |
| Easy Setup                 |                              |
|                            | TAG                          |
|                            | Descriptor                   |
| Volume Flow-Measured Value |                              |
|                            | Unit                         |
|                            | Filter Time                  |
| Process Value Scale        |                              |
|                            | Lower Value                  |
|                            | Upper Value                  |
| Out scale                  |                              |
|                            | Lower Value                  |
|                            | Upper Value                  |
|                            | Unit                         |
|                            | Decimal Point                |
| Local Display              |                              |
|                            | Select1                      |
|                            | Select2                      |
|                            | Select3                      |
| Transducer Block           |                              |
|                            | Target Mode                  |
|                            | Actual Mode                  |
| Analog Input               |                              |
|                            | Target Mode                  |
|                            | Actual Mode                  |
|                            | Filter Time Const            |
|                            | Velocity Check               |
| Identification             |                              |
| Operation Unit             |                              |
|                            | TAG                          |
|                            | Descriptor                   |
|                            | Message                      |
| Device                     |                              |
|                            | Manufacturer                 |
|                            | Product designation          |
|                            | Device Serial Num            |
|                            | Software Revision            |
|                            | Hardware Revision            |
|                            | Profile Revision             |
|                            | Static Revision No.          |
|                            | PROFIBUS Ident Number        |
|                            | Installation Date            |
|                            | Software Description         |
| Input                      |                              |
| Transducer Block - Flow    |                              |
|                            | Gain Compensation Factor     |
|                            | Unit                         |
|                            | Flow Direction               |
|                            | Low Flow Cut Off             |
|                            | Mode                         |
|                            | Nominal Size                 |
|                            | Nominal Size Unit            |
|                            | Low Limit - Lower Value Min  |
|                            | High Limit - Upper Value Max |
|                            | Zero Point Offset            |
|                            | Filter Time                  |
|                            | Density Unit                 |
|                            | Mass Flow Density            |
|                            | Target Mode                  |
|                            | Actual Mode                  |
| Flow Tube                  |                              |
|                            | Select Flow Tube             |
|                            | Dual Frequency Mode          |
|                            | Low MF                       |
|                            | High MF                      |
|                            | Low MF EDF                   |
|                            | High MF EDF                  |

|        |  |                       |
|--------|--|-----------------------|
|        |  | DI Set                |
|        |  | Limit Switch 1        |
|        |  | Value                 |
|        |  | Status                |
|        |  | Limit                 |
|        |  | Target                |
|        |  | Setpoint              |
|        |  | Direction             |
|        |  | Hysteresis            |
|        |  | Unit                  |
|        |  | Limit Switch 2        |
|        |  | Value                 |
|        |  | Status                |
|        |  | Limit                 |
|        |  | Target                |
|        |  | Setpoint              |
|        |  | Direction             |
|        |  | Hysteresis            |
|        |  | Unit                  |
|        |  | Switch 1              |
|        |  | Value                 |
|        |  | Status                |
|        |  | Limit                 |
|        |  | Target                |
|        |  | Switch 2              |
|        |  | Value                 |
|        |  | Status                |
|        |  | Limit                 |
|        |  | Target                |
|        |  | AUX                   |
|        |  | Rate Limit            |
|        |  | Dead Time             |
|        |  | Pulsing Flow          |
|        |  | Power Synch           |
|        |  | Power Frequency       |
|        |  | Software Rev No       |
|        |  | Mask Alarm            |
|        |  | Alarm Perform         |
|        |  | Adhesion              |
|        |  | Adhesion Check        |
|        |  | Adhesion Level1       |
|        |  | Adhesion Level2       |
|        |  | Adhesion Level3       |
|        |  | Adhesion Level4       |
|        |  | Measure Value         |
| Output |  |                       |
|        |  | Analog Input          |
|        |  | Static Revision No.   |
|        |  | Channel               |
|        |  | Unit                  |
|        |  | Out unit text         |
|        |  | Filter Time Const     |
|        |  | Characterization Type |
|        |  | Target Mode           |
|        |  | Actual Mode           |
|        |  | Batch Information     |
|        |  | Batch ID              |
|        |  | Batch Unit            |
|        |  | Batch Operation       |
|        |  | Batch Phase           |
|        |  | Process Value Scale   |
|        |  | Lower Value           |
|        |  | Upper Value           |
|        |  | Output scale          |
|        |  | Lower Value           |
|        |  | Upper Value           |
|        |  | Output Limits         |
|        |  | Lower Limit Alarm     |

APPENDIX 2. LIST OF PDM (EDDL) MENU

|                 |                    |                         |
|-----------------|--------------------|-------------------------|
|                 |                    | Lower Limit Warning     |
|                 |                    | Upper Limit Warning     |
|                 |                    | Upper Limit Alarm       |
|                 |                    | Hysteresis              |
|                 | Fail Safe Mode     |                         |
|                 |                    | Fail Safe Mode          |
|                 |                    | Fail Safe Default Value |
|                 | Human Interface    |                         |
|                 |                    | Decimal Point           |
|                 | Velocity check     |                         |
|                 |                    | Velocity Check          |
| Discrete Input1 |                    |                         |
|                 | Satic Revision No. |                         |
|                 | Channel            |                         |
|                 | Invert Input Value |                         |
|                 | Target Mode        |                         |
|                 | Actual Mode        |                         |
|                 | Batch Information  |                         |
|                 |                    | Batch ID                |
|                 |                    | Batch Unit              |
|                 |                    | Batch Operation         |
|                 |                    | Batch Phase             |
|                 | Fail Safe Mode     |                         |
|                 |                    | Fail Safe Mode          |
|                 |                    | Fail Safe Default Value |
| Discrete Input2 |                    |                         |
|                 | Satic Revision No. |                         |
|                 | Channel            |                         |
|                 | Invert Input Value |                         |
|                 | Target Mode        |                         |
|                 | Actual Mode        |                         |
|                 | Batch Information  |                         |
|                 |                    | Batch ID                |
|                 |                    | Batch Unit              |
|                 |                    | Batch Operation         |
|                 |                    | Batch Phase             |
|                 | Fail Safe Mode     |                         |
|                 |                    | Fail Safe Mode          |
|                 |                    | Fail Safe Default Value |
| Totalizer1      |                    |                         |
|                 | Satic Revision No. |                         |
|                 | Channel            |                         |
|                 | Unit (Totalizer)   |                         |
|                 | Mode               |                         |
|                 | Preset Value       |                         |
|                 | Fail Safe Mode     |                         |
|                 | Target Mode        |                         |
|                 | Actual Mode        |                         |
|                 | Batch Information  |                         |
|                 |                    | Batch ID                |
|                 |                    | Batch Unit              |
|                 |                    | Batch Operation         |
|                 |                    | Batch Phase             |
|                 | Output Limits      |                         |
|                 |                    | Lower Limit Alarm       |
|                 |                    | Lower Limit Warning     |
|                 |                    | Upper Limit Warning     |
|                 |                    | Upper Limit Alarm       |
|                 |                    | Limit Hysteresis        |
| Totalizer2      |                    |                         |
|                 | Satic Revision No. |                         |
|                 | Channel            |                         |
|                 | Unit (Totalizer)   |                         |
|                 | Mode               |                         |
|                 | Preset Value       |                         |
|                 | Fail Safe Mode     |                         |
|                 | Target Mode        |                         |
|                 | Actual Mode        |                         |

|               |                    |                   |                     |
|---------------|--------------------|-------------------|---------------------|
|               |                    | Batch Information |                     |
|               |                    |                   | Batch ID            |
|               |                    |                   | Batch Unit          |
|               |                    |                   | Batch Operation     |
|               |                    |                   | Batch Phase         |
|               |                    | Output Limits     |                     |
|               |                    |                   | Lower Limit Alarm   |
|               |                    |                   | Lower Limit Warning |
|               |                    |                   | Upper Limit Warning |
|               |                    |                   | Upper Limit Alarm   |
|               |                    |                   | Limit Hysteresis    |
| Totalizer3    |                    |                   |                     |
|               | Satic Revision No. |                   |                     |
|               | Channel            |                   |                     |
|               | Unit (Totalizer)   |                   |                     |
|               | Mode               |                   |                     |
|               | Preset Value       |                   |                     |
|               | Fail Safe Mode     |                   |                     |
|               | Target Mode        |                   |                     |
|               | Actual Mode        |                   |                     |
|               | Batch Information  |                   |                     |
|               |                    |                   | Batch ID            |
|               |                    |                   | Batch Unit          |
|               |                    |                   | Batch Operation     |
|               |                    |                   | Batch Phase         |
|               |                    | Output Limits     |                     |
|               |                    |                   | Lower Limit Alarm   |
|               |                    |                   | Lower Limit Warning |
|               |                    |                   | Upper Limit Warning |
|               |                    |                   | Upper Limit Alarm   |
|               |                    |                   | Limit Hysteresis    |
| Local Display |                    |                   |                     |
|               | Select1            |                   |                     |
|               | Select2            |                   |                     |
|               | Select3            |                   |                     |
|               | Display Cycle      |                   |                     |
|               | Language           |                   |                     |
| Target Mode   |                    |                   |                     |
|               | Physical Block     |                   |                     |
|               |                    |                   | Target Mode         |
|               |                    |                   | Actual Mode         |
|               | Transducer Block   |                   |                     |
|               |                    |                   | Target Mode         |
|               |                    |                   | Actual Mode         |
|               | Analog Input       |                   |                     |
|               |                    |                   | Target Mode         |
|               |                    |                   | Actual Mode         |
|               | Totalizer1         |                   |                     |
|               |                    |                   | Target Mode         |
|               |                    |                   | Actual Mode         |
|               | Totalizer2         |                   |                     |
|               |                    |                   | Target Mode         |
|               |                    |                   | Actual Mode         |
|               | Totalizer3         |                   |                     |
|               |                    |                   | Target Mode         |
|               |                    |                   | Actual Mode         |
|               | Discrete Input1    |                   |                     |
|               |                    |                   | Target Mode         |
|               |                    |                   | Actual Mode         |
|               | Discrete Input2    |                   |                     |
|               |                    |                   | Target Mode         |
|               |                    |                   | Actual Mode         |

# REVISION RECORD

Title: AXF PROFIBUS PA Communication Type Magnetic Flowmeter  
Manual No.: IM 01E20F12-01E

| <b>Edition</b> | <b>Date</b> | <b>Page</b>                            | <b>Revised Item</b>  |
|----------------|-------------|--|--|
| 1st            | Mar. 2008   | –                                      | New publication  |
| 2nd            | Sep. 2015   | 1-1<br>1-2 to 1-3<br>1-3<br>1-4<br>8-1 | 1. Added the NOTE for this manual.<br>1.1 (1), (3), (4), (5), (6), (7), (8), (9) Added the WARNING.<br>1.2 Added the Trademarks.<br>1.3 Changed the IMPORTANT for combination remote flowtubes.<br>8.1 Changed the definition of accuracy. |

REVISION RECORD.EPS